

95x70mm

Wi-Fi带屏网络智能摄像机 使用说明书 千鸟物联APP

一、下载并安装APP

1.通过扫描二维码快速下载并安装



2.在手机软件应用商店搜索“千鸟物联”下载并安装

二、注册登录

- 1.新用户需要注册账号，点击“立即注册”，进入注册页面
- 2.选择您所在的国家，输入账户名称（手机号或邮箱），通过验证码可按提示进行注册操作
- 3.已有账号可直接输入账户名与密码进行登录



三、摄像机连接的两种方法

第一次配置Wi-Fi的时候请尽可能放置摄像机靠近Wi-Fi路由器的位置，配置完成后在安装到需要安装的位置。
3-1.热点添加摄像机给摄像机接通电源，等待摄像机启动成功后发出“请使用手机客户端软件进行无线配置后”打开手机APP——点击右上角“+”号——选择“热点添加”。



1.点击右上角“+”号 2.点击“热点添加” 3.勾选确认，点击“下一步” 4.输入Wi-Fi密码,点击“下一步”



5.点击切换网络，跳转连接监控热点 6.找到HAP-XXXXXX开头的Wi-Fi点击连接 7.返回APP，显示连接成功后点击下一步 8.等待设备上电，连接成功后页面跳转 9.连接成功，点击观看

3-2.二维码添加



1.打开千鸟物联app,点击右上角“+”号 2.点击“智能添加” 3.点击下一步 4.输入Wi-Fi密码，点击下一步生成二维码 5.将二维码放到手机镜头前，大概距离10cm到20cm.听到“Wi-Fi识别成功的提示音”后，等待手机自动跳转至连接页面 6.等待设备上电，连接成功后页面跳转 7.连接成功，点击观看

四、首页



常见问题解答

1. 网络连接不上怎么办？
A：若摄像机接网线即100%连上网络，在APP里面的添加页面打开“网线添加摄像机”。
B：若用Wi-Fi，请确保Wi-Fi密码正确，勿插入网线，同时听到摄像机发出开机音乐，用复位针复位后，选择“网线添加摄像机”根据提示操作即可，如果周围有强电干扰，或者Wi-Fi用至高峰时，建议使用网线连接。注意：首选确保摄像机已通电，并正常启动听到摄像机发出音乐声。摄像机需要使用随机标配电源，手机电源无法保证摄像机正常工作。
2. 图像卡顿是什么问题？
摄像机需要一定的上传带宽维持一个稳定的连接，推荐摄像机所接网络上行带宽在2M以上，手机所处网络下行带宽建议2M以上，若摄像机接入的是Wi-Fi，Wi-Fi使用的人较多也会导致图像卡，建议摄像机插网线再试。
3. 摄像机有时候在添加时，在“连接中”状态下进入较慢是正常的吗？
是正常的，因为此时摄像机的用户信息正在保存到云端服务，这需要时间相互通信，以后手机若不慎丢失，更换新手机只要登录账号不变，摄像机所有信息都不需要重新输入。
4. 摄像机维护注意事项
若图像逐步模糊，可用软布沾酒精擦拭镜头，去除污渍影像即清晰。摄像机喇叭报警声建议不能长期打开，报警声音会吵扰周围邻居，同时也影响喇叭寿命。

六、分享功能



6-2.通过面对面扫码进行分享进行分享

6-1.通过输入账号进行分享
(输入用户注册的手机号码或者是邮箱账号进行分享)


七、录像功能

报警录像：打开移动侦测后检测到物体移动会进行录像
全时录像：全时间录像
计划录像：可设置录像的时间段

八、报警功能

打开推送开关和移动侦测,摄像机报警信息可以发送到手机上。
8-1.移动侦测:当周围物体移动时,会触发报警
8-2.人形侦测:当检测到有人时,会触发报警

九、云存储回放



十、录像回放



十一、移动追踪

周围物体移动时，摄像机自动转动镜头跟踪定位
1.点击摄像机设置-点击移动追踪
2.选择悬屏时间后，点击确定。

十二、悬屏设置

可设置多长时间无操作后悬屏。
1.点击摄像机设置-点击悬屏设置。
2.选择悬屏时间后，点击确定。

十三、视频通话功能

- 1.在只有主账号添加设备的情况下，通话按钮1与通话按钮2都是通话键，按压后可与主账号视频通话。
- 2.在主账号和分享账号都绑定该设备的情况下，通话按钮1对应与主账号通话，通话按钮2对应与分享账号通话。
- 3.按呼叫键呼叫用户后，app未接通视频通话的情况下，5秒钟之后再按一次呼叫键就会停止呼叫。



WI FI SCREEN NETWORK INTELLIGENT CAMERA User Manual V360 Pro APP

I Download and install the app


1.Quickly download and install by scanning the QR code



2.Search for "V360 Pro" in the mobile app store to download and install


II Registration and login

- 1.New users need to register an account, click "Register Now" to enter the registration page
- 2.Select your country, enter your account name (phone number or email), and use the verification code to follow the prompts for registration
- 3.Existing accounts can be directly logged in by entering the account name and password




III Two methods of camera connection

When configuring Wi-Fi for the first time, please place the camera as close to the Wi-Fi router as possible, and then install it to the location that needs to be installed after the configuration is completed
3-1. Add a camera to the hot spot to connect the camera to the power supply. After the camera is started successfully, issue "Please use the mobile phone client software for wireless configuration" to open the mobile phone APP - click the "+" sign in the upper right corner - select "Add a hot spot"



1. Click the "+" in the upper right corner 2. Click "Add hotspot" 3. Check to confirm and click "Next" 4. Enter the Wi-Fi password and click "Next"




5. Click Switch Network to jump to the connection monitoring hotspot 6. Find the Wi-Fi at the beginning of HAP - XXXXXX and click Connect 7. Return to APP and click Next after the connection is successful 8. Wait for the device to go online, and the page will jump after the connection is successful 9. Connect successfully, click to view

3-2. QR code addition



1. Open the V360 Pro APP and click the "+" sign in the upper right corner 2. Click "Smart Add" 3. Click Next 4. Enter the Wi-Fi password and click Next to generate the QR code 5. Place the QR code in front of the camera lens at a distance of approximately 10cm to 20cm. Hear the "Wi-Fi recognition successful prompt tone" Waiting for the phone to automatically redirect to the connection page 6. Wait for the device to go online, and the page will jump after the connection is successful 7. Connect successfully, click to view


IV Home page



FAQs:

1. What if I can't connect to the network?
If you use Wi-Fi, please make sure that the Wi-Fi password is correct. Do not plug in the network cable, and hear the video camera send out power-on music at the same time. After resetting with the reset pin, select Smart Add and follow the prompts.
Note: It is the first choice to ensure that the camera is powered on, and to hear the warning sound of the camera when it is started normally. The camera needs to use the standard power supply, and the mobile phone power supply cannot guarantee the normal operation of the camera.
2. What is the problem with image jamming?
The camera needs a certain upload bandwidth to maintain a stable connection. It is recommended that the uplink bandwidth of the network where the camera is located be more than 2M, and the downlink bandwidth of the network where the mobile phone is located be more than 2M. If the camera is connected to Wi-Fi, many people using Wi-Fi will also lead to image affected.
3. Is it normal for the camera to enter slowly in the "connected state" when it is added?
It is normal because at this time, the user information of the camera is being saved to the service, which requires time to communicate with each other. If the mobile phone is accidentally lost in the future, replace it with a new one, as long as the login account remains unchanged, and all the camera information does not need to be re-entered.

VI Sharing function



6-2. Share through face-to-face QR code scanning

6-1. Share by entering an account
(Enter the user's registered mobile phone number or email account) Share)


VII Recording function

Alarm record: Object movement detected after turning on motion detection will be recorded
Full time record: Full time recording
Plan record: The time period for recording can be set


VIII Alarm function

Turn on the push switch and motion detection, and the camera alarm information can be sent to your phone.
1. Movement detection: When surrounding objects move, an alarm will be triggered.
2. Human Shape Detection: When someone is detected, an alarm will be triggered.

IX Cloud Storage Playback



X Video replay




VII Screen settings

How long can the screen be reset without operation be set.
1. Click on Camera Settings - click on Screen Settings.
2. After selecting the screen rest time, click OK.

XI Mobile Tracking

When surrounding objects move, the camera automatically rotates the lens to track and locate them
1. Click on camera settings - click on motion tracking



XIII Video call function

1. Can make video calls with bound accounts.
1. When only the main account adds a device, make a call Both button 1 and call button 2 are call buttons, which can be pressed to Video call with the main account.
2. In the case where both the main account and the shared account are bound to the device, call button 1 corresponds to calling with the main account, and call button 2 corresponds to calling with the shared account.
3. After pressing the call button to call the user, if the app does not connect to the video call, pressing the call button again after 5 seconds will stop the call.



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.