


Remote control cabinet light



CW




RGB



RGB+W


PACKAGE CONTENTS

A




Remote Control

B



LED Puck Light

C




Adhesive Mounting Pad

▲ SAFETY INFORMATION


Please read and understand this entire manual before attempting to assemble, operate or install the product. Anywhere Nightlight, Wall Light for Entrance, Hallway, Basement, Cabinet, Closet and so on.

ASSEMBLY INSTRUCTIONS


1. Determine and lightly mark location for each puck.




2. To open the puck, rotate the two halves until the parts are aligned, then lift off the top.




3. Install batteries, matching polarity, into each puck.




4. Reassemble the puck by aligning the covers then rotating to secure.




5. Attach one adhesive mounting pad to the underside of each puck light.




6. Peel off adhesive strip and push puck firmly to secure to mounting surface in locations marked.




7. By pressing the lamp body center, you can turn off the lamp manually, turn on the lamp and adjust the color of the lamp.



8. To replace remote control's battery follow directions on back of remote control to slide battery drawer out. Replace battery (+side up) and slide battery drawer back in.



9. Use remote control for on/off control, dimming and setting operation duration. You can put it in the bathroom, wardrobe, cabinet, bedside cabinet corridor, etc. It's more convenient for lighting at night.



SAFETY INFORMATION

Before beginning installation of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble, install or operate the product.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.