

65*95 mm

eFones

WiMag 5000mAh Magnetic Wireless Powerbank User Manual

1. Work as magnetic suction wireless powerbank, supporting iPhone 12-15 Series



2. Work as normal wireless powerbank, supporting all mobile phones with Qi protocol



Supporting OP, HW, XM, SAM and other wireless charging phones

3. Work as portable small size powerbank, supporting normal charging for 99% phones



4. It is both a wireless charger and a mobile phone holder, which brings more convenience to charging

Notes: wireless charging function

- ★ Put the phone on the wireless charger, click to turn on the wireless charging function
- ★ When using the charger to charge the powerbank, when the input is in the fast charging state, then turn on the wireless charging for fast charging.


3C DIGITAL ORIGINAL DESIGN

Features

- 15W magnetic wireless quick charging
- 5000mAh wireless+magnetic suction 3 in 1
- QC+PD 20W quick charging
- Sync input and output for portable charging
- Accurate LED power indicators
- High quality safe polymer battery

Packing details

- Powerbank, manual*1



Specifications

Name:	Magnetic Wireless Powerbank
Model:	WiMag
Capacity:	5000mAh/3.8V (19Wh)
Lightning Input:	5V=2A
Wireless Output:	15W/10W/7.5W/5W
Type-C Input:	5V=3A, 9V=2A (PD 18W)
Type-C Output:	5V=3A, 9V=2.22A, 12V=1.67A (PD 20W)
Working temperature:	-10°C-40°C



Power Indicators

Power indicators to monitor the power status

1. Checking remaining power:



Click the button, if one white light is on, it means the power is within 25%, if two white lights are on it means the power is within 50%, if three white lights are on it means the power is within 75%, and if four white lights are on, it means the power is within 100%. When the last light of the light flashes, the battery level is less than 5%, please charge it as soon as possible

2. Checking charging function:



After clicking the button, during use, the fifth light turns on red, indicating that the mobile power supply has started the fast charging function. For example, the fifth light is always on blue light, indicating that the mobile power wireless charging is working normally



Notes and Warnings

- ★ If this device is not used for a long time, please charge it at least every 3 months
- ★ It might produce slight heat during charging, which is normal as long as it's below 55°C
- ★ Always keep this device dry and do not clean it with chemical agents
- ★ Go green with XIPIN and recycle this device at designated place
- ★ Children must use it under the guidance of adults.
- ★ Do not crash, disassemble, impale or put this device into humid conditions.
- ★ Do not use it to charge devices with incompatible current and voltage, which will cause fire or other problems



FAQ

- ★ When it's not charging for this device:
 - Please check the cable, charger or adapter used are working
 - If not, please choose compatible components to charge it
- ★ When it's charging for the phone
 - Please make sure the power is on and there is power left in this device
 - If above are checked OK, please go to the local retailer for assistance

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.