

Mormoque


NECKBAND HEADPHONE

G5



USER'S MANUAL

APPEARANCE AND PARAMETER



- Button illustration:**
- 1. Multi-function Button
 - 2. Type-C
 - 3. LED indicator
 - 4. Volume-/Previous Track
 - 5. Volume+/Next Track
 - 6. MIC

1

CHARGING YOUR EARPHONE

Your Bluetooth earphones come with a built-in rechargeable battery and a charging cable

Charge fully before use

Using the charging cable through the corresponding port to charge the battery, the LED indicator will show red while charging, and show blue once fully charged.

GETTING STARTED

To use your Bluetooth earphones, please follow the steps below:

1. Ensure your Bluetooth earphones are fully charged.
2. Pair your Bluetooth earphones to a Bluetooth-enabled device prior to use.(See Pairing instructions)

Powering On the Earphone

Press and hold the Multi-Function Button for 3 seconds until blue lights on

2

Powering Off the Earphone

Once powered on, press and hold the Multi-Function Button for 5 seconds until red lights on and out.

PAIRING YOUR EARPHONE

1. Power on your Bluetooth earphones
2. Press and hold the Multi-Function Button for approximately 5-6 seconds until the indicator flashes blue and red alternatively, your earphones are now in pairing mode.

3. Activate the Bluetooth function of your devices and start to search.
4. The indicator will flash blue every 10 seconds once successfully paired/connected.

Note:

1. The earphones should be within 30ft range from your Bluetooth devices while pairing/playing.
2. The earphones will automatically power off without connection for 5 minutes

GAME MODE

Triple-click the function to activate Game Mode (low latency).

MUSIC MODE

- **Adjust Volume:**
Short press the Volume+ to raise the volume or Volume- to lower the volume. You can also adjust the volume by your Bluetooth devices.

- **Redialing a Call:**
Double click the Multi-Function Button to redial the last dialed phone number on your mobile phone.

- **Play/Pause Music:**
Once connected, short press the Multi-Function Button to play or pause music.

- **Previous Track:**
Press and hold the Volume- 1 second to the previous track.

- **Next Track:**
Press and hold the volume+ 1 second to the next track.

CALL MODE

- **Answering a Call:**
Short press the Multi-Function Button to answer an incoming call, or answer the call normally via your mobile phone.

- **Rejecting a Call:**
Press and hold the Multi-Function Button for 2 seconds to reject the incoming call.

3

LED INDICATOR

STATUS	INDICATOR
Power On	Blue(slow flash)
Power Off	Red(solid and out)
Charging	Red(solid)
Fully Charged	Blue(solid)
Pairing	Blue/Red(quick flash)
Connected	Blue(slow flash)
Low Power	Red(quick flash)

4

Specifications:

- Bluetooth Version: 5.2
- HIFI/FPA/DAP/AVRCP/SC
- Frequency: 24.02 MHz - 24.48 MHz
- Wireless distance: up to 10 meters
- Frequency response range: 20Hz-20kHz
- Charging time: about 1 hours
- Wireless class: X4
- Battery capacity: 15 mAh - 15 mAh
- Playtime: about 8 hours in 70% volume
- Microphone: yes
- Weight device: 3g
- Contents of package: charging cable, USB-C, headset, user manual, warranty card, 2 earbud



Manufacturer: Mormoque Electronic Technology (Dongguan) Co., Ltd
Address: Room 401 Building 5, No. 1, Yuxing South Road, Hengtai Town, Dongguan City, Guangdong Province, China
Customer service: mormoque@foxmail.com

5

6

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.