




KB-TWS-C90

True Wireless Stereo Earbuds



User Manual

Product Specification

Model: KB-TWS-C90

Product Name: TWS Earphone

Wireless version: V5.3

Transmission Distance: 10-15M (open area)

Music time: Around 6 Hrs per charge at 50% volume, total around 20 Hrs with charging case

Charging time: around 2 Hrs

Standby time: >100 Hrs

Charging box capacity: 230mAh

Operation Instruction

Previous track: Double click L

Next track: Double click R

Volume increase: Three clicks L

Volume reduction: Three presses R

Voice Assistant: Long press for 2 seconds left/right

Pause/Play: Press left/right


Answer call: Press left/right

Hang up the phone: Press left/right

Reject call: Double press left/right

Power off time: default 3 minutes, can be held down manually for 4-5 seconds to turn off, default is on when placed in compartment

Product Schematic >>



- ① Charging case indicator ② Charging case
② ③ Charging port ④ Dust-proof Mesh
③ ⑤ Touch area ⑥ Earbud charging contact

Charging Case

When charging: LED will flash red

Fully charged: LED will stay red

When charging the earbuds: LED will stay blue

Charging time: around 90 minutes

Earbuds

When charging: LED will stay red

Fully charged: LED will turn off

Charging time: around 60 minutes

Warning :

When you are plugging your cable into a wall charger, we recommend using a UL/ETL 5V/1A approved charger. Don't use the fast charger over 5V/1A to avoid damage to the charging case. To ensure the battery life of the earbuds, the earbuds and charging case should be charged once a month.

Product operation >>

Using Both Earbuds/Binaural Use:

1. Take the earbuds from the charging case, the earbuds will automatically turn on and pair.

2. Turn on the Bluetooth of your mobile phone and put the earbuds close to the mobile phone. Select "KB-TWS-C90" from the Bluetooth device list to connect.

Power off:

1. Put the earbuds into the charging case, the earbuds will turn off automatically. The charging case will automatically charge the earbuds;
2. When the earbuds is turned on, long touch for 5 seconds to turn it off;
3. If the earbuds is not connected for 5 minutes, it will power off automatically.

Charging:

Prepare the USB charger and connect the charging cable to the charger and connect charging case. When charging, the LED will flash red. When fully charged, the LED will stay red.

FAQ

A. When the earbuds can't power on automatically

Check whether the earbuds have power (After the earbuds put into the charging cases and connect it with the USB charging cable, make sure to charge continuously for more than 1 hour.)

B. When the earbuds have only one side sound or the mobile phone can not find the Bluetooth device

1. Make sure that both earbuds are powered on and the Bluetooth of mobile phone is activated.
2. Check whether the earbuds connected with other Bluetooth device.
3. Clear away all the relevant Bluetooth device name on the mobile phone, put both earbuds back into charging cases and take them out after a while to reconnect.

C. When the earbuds is stuck or disconnected while talking or playing music

1. The earbuds are low power,
2. Check whether the distance between earbuds and mobile phone is more than 10 meters.
3. Check whether there is any large area of signal barrier between the earbuds and mobile phone, such as wall or iron door
4. There may be some interfering devices nearby, such as routers or other BT

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.