WH-200

User Documentation

1. Parameter

Model	WH-200	Туре	Headset
wireless	V5.3+EDR	Protocol	A2DP、AVRCP, HSP, IIFF
Frequencyrange	2. 4-2. 4835G	TX power	Class B
CVCTMDSP	Support	Effective	10 Meter
FM Radio		Frequency	87-108MHz
Mico SD/TFCard	Support	Max support	32G
Speaker material	NsFeB	Specification	40mm
Sensistance	105±3dB	Distortion	≤1%At1KHz
Power ToBear	30mW	Frequency	20-20KHz
Resistance	32Ω	Recognition	Capacitance
Microphone	Support	Frequency	30-16KHz
Sensitivity	58 ±3dB	Recognition	Capacitance
Life time	12-15 hours	Charge port	USB
		Charge time	about 4hours
Standby	0.5-0.6mA		
Battery type	Lithium	Charge voltage	5 V
Battery capacity	400 mAH	Temperature	15° CTo35° C

2.Button.interface.switch





Type-c charging port

Search pairing name: WH-200

Turn on key/pause key/make a call (short press to answer and end, long press to reject)

- Long press previous/short press to decrease volume
- → Long press/short press to increase volume

Short press the mode key to switch between Bluetooth, TF card, and FM mode (short press the power button to search for channels)

Red light on when charging blue light on when fully charged

Be careful.

(Do not charge with a charging head exceeding 1.5A)

wireless

& Switch, Hold down the The & headset will then start. Light blue light and green light flashing in each other. Headset wireless is on, Waiting for connerction state, wireless headse thas place ai this time in the state can befind.

2) Click on the wirelss Settings in the phone Settings, select "open". This is opened

Mobile phonewirelss function.

3) Open the phone's bluetooth option, to find, search to wait for matching success Bluetooth, shown on the list of equipment available for WH-200 click WH-200 connection, atthis time Headphones light flashing, saysit has the connection is successful. Note: the part of the mobile

3.1.TF Card Play

Insert TF to headphones in the card slot, long press the M key switch to the cardread mode, indicatorlight, Flashing System automatically decoded audio format file, at this point your favorite melodious songs Gently.

phoneconnection, instructions Need to enter the password (0000).

.2. Switch on/hang up %

Short by answering the telephone, long press for 3 seconds to hang up the phone.

Beforecharging the headset off, to make the charging line headset with computer USB connection. The headset indicator light is red, the

headset is charging. The built-in battery capacity test and fire protection. Don't have to worry about charging time of the batterylmpact. Light automatically extinguished said charging has been completed.

Low—power low battery automatically shut down, please charge as soon as possible, so as to meet the blusSystem re quirements. Note:please don't open he headset in the process of charging, therwise

damage the headset battery hardeareLife.

5.Matters needing attention

- 1) this head set is not waterproof, please pay attention to wateroof and moistu prroof, to ensure that the system can be positive Oiten use. 2) it is the main support computer USB charging don't change or connerct
- itto the outside Itcharging power supply.
- 3) headst can not be placed for a long time, please charge and discharge once a week, so as to extend the electricity The pool of life.
- 6. To record the line connection phone listening to music, please turn off the power supply, lestcause noise.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device.

pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.