



Table of contents



1. Basic information about DEXNET NODE.
2. Equipment.
3. Connect the DEXNET NODE to the network.
4. Registration in the dexnet.one account
5. Activation of the DEXNET NODE.
6. Contact us.

Basic information



CPU: 4-core Rockship RK3566

RAM: 8 GB

ETHERNET: RJ45

SSD: 2 TB

GSM: with e-sim DEX Mobile

Dex Wan: own high-frequency terrestrial channel 915 MHz, 5.5 km

DEXNET-NODE

The node of the global decentralized Dexnet network generates a token for maintaining the network.

DEXNET NODE has a high-frequency terrestrial communication channel at a frequency of 915 Mhz. DEXNET NODES detect each other within a radius of up to 5.5 km. and they form a direct communication channel, overlapping each other with a terrestrial radio signal on the principle of honeycombs.

It also has a direct connection of DEXNET NODE devices to the low-orbit Swarm satellite network from Space X. Connection to the nearest Swarm satellite is via a compact antenna.

DEXNET NODE devices connecting to the base stations of existing mobile operators around the world form a closed VPN (Virtual Private Network) in the global GSM network.

Each node connects to a home Internet cable instead of (or in parallel) the usual Wi-Fi router to exchange encrypted data packets over a wide global Internet communication channel.

Equipment



DEXNET NODE



LoRaWan Antenna



Extension cable for
LoRaWAN antenna



GSM antenna (2 pieces)



LAN Cable



Power unit



Power cable
via USB

Connection instructions Dexnet Node



GSM antennas are installed in the side connectors, in any order

Install the LoRaWAN flat antenna in the middle connector


DEXNET NODE is a decentralized cloud server

Connect the power supply to the power grid

Connect the network cable to any available LAN port of your WI-FI router


Connect the DEXNET NODE to your WI-FI router network cable

Connect the power connector to the DEXNET NODE



1

Go to the DEXNET.ONE website and click "Sign in"






The screenshot shows the DEXNET Technologies logo in the top left corner. The main heading reads "GLOBAL DEX CLOUD" in large, bold, white letters. Below the heading, the text states: "The decentralized, autonomus and secure web 4.0 cloud is here". In the top right corner of the page, there is a "Sign In" button with an external link icon and a language selector set to "EN". The background of the page features a satellite in orbit over a planet's horizon against a starry space background. A "DEXNET SUPPORT" logo is visible in the bottom right corner of the page.




2

On the next page
click "Sign Up"






[Sign Up](#)  EN

Sign in to the system

Email

Password [Forgot password](#)

SIGN IN



3


In the window that appears, fill in **your details** and **the delivery address** of the device

4

Enter the promo code and click **Activate**

5

After activation, you will receive login details by email



Specify the information to ship the device.

Michael

Finey

m.finey@hotmail.com

Country code Phone number ×
+1 (202) 455-4433

6073 S Moonlight Beach, Las Vegas, NV 89113, |

89113


Promocode activated -100%

Activate promocode

* Apply a Promo Code for a 100% discount received in personal account of the marketing company

After entering the account, enter the license key and click **activate device**

* The license key is located on the underside of the DEXNET NODE



DEXNET TECHNOLOGIES

Dexnode Base v1.0

After receiving the device, activate it by entering the serial number in this field

A8R3-...-MJKX ✓

ACTIVATE DEVICE

+ ORDER ANOTHER DEVICE

Order number: 0001595

Order status: Not paid

Shipping address: 6073 S Moonlight Beach, Las Vegas, NV 89113, USA

Shipping date: —


DXT 0 Log Out EN

ACTIVATE DEVICE

ACTIVATE DEVICE

DEXNET SUPPORT

After activation, your device will begin initialization on the DEXNET network, the process may take up to 4 hours



DEXNET TECHNOLOGIES

Dexnode Base v1.0

Dex Node is in the process of being configured. This may take several hours.

Online time
37 seconds

Total profit
0.00 DXT

Download speed
0 MB/s

Upload speed
0 MB/s

Storage
-

DEX rate
-

RAM
-


DEX rate
-

Log Out EN

+ ORDER ANOTHER DEVICE

DEXNET SUPPORT

The **Node online** status indicates the successful initialization of the Node on the DEXNET network.



The screenshot displays the DEXNET dashboard for a user with the account ID **DXT 240**. The dashboard is divided into several sections:

- Header:** DEXNET TECHNOLOGIES logo on the left, and **DXT 240**, [Log Out](#), and [EN](#) on the right.
- Node Information:** A hexagonal icon representing the node, the text **Dexnode Base v1.0**, and a status indicator **Node online** with a green circle icon.
- Performance Metrics:**

Metric	Value
Order ID	0000225
Online time	9 days
CPU Load	1.50%
Total profit	240 DXT
Storage	0.00%
RAM	5.70%
DEX rate	—
Download speed	585.68 MB/s
Upload speed	570.13 MB/s
- Footer:** A button labeled **+ ORDER ANOTHER DEVICE** and a world map visualization with glowing nodes and connecting lines. A chat icon is visible in the bottom right corner.



THANK YOU FOR YOUR PURCHASE!

We appreciate your attention to our
company and are ready to be in touch.

Email for partnership issues:
info@dexnet.one

Support Service email:
support@dexnet.one

Office address:
Conrad Business Tower, Office 1008,
Sheikh Zayed Road - Dubai, UAE.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Considerations

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.