


User Manual

LED STRIP LIGHT



How to Use It? Please Scan the QR Code

- Download Hi lighting app from the App Store / Google Store




Hi Lighting



APP instructions

Steps to connect your phone to your device:

1. Android needs to enable the positioning permission to use Bluetooth, which is a mandatory requirement of the Android system;
2. Click the "+" button in the upper right corner to find the device and connect it. If the system Bluetooth cannot find the light strip, try the following methods:
3. After disconnecting the power supply of the light strip, power it on again, turn off the Bluetooth first, then turn it on again, and enter the app to search for the device again;
4. Restart the app, clear the app from the background of the phone, and then restart the app



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.