

Product Frequency: 433mHZ-RF

RX Supply voltage: DC 8V to 15V

TX Supply voltage: DC 3V

Standby current: 7mA

Operating Current: 130mA

Product Load: 40A 350W peak

Input power supply voltage = output power supply voltage

Remote control distance: about 20 metres Can be used through the wall

Metal remote control size: 62mm*30mm*12mm

Controller size 82mm*50mm*31mm

Product performance: wireless radio frequency remote control signal, the receiver by comparing the received remote control signal, the implementation of the relay switch function, the

Translated with www.DeepL.com/Translator (free version)

Remote control configuration mode:

Next to the controller working indicator, there is a setup button, press once, the indicator light is always on, then press the remote control to open the button, the indicator light blinks and then always on, then press the remote control to close the button, the indicator light blinks and then goes out, the remote control configuration is complete.

Controller control mode adjustment:

Press and hold the setting button of the controller, the indicator light flashes 1 time, release the button, the mode is interlock mode.

Interlock mode working mode: press the remote control open button, the controller is opened and keep open state, press the remote control close button, the controller closes the output.

Press and hold the setup button of the controller, the indicator will flash continuously for 2 times, release the button, and the mode will be pointing mode.

The mode of operation of pointing mode: press and hold the remote control open button, the controller is turned on, release the remote control button, the controller is turned off.

Press and hold the setting button of the controller, the indicator light will flash 3 times continuously, release the button, the mode is self-locking mode.

Self-locking mode: press the remote control on button once, the controller is turned on and stays on, press the remote control on button again, the controller is turned off, the way is self-locking mode.

Press and hold the setting button of the controller, the indication light flashes 7 times continuously, release the button, return to the factory setting, it will clear the internal storage of the remote control information.

Translated with www.DeepL.com/Translator (free version)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.