


OWS
真无线蓝牙耳机



使用说明书
使用前请阅读使用说明书


产品使用简介

- 除说明书有特殊标示的操作方式以外, 请勿尝试拆卸或更改产品的任何零件。
- 请勿将产品放入水或其他任何液体中, 此产品并非防水设计。
- 安装任何液体不小心进入产品内部, 请立即断开连接并移开此产品。
- 为避免触电, 请在安装或拆卸产品时, 确保手上无潮湿沾水。
- 请勿将本产品放置于有强电磁辐射的环境中, 否则会导致产品故障。

包装清单

	耳机X2		充电仓X1
	使用说明书X1		充电线X1
	耳机X1		

产品示意图说明



- 一加能舱盖区
- 一指开灯
- 一指充电
- 一指开灯
- 一指充电

产品规格

蓝牙版本: V5.4
传输距离: 10m
电池容量: 30mAh
充电时间: 约55分钟
充电时长: 约1.5小时
额定输入: 5V\leq200mA

充电仓规格

电池容量: 250mAh
充电时间: 约55分钟
额定输入: 5V\leq200mA
输入功率: 约1.5W
所有充电信息以实际为准

充电仓充电


请Type-C充电线连接充电仓与电源适配器。
(请确保Type-C充电线连接好线材, 请勿接触充电仓触点。)

LED指示灯说明

充电仓指示灯	• 给耳机充电未充满: 绿灯常亮 • 给耳机充满电: 灯灭 • 给充电仓充电: 白灯闪烁 • 给充电仓充满: 白灯常亮 • 充电仓耗电: 绿灯闪烁
耳机指示灯	• 开机: 白绿灯交替闪烁 • 关机: 白灯闪烁三次 • 蓝牙配对状态: 白绿灯交替闪烁 • 耳机配对成功: 灯灭

产品操作说明

- 开机**
方式一: 将耳机从充电仓中取出, 耳机自动开机。
方式二: 当耳机处于关机状态, 长按耳机触摸功能区3秒, 耳机开机。
- 关机**
方式一: 将耳机放回充电仓, 耳机关机。
方式二: 长按耳机触摸功能区3秒, 耳机关机。
- 配对**
步骤一: 将耳机从充电仓中取出, 耳机自动开机, 并开启耳机自动配对。
步骤二: 打开智能设备的蓝牙列表, 搜索“OWS-31”并连接(支持蓝牙耳机使用)。



触控按键的操作

▶▶▶ 左手耳机操作

- 上一曲: 双击在耳机(L)功能键
- 下一曲: 双击在耳机(R)功能键
- 音量+: 三击在耳机(L)功能键
- 音量-: 三击在耳机(R)功能键
- 暂停/播放: 单击任意耳机功能键

电话免提

▶▶▶ 左右耳机操作(来电状态下)


- 接听: 单击任意耳机功能键
- 拒接: 长按任意耳机功能键2秒
- 静音: 单击任意耳机功能键

激活语音助手(智能设备支持语音助手)

▶▶▶ 左/右耳机操作

- 激活: 长按任意耳机功能键1.5秒(通话状态下除外)

OWS



Manual
Please read all instructions carefully and retain for future use.


Usage Instruction

- Do not attempt to disassemble the unit and charge any part, except there is operation method mentioned in the manual.
- Do not expose the unit to liquid, moisture or humidity, since it is not a waterproof product.
- Disconnect the unit with your BT device and move it to the safe area if the liquid get inside the unit.
- Do not assemble or disassemble the unit to avoid electric shock, if there is water on your hands.
- Do not expose the unit to extremely high temperature or dispose of the unit in fire as it will result in an explosion.
- Do not place the unit in an electromagnetic interference environment to avoid malfunction.

Packing list

	Earphones X 2		Charging case X 1
	Manual X 1		Type-C X 1
	Single X 1		

Product schematic description



- 一指开灯
- 一指充电
- 一指开灯
- 一指充电

Product specification

BT Version: 5.4
Transmission distance: 10m
Battery capacity: 30mAh
Playing time: About 5 hours
Charging time: About 1.5 hours
Rated input: 5V\leq200mA

Charging case specification

Battery capacity: 250mAh
Charging time: About 2 hours
Rated input: 5V\leq200mA
Playing time: About 5.5 hours
(All technical information is subject to actual performance)

Charge the charging case.
Connect the Type-C cable to the 5V power adaptor, and another end to the charging port of the charging case.
(If the green light of the charging case blinks, please charge the charging case in time.)

LED Indicator Status


- Charge the charging bay: Green light on.
- Charging bay is fully charged: Indicator is off.
- Charging the earphones is not fully charged: White light flashing.
- Fully charge the earphones: White light on.
- Low charge: Green flashing.

Charge case Indicator

- Power on: Blinking white and green.
- Power off: White light flashes 3 times.
- BT pairing status: White and green lights flash alternately.
- Earphones are successfully paired: Indicator is off.

Product operating instructions

- Power on**
Method 1: Remove the earphones from the charging bin, and the earphones will automatically power on.
Method 2: When the earphones is off, press and hold the earphones to touch the functional area for 3 seconds power on.
- Power off**
Method 1: Put the earphones back into the charging bin and turn off the earphones.
Method 2: Press and hold the earphones to touch the functional area for 5 seconds, and the earphones shuts down.
- Pairing**
Step 1: Remove the earphones from the charging compartment, the earphones will automatically turn on, and the earphones will be turned on automatic team formation.
Step 2: Open the BT list of smart devices, search for “OWS-31” and connect. (Supports single phone use.)



▶▶▶ 触控按键的操作

▶▶▶ 左手耳机操作

- Previous song: double-click the (L) function button on the left earphone.
- Next song: double-click right the (R) function button on the left earphone.
- Volume+: Triple strike the MF button of right earphone.
- Volume-: Triple strike the MF button of left earphone.
- Pause/Play: Click the MF button of one earphones.

Hands free function

▶▶▶ Left/Right earphone operating (incoming call)

- Answer incoming call: Click the MF button of any earphones.
- Access denial: Press and hold the MF button of any earphones for 2 seconds.
- Hang up: Click the MF button of any earphones.

Active the voice assistant function (the smart devices support voice assistant function)

▶▶▶ Left/Right earphone operating

- Activation: Press and hold the MF button of any earphones for 1.5 seconds(except in call state)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.