






TWS Bluetooth headset

Packing list

	Headphones *2		Type-C Charging cable *1
	Charging case *1		Instructions and Warranty card *1

Product diagram



Tips

1. Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the earbuds.
2. Don't put the earbuds in the water or any other liquid. The earbuds are not waterproof.
3. If any liquid enters the product by accident, please disconnect and remove the connection immediately.
4. Please make sure that there is no water on your hands when installing


5. Do not put the product near by the heat source or expose it to the fire source directly.
6. Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product specification

BT version: V5.4
 Transmission distance: ≥10m
 Speaker unit: Φ14.2mm 16Ω
 sensitivity: 118+3dB @1kHz
 Frequency response range: 20-20kHz
 rated power: 10mW
 Music playing time: ≈ 4.5 hours
 Charging time (headphones): 1.5 hours
 Charging time (charging case): 1.5 hours
 Battery capacity (charging case): 300mAh
 Battery capacity (headset): 40mAh
 Number of charges available for headphones: ≈ 3 times

Product operation instructions

- ① Power on:
 Method 1: Remove the headphones from the charging compartment and the headphones will automatically turn on. Method 2: Press and hold the left/right multifunction button for 3 seconds. The blue light is on for 1 second, and the headphones are turned on. (Voice prompt tone: "power on")
- ② Shutdown:
 Method 1: Replace the charging box, and the headphones will automatically turn off. Method 2: The headphones are not connected within 3 minutes. The device automatically shuts down. (Voice prompt tone: "power off")
- ③ Bluetooth pairing:
 1. Remove the headphones from the charging compartment, and the left and right headphones will automatically enter Bluetooth pairing mode, waiting for connection. (Voice prompt tone: "pairing")
 2. Open Bluetooth on your phone, search for the device name " TWS ", and click to enter the connection. (Voice prompt tone: "connected")



Enter device pairing status:
 The left ear host alternates between blue and white, and the auxiliary ear goes out



Wearing method

1. Hold the ear with one hand and hang the earphones over your ears.
2. Rotate and adjust the horn position of the earphone, moving it up and down until the earphone completely fits the outline of the ear.
3. Pay attention to distinguish the wearing position of L/R, if it is reversed, it cannot be worn up.



LED indicator status

Power on	The ice blue light will be on for 1 second, and the ice blue light will alternately flash after turning on
Power Off	White light flashes three times to shut down
TWS pairing status	The ice blue light alternates with the white light
The device pairing status is displayed	The ice blue and white lights of the left ear main engine flash alternately, and the right earphone is off
Earphone low battery warning	White light flashing slowly (flashing every 5 seconds)
Earphone charging	White light always on
Headphones fully charged	White light goes out
Restore factory settings	White light flashes 3 times quickly

Touch operation

General mode



- Voice Assistant: Press and hold the left function key for 2 seconds to start/stop
- Volume Increase: Click the right function key
- Volume Down: Click the left function button

Music playback mode



- Play/Pause: Double click any headset touch button
- Previous: Three hits left ear function key
- Next: Three clicks right ear function key

Call mode



- Answer/hang up a call: Double click any headset touch button
- Reject incoming calls: Hold down any earphone touch button for 2 seconds

Game/ Music mode switch



- Music mode: Press and hold the touch button on your right ear for 2 seconds. (Prompt tone: "music mode")
- Game mode: Long press the right ear touch button for 2 seconds. (Prompt tone: "game mode")

Restore factory settings

- If the headset is not connected to the device after being powered on, click any headset function key five times to restore the factory Settings and shut down the headset.
- When the headset is connected to the device, click any headset function key five times, and hold down any headset function key for 10 seconds within 3 seconds. After restoring factory Settings, power off the device.

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11564.

○Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.

XIndicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.

The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components:
Including printed circuit boards and their parts, electronic components, etc. and depending on the product model, the earbuds you purchased may not contain all the above components.



Electronic and electrical products sold in the People's Republic of China must mark this LOGO, the number in the logo represents the product under normal use Environmental protection use period.

Warranty statement

Disclaimer

This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:

The product attached to this document is guaranteed as follows: if the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired. Free repair/free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale the ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 15 (15) months. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:

- Exceeding the validity period of the three packs;
- Altering the warranty card and product code does not match the product body;
- Causes caused by misuse, abuse or improper transportation, use, maintenance or storage obstacles or damage;
- Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.) or accident bad;
- The zipper and tower buckle are damaged due to excessive force;
- Disconnection or tearing caused by excessive load;
- Any damage caused by sharp objects;
- Products with signs of burning or flooding;
- Damage caused by unauthorized disassembly;
- Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product.
- If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info

User name		Email	
Contact number		Postal code	
Mailing address			

Product information

Product name		Product number	
Product barcode / Serial number / Batch number			

Vendor information

Name			
Address			
Contact number		Postal code	
Sales date		Invoice number	
Remark			

Certificate of Approval

Product No: _____

Production Time: _____

QC: _____



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.