


die - cut 
 k线 


80mm



Smart Camera Quick Guide

This manual is for reference only, and the specific functions are subject to actual conditions

80mm




Packing List

After opening the package, please confirm whether the main body of the camera is in good condition and whether the accessories are complete.


- Camera
- Power Cable x1
- Power Adapter x1
- Screw Kit x1
- Wall Mount x1
- Smart Camera Quick Guide x1

Appearance Introduction



light Sensor
MIC Lens
Micro SD Card Slot
Reset Button
LED Indicator
Call Key
Vents
Speaker
Power Input

Power Connection




Use the power cable to connect the power interface on the back of the camera to the power socket. When the indicator light of the camera is on or the device broadcasts a voice prompt, it means that the power is turned on. Do not expose this device to rain or use it near water or in a humid environment.

Indicator Light

- The device starts up, and the indicator light flashes when it is not connected to the network;
- The device is successfully connected to the internet - the indicator light is always on;
- The indicator light can be turned on/off through the APP

Quick Configuration



STEP1 Download APP

1. Scan the QR code below, download and install the APP.
2. Go to the APP Store and major application markets to search for "Closeli", download and install the APP.

STEP 2 Register And log In To The APP


1. Please register an APP account and log in.
2. If you have already registered, please log in directly

STEP 3 Add Device

Open "Closeli" APP, add devices, follow the mobile phone guide, or refer to the "add device" process to bind the device.


***Due to APP upgrades and updates, the actual operation may be slightly different from the above description, please follow the instructions in the APP to operate.**

Add Device



3.1 Wi-Fi Distribution network

- After the camera is powered on, you can hear the voice broadcast of the device, and connect your mobile phone to Wi-Fi
- Enter the APP home page, click "+", and select "Add Device" (Refer to Figure 1)
- 2. scan the QR code on the device body (Refer to Figure 2)
- 3. Select "Wi-Fi distribution network" (Refer to Figure 3)




- On the "Please power on the camera" interface, check "The above operations have been completed", and click "Next".
- On the "Wait for the beep from the camera" interface, check "The above operations have been completed", and click "Next".
- Make sure there is no obstruction between the router, the camera and the mobile phone, and the distance between them is within 2 meters, and then click "Next".
- After entering the Wi-Fi password, click "Next"

虚线刀只需印刷，不用打牙线

Hotspot Distribution Network

8. Point the mobile phone screen directly in front of the camera lens, with an interval of 15cm-20cm. Try not to let the mobile phone shake during the process. After hearing the device prompt tone or indicator light changing click "Hearing the prompt tone or indicator light flashing", and wait for the addition to succeed.



Home Security Cloud Storage Introduction


1. What is cloud storage?
Home security cloud storage is the function of storing the video recorded by the security equipment in the cloud, which can be viewed online at any time through "Closeli" APP, and the video can be stored in the cloud.

2. What are the advantages of home security cloud storage?
More timely storage, instant upload, anti-theft, anti-theft and anti-damage. The content is more secure, bank financial level security encryption. The protection is more intimate, 24 hours of recording and storage, completely restoring the truth of the matter, and not missing any highlights.

3. How to Subscribe home security cloud storage service?
Depending on your purchase channel, you can Subscribe home security cloud storage services via "Closeli" APP.

Installation Instructions (for indoor use only)

Cement wall: use the upper wall mounting piece to drill the wall, push in the expansion screw, and then push in the screw to fix the upper wall mounting piece; Wooden wall: Align the hole of the upper wall mounting piece, and push the screw directly to fix it. Align the camera base with the buckle of the upper wall mounting piece, and rotate the direction to fix the camera.



FAQ

Q: How to store video?
A: The camera supports two storage methods, local storage and cloud storage (Subscribe).
Local Storage: store the video recorded by the camera to the Micro SD card.
Cloud Storage: The video recorded by the camera is stored in the cloud. According to the storage time of the video, three types of recent 3 days, 7 days, and 30 days can be stored cyclically, and online viewing and downloading of historical videos are supported.

Q: Why can't the camera connect to the Wi-Fi network?
A: Currently, the camera supports 2.4G Wi-Fi with 802.11 b/g/n protocol, but does not support 5G Wi-Fi. Please make sure that the Wi-Fi signal of the wireless router connected to the camera is within the coverage.

Q: The camera is abnormally offline, how to check?
A: Check whether the power supply and network are normal; Re-plug the power supply to restart the device; Reconfigure the camera.


List of Restricted Substances or Elements Identification

Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr)	Polybrominated Biphenyls (PBBs)	Polybrominated Diphenyl Ethers (PBDEs)
Sheet Metal Parts	X	0	0	0	0	0
Plastic Parts	0	0	0	0	0	0
Circuit Board	X	0	0	0	0	0
Lens	X	0	0	0	0	0
Power Supply	X	0	0	0	0	0
Appendix	X	0	0	0	0	0

Illustrate:
1. 0 indicates that the content of restricted substances in all homogeneous materials of this part is below the limit requirement stipulated in the SJ/T 11363-2006 standard;
2. x indicates that the content of the restricted substance in at least one homogeneous material of the part exceeds the limit requirement stipulated in the SJ/T 11363-2006 standard.

After-sales Service Card

Product Model:
Serial Number:
User Name/Contact:
Address:
Telephone:
Fax:
Post Code:
Maintenance:
Records:



Date	Symptoms	Maintenance

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device under Part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference

in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures

:

(1) Reorient or relocate the receiving antenna.

(2) Increase the separation between the equipment and receiver.

(3) Connect the equipment to an outlet on a circuit different from the receivers.

(4) Consult the dealer or an experienced radio/TV technician for help.

Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.