



Quick Start Guide

Pay Pro

Product Details




1. **Power key:** long press to power on/off; short press to activate or shut down the screen
2. **Screen:** display and touch operation
3. **USB-C 1&2:** to connect with T2 stand and to connect with HUB, can be mixed use

Main Specifications

Model	D052
Operation System	Android 13
CPU	Octa-Core 2.0GHz
Communications	WiFi/Internet
Memory	4GB RAM, 64GB ROM
Screen	13.3"LCD, Touch Panel
BT	BT5.0, Dual Mode
Wi-Fi	WLAN802.11a/b/g/n/ac
Ports	2*USB-C
Stand	The screen rotates parallel to the desktop and turned outward 100°, 50,000 time life cycle

Instructions for use



Step 1: USB HUB connect to the USB-C of D052 through usb cable

Step 2: Power adapter connect to the USB HUB through power cable

Step 3: T2 stand connect to the USB-C of D052 through usb cable

Step 4: T2 put on the T2 stand

Step 5: Power on the D052 and T2 through the power key

Step 6: D052 connect to the internet through WiFi or Ethernet

Step 7: T3 connect to the internet through WiFi

Step 8: Runing ordering apps on D052 and intiate the transaction and send the amount to T2

Step 9: T2 deals with the transaction and feed back to D052

Notes: D052 is a desktop ECR device, installed on the counter with a height of less than 1m.

Safety Alert

- Do not place the terminal in extremely hot or cold conditions.
- Do not place terminal together with computer disc, credit card, travel card or any other magnetic items; otherwise, the information stored in magnetic cards will be affected.
- Do not place the terminal in fire.
- Do not disassemble the terminal or any accessories by yourself.
- Please use a moist and anti-static cloth to clean the terminal screen.
- Warning: Please replace the batteries with the same type and rating to avoid battery explosion.
- Do not expose the battery in strong direct sunlight, near heat sources or any similar conditions.
- Please recycle or dispose of old, weak, or worn batteries in accordance with local, regional, or national law or regulation.
- Do not use detergent with chemical or scrub particle which may damage the terminal body or screen.
- Please keep the terminal in a safe place and avoid crush or squeeze that may cause a damage on screen or camera.
- When the user use the third party's root tool or update with unauthorized operation system, it will bring risk to the normal operation system.
- The maximum operating temperature of the product should not exceed 40°C.
- Product battery should not be placed in an overheated environment (over 60°C).
- To prevent potential electrical damage, please be recommended to use the power adapter and the USB cable provided with the packing only.

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator& your

body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Le rayonnement de la classe b repecte ISED fixaient un environnement non contrôlé. Installation et mise en

œuvre de ce matériel devrait avec échangeur distance minimale entre 20 cm ton corps. Lanceurs ou ne peuvent pas coexister cette antenne ou capteurs avec d'autres.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement.

Le matériel est conforme aux limites de dose d'exposition aux rayonnements énoncées pour faciliter un autre environnement. Ce dispositif a été évalué à satisfaire l'exigence générale de l'exposition aux rf.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

the emissions are maintained within the band of operation under all conditions of normal operation