

Important Safety Instructions

Read and follow all instructions and warnings in this user manual

Important Safety Instructions

- 1. Read these instructions.
- 2. Keep these instructions.
- 3. Heed all warnings.
- 4. Follow all instructions.
- 5. Do not place near any heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
- 6. Clean only with a dry cloth.
- 7. Refer all servicing to qualified personnel. Servicing is required when the product has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the product, the product has been exposed to rain or moisture, does not operate normally, or has been dropped.

Warnings/Cautions

- Keep the product away from fire and heat sources. Do NOT place naked flame sources, such as lighted candles, on or near the product.
- Do NOT make unauthorized alterations to this product.
- Do NOT use a power inverter with this product.
- The battery provided with this product may present a risk of fire or chemical burn if mishandled.
- Do not expose products containing batteries to excessive heat (e.g. from storage in direct sunlight, fire or the light)
- Do NOT use any charger other than that specifically provided for use with the product.

Regulatory and Legal Information

Management Regulation for Low-power Radio-frequency Devices

Article XII

According to "Management Regulation for Low-power Radio-frequency Devices" without permission granted by the NCC, any company, enterprise, or user is not allowed to change frequency, enhance transmitting power or alter original characteristic as well as performance to an approved low power radio-frequency devices.

Article XIV

The low power radio-frequency devices shall not influence aircraft security and interfere legal communications; If found, the user shall cease operating immediately until no interference is achieved. The said legal communications means radio communications operated in compliance with the Telecommunications Act.

The low power radio-frequency devices must be susceptible with the interference from legal communications or ISM radio wave radiated devices.

DON'T attempt to remove the rechargeable lithium-ion battery from this product. Contact your local Bose retailer or other qualified professional for recycling and disposal.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.



Please dispose of used batteries properly, following local regulations. Do not incinerate.





Nimba is trademark of Nimba Wellness Technology Limited.

©2023 Nimba Wellness Technology Limited. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.

App Control and Setup

Nimba App

The Nimba app lets you set up and control Nimba OFLO from your mobile device. Using the app, you can select and download sounds and music, set wake-up alarms, and manage OFLO settings.

Bluetooth

Bluetooth Low Energy wireless technology lets you control OFLO using the Nimba app on your mobile device. Before you can control OFLO, you must download the app and connect your device with OFLO.

Connect your Mobile Device

1. Download the Nimba app









2. Follow the steps shown in the App



Note

Nimba OFLO must be within range (6ft or 2m) and powered on.

Disconnect a Mobile Device


Use the Nimba app to disconnect a device.

You can also disable the Bluetooth feature on your device to disconnect. Disabling the Bluetooth feature on your device disconnects all other devices.


Battery

Charging

Use the included USB Type-A® to Type-C® power cable and power adapter to charge the device.



While charging, the battery indicator will blink and show its current battery level. When the battery is fully charged, the battery indicator glows solid white.




With typical usage, the battery lasts up to 8 hours. Battery performance varies with the volume at which it's played, and lighting at which it's set.


Battery will fully charge in approximately 3.5 hours when using the included power adapter and cable.

CAUTION: Do NOT store your speaker for extended periods when fully charged or with a remaining charge of less than 10 percent.

Button Overview



Functions



Troubleshooting

TRY THESE SOLUTIONS FIRST

If you experience problems with OFLO, or connecting to the Nimba app, try these solutions first:

- Charge OFLO (see page 6)
- Move your mobile device closer to OFLO (within 6 ft or 2 m) and away from any interference or obstructions.
- Make sure that your device supports Bluetooth Low Energy (also called Bluetooth Smart). All devices that are compatible with iOS 10 and newer and most devices that are compatible with Android 5.0 and newer support Bluetooth Low Energy.
- Check the Nimba app to make sure that the software for OFLO is up to date.
- Make sure that you are using the Nimba app, not a different app, to control OFLO (see page 5).

Other solutions

Symptoms

If you could not resolve your issue, see the table below to identify symptoms and solutions to common problems. If you are unable to resolve your issue, contact Nimba customer service.

Solution

Symptoms	Solution
Sound machine does not turn on	 Battery may be discharged, connect your sound machine to a wall charger Press and hold the power button over 10 seconds
Sound machine does not charge	 Make sure the provided power adapter and cable is used Make sure the connector on the cable is correctly aligned with the connector on the sound machine Try another charging source
Sound machine does not connect with app	 Restart the sound machine and try again Ensure that the Bluetooth feature is enabled Turn off and on the Bluetooth in your mobile device
No sound	 Press the Play/Pause/Next button to play sound Press the + button to increase the volume
No light	 Make sure the Blackout mode is off Press the light control button Increase the intensity using Nimba app

Troubleshooting

Symptoms	Solution
Sound machine not responding to multi-button-presses	For multi-press functions using the Multi-function button, vary the speed of presses.
Sound machine not responding	Press and hold the power button over 10 seconds

Factory Data Reset

Reset your OFLO to its factory default settings, this will erase all setting. Only downloaded music and sounds will be kept.

Specifications

Model	OFLO
Rated input voltage adapter	100-240Vac
Rated input frequency adapter	50/60Hz
No-load power adapter	< 0.1W
Rated output voltage adapter	5Vdc
Average Standby Power appliance Condition: (All functions suspended, ambient light scenario; day 12h, 500 lux and night 12h, 0 lux) clock display at maximum brightness setting	< 0.5W
USB charging port	5V, 1000mA
Nominal light output (level 1 - 10)	1- 35 lux
Nominal light color (level 1 - 10)	1500-5000K
Physical Characteristics	
Dimensions (Height x Width x Depth)	18.8 x 8.1 x 7 cm (7.4 x 3.2 x 2.8 in.)
Weight main unit / adapter	Approx. 0.4kg (14.1oz) / 0.14kg (4.9oz)
Cord length adapter	120cm (4 feet)
Average battery life	Up to 8 hours
Average charging time	Approx. 3.5 hours
BLE version	5.2
Inputs	USB Type-C®
Classification	
Main unit	Portable Electric Sound Machine
Adapter	Class 2 power supply
Mode of operation	Continuous
Operating conditions	
Temperature	+5°C to +35°C (41°F to 95°F)
Relative humidity	15% to 90% (no condensation)
Storage conditions	
Temperature	-20°C to +50°C (-4°F to +122°F)
Relative humidity	15% to 90% (no condensation)

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.