

# KM02说明书

尺寸: 195 x158mm

材质: 250G双铜纸四色印刷





	Mode of operation	Function description	
0	Short press	Switching: Bluetooth /TF card /AUX	
	Tap and hold	Acoustic on/off	
-	Short press	Volume plus	
	Tap and hold	Next song	
+	Short press	Volume down	
	Tap and hold	Previous song	
*	Tap and hold	Mode switching	
	Short press	Color changes within the mode	
	Tap and hold	Jurn on/off the lights	
	Short pre ss	Play/pause	
	Tap and hold	Switch on and off	
Indicator light (White/Red)	1, < indicator 2>— Bluetooth light; The unconnected white light is on, the blue light is on, and the connected white light is on and the connected white light is on 2, < indicator 1>— power light; When the battery is low, the red light blinks slowly. The red light keeps on while charging		
Reset	Reset attribute		
Type-C	Type-c interface charging		
TF Card	TF card audio source reading		
AUX	3.5mm AUX cable connection		

# Microphone control instructions

	① On/off	Short press	Play/pause (audio music)
		Tap and hold	On/off
0	② Volume +	Short press	Volume +
	③ Volume -	Short press	Volume -
0	(4) Mark function key	Short press	Toggle: Original/Magic voice (Minions, dolls)
9 3		Tap and hold	On/off silence
0		double-click	Turn the MIC lights on/off
	Mark fun ction key		Type-C charging
			,

Light color: Red/orange/yellow/green/light blue/dark blue/purple. When turning on (default), RGB pulse, when turning off the light.

Lighting pattern(5 large modes)

Color mode, low speed, medium speed, fast; Run with musical energy when playing music

Monochrome mode, red/orange/yellow/green/light blue/dark blue/purple /7

Breathing pattern, 7 color cycle changes Horse mode, mode 1: Run counterclockwise, 7 color switch; Mode 2: Clockwise mode, 7 color switch

Music beat mode, 1> main color red beat flash; 2> Main color blue light beat

flash: 3>7 color beat flash

# Bluetooth connection instructions

used. At this time, please turn on the Bluetooth function of the Bluetooth device and search for the Bluetooth name "KMO2", When the connection is successful, the pro mpttone "Bluetooth is connected" is displayed

ects back to the last connected device, and the "Bluetooth Connected"tone is displayed If the connection fails, it automatically enters the Bluetooth to be connected state. If the connected Bluetooth device and speaker are disconnected, return within 10 minutes The Bluetooth effective range to the speaker can be automatically connected back.

# **FCC Statement**

void the user's authority to operate the equipment

pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful Interference to radio or television reception, which can be determined by turning the equipment following measures:

Reorient or relocate the receiving antenna

- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from
- that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device compiles with part 15 of the FCC rules. Operation is subject to the following two

(2)This device must accept any interference received, including interference that may cause

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.