





Freq. Stability NVNT ac20 5700MHz Ant1




Freq. Stability NVNT ac40 5510MHz Ant1






Freq. Stability NVNT ac40 5550MHz Ant1




Freq. Stability NVNT ac40 5670MHz Ant1






Freq. Stability NVNT ac80 5530MHz Ant1



Freq. Stability NVNT ac80 5610MHz Ant1





F.6 Duty Cycle


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5500	Ant0	94.56	0.24	0.91
NVNT	a	5580	Ant0	94.65	0.24	0.91
NVNT	a	5700	Ant0	94.65	0.24	0.91
NVNT	n20	5500	Ant0	93.67	0.28	1.07
NVNT	n20	5580	Ant0	93.77	0.28	1.07
NVNT	n20	5700	Ant0	93.77	0.28	1.07
NVNT	n40	5510	Ant0	93.15	0.31	1.19
NVNT	n40	5550	Ant0	93.15	0.31	1.19
NVNT	n40	5670	Ant0	93.15	0.31	1.19
NVNT	ac20	5500	Ant0	93.72	0.28	1.06
NVNT	ac20	5580	Ant0	93.72	0.28	1.06
NVNT	ac20	5700	Ant0	93.82	0.28	1.06
NVNT	ac40	5510	Ant0	93.18	0.31	1.18
NVNT	ac40	5550	Ant0	93.18	0.31	1.18
NVNT	ac40	5670	Ant0	93.18	0.31	1.18
NVNT	ac80	5530	Ant0	89.65	0.47	1.86
NVNT	ac80	5610	Ant0	89.65	0.47	1.86






Test Graphs

Duty Cycle NVNT a 5500MHz Ant0




Duty Cycle NVNT a 5580MHz Ant0






Duty Cycle NVNT a 5700MHz Ant0




Duty Cycle NVNT n20 5500MHz Ant0






Duty Cycle NVNT n20 5580MHz Ant0




Duty Cycle NVNT n20 5700MHz Ant0






Duty Cycle NVNT n40 5510MHz Ant0




Duty Cycle NVNT n40 5550MHz Ant0






Duty Cycle NVNT n40 5670MHz Ant0




Duty Cycle NVNT ac20 5500MHz Ant0






Duty Cycle NVNT ac20 5580MHz Ant0




Duty Cycle NVNT ac20 5700MHz Ant0






Duty Cycle NVNT ac40 5510MHz Ant0




Duty Cycle NVNT ac40 5550MHz Ant0







Duty Cycle NVNT ac40 5670MHz Ant0



Duty Cycle NVNT ac80 5530MHz Ant0






Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5500	Ant1	94.56	0.24	0.91
NVNT	a	5580	Ant1	94.56	0.24	0.91
NVNT	a	5700	Ant1	94.56	0.24	0.91
NVNT	n20	5500	Ant1	93.67	0.28	1.07
NVNT	n20	5580	Ant1	93.77	0.28	1.07
NVNT	n20	5700	Ant1	93.77	0.28	1.07
NVNT	n40	5510	Ant1	93.15	0.31	1.19
NVNT	n40	5550	Ant1	93.04	0.31	1.19
NVNT	n40	5670	Ant1	93.04	0.31	1.19
NVNT	ac20	5500	Ant1	93.72	0.28	1.06
NVNT	ac20	5580	Ant1	93.72	0.28	1.06
NVNT	ac20	5700	Ant1	93.72	0.28	1.06
NVNT	ac40	5510	Ant1	93.07	0.31	1.18
NVNT	ac40	5550	Ant1	93.07	0.31	1.18
NVNT	ac40	5670	Ant1	93.18	0.31	1.18
NVNT	ac80	5530	Ant1	89.65	0.47	1.86
NVNT	ac80	5610	Ant1	89.65	0.47	1.86






Test Graphs

Duty Cycle NVNT a 5500MHz Ant1




Duty Cycle NVNT a 5580MHz Ant1






Duty Cycle NVNT a 5700MHz Ant1




Duty Cycle NVNT n20 5500MHz Ant1






Duty Cycle NVNT n20 5580MHz Ant1




Duty Cycle NVNT n20 5700MHz Ant1






Duty Cycle NVNT n40 5510MHz Ant1




Duty Cycle NVNT n40 5550MHz Ant1






Duty Cycle NVNT n40 5670MHz Ant1




Duty Cycle NVNT ac20 5500MHz Ant1






Duty Cycle NVNT ac20 5580MHz Ant1




Duty Cycle NVNT ac20 5700MHz Ant1






Duty Cycle NVNT ac40 5510MHz Ant1




Duty Cycle NVNT ac40 5550MHz Ant1





Duty Cycle NVNT ac40 5670MHz Ant1



Duty Cycle NVNT ac80 5530MHz Ant1

