Key operation instructions
Bluetooth mode

Slide left and right on/off the machine
Click the pause button to answer the call,

Double-click the pause button to refuse to hear calls
Press twice to make a phone call
Playing status
Press the middle button briefly (play, pause)
Click-button to previous a song, hold and hold the volume down
Click the + key to play the next song, hold down the volume plus
Press and hold the pause button and + button at the same time for 2 seconds, the main light switch

(2) indicator light

 $(1)\,$  Wireless status: The red and blue lights flash in pairing status, and the blue lights flash slowly after pairing is successful

1:TF mode status:

Blue light flashes slowly during playback

2: Charging status: The red light stays on during charging, and the blue light stays on after charging is completed (3)LINE external audio input Operation instructions:

① When the audio cable is plugged in, go directly to AUX LINE IN mode. At this time, the headset is a normal headset, and the button is invalid. ② Support external audio input from mobile phone/AP4/MP3/CD/notebook (4) Functional parameters:

OUSB charging: DC5VIN 2 SNR:88Db

FM frequency:87.5-108MHz Wireless distance:10 meters Frequency response:50HZ-20KHz

④ Output power:35m circle

④ Wireless frequency:2.401-2.480GHIz ④ Charging time:2 hours @ Call time:6 hours Standby time:15 hours

## FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.