



AirKing Pro Manual

Thank you for choosing our smart products. In order to fully understand the functions of the device, we recommend that you read this manual carefully, the smart headset mainly relies on wireless to connect to your phone, It provides new practical functions and services to improve your experience. The Company reserves the right to update the contents of this manual at any time without prior notice. We would like to remind you that if the earphones are damaged due to non-compliance with the instructions provided, our company will not provide free warranty service.

耳机参数：

- 1. Product name:** AirKing Max ANC
5th+Smart screen
- 2. Version model:** V5.4
- 3. Transmission distance:** $\leq 15\text{M}$
- 4. Support protocol:** A2DP/AVRCP/
HFP/HID/AVCTP/AVDTP
- 5. Carrier frequency:** 2.402-2.480GHz
- 6. Response frequency:** 20-20000Hz
- 7. Speaker size:** $\Phi 13$ titanium film
- 8. Speaker sensitivity:** 115dB \pm 3dB
- 9. Horn impedance:** 32 Ω \pm 15%
- 10. Rated power of speaker:** 3mW
- 11. Charging input standard:**
DC4.75-5.25V/600mA
- 12. Headset use time:** 5.5 hours
- 13. Charging time of charging case:** 1.5 hours
- 14. Charging interface:** Type-C

产品操作介绍：

Function	Operate
Boot	Press and hold the function button of the charging case to power on
Shutdown	Press the function button of the charging case 5 times to power off

Chinese and English	When not connected, double-click any earphone to switch between Chinese and English mode
Play/Pause	Click any earphone while the music is playing
Up/down	Double-click the left earphone/right earphone toggle
Volume up/down	Swipe up/down on the headphones to increase/decrease the volume
Reject an incoming call	Long press any earphone for 3 seconds when a call comes in
Answer/hang up	Click any earphone when a call comes in
Voice Assistant/Siri	Press and hold the left earphone for 3 seconds to wake up
Transparency/noise reduction	Press and hold the right earphone for 3 seconds to switch

Note: The earbuds will automatically turn off after 2 minutes if they are not connected to the mobile phone after leaving the warehouse.

Safety Guidelines:

1. Before using this product for the first time, please fully charge it before using it;
2. This product is not a toy, children under the age of 12 must be used under the supervision of an adult;
3. Please use the SV/1A charger that has passed the safety certification of the regular factory to avoid the fast charging charger that supports high voltage to the product
4. Please charge in a safe environment, when charging the charging case, please pull out the charging cable as soon as possible after the power is fully charged to avoid damage to the battery caused by long-term charging. The charging mode of the charging case is Type-C interface;
5. This product has a built-in non-removable rechargeable battery, and repeated charging and discharging of the earbuds will lead to a decrease in battery performance over time, which is normal for all rechargeable batteries;
6. This product has a lithium battery, if it has not been used for a long time, please charge it at least once a month;
7. Due to individual differences, if you feel skin discomfort when wearing, please stop wearing it and consult a doctor;
9. When using this product wirelessly, please adjust the sound of the earphones to the appropriate maximum to avoid hearing damage caused by long-term loud volume;
9. If you use this product while engaging in activities that require concentration, you should pay attention to your own safety and the safety of others, such as when driving or cycling, on the road, construction site, railway, or walking, you should remove the headphones or adjust the volume to ensure that you can hear the surrounding sounds, including alarm and warning signals;
10. Please abide by the relevant regulations of the region or country, and use this product according to the requirements when driving.
11. This product contains magnetic materials, please keep away from electrical appliances with strong magnetic or electric fields, such as microwave ovens, refrigerators, etc., when using or placing the product;

12. It is recommended to use this product in an environment with a temperature of -0°C~45°C. When the ambient temperature is below +5°C, battery performance is limited;
13. Do not use this product in places where it is expressly prohibited to use wireless equipment, otherwise it will interfere with other electronic equipment or cause other dangers;
14. Before approaching medical and industrial equipment or boarding the plane, please consult the local staff if they can use it;
15. Before cleaning and maintaining this product, please stop using this product, turn off all applications, and disconnect all connections or wires with other equipment;
16. Please report to the local laws and regulations, properly dispose of discarded electronic products, and do not discard electronic and electrical equipment, parts, batteries and other household garbage.

Warning :

1. Please follow the content of this manual to avoid damage to the product due to wrong operation;
2. Please keep this product away from children, fire sources, heat sources, freezing sources, water sources and chemicals;
3. Do not listen at a loud volume for a long time, so as not to cause adverse effects on hearing.
4. Do not invade any liquid or rinse the product with water, otherwise it will lead to fire or electric shock danger;
5. Do not place the product in the sun or in a place with high temperature, as high temperature will shorten the service life of electronic components, damage the battery, and deform some plastics;

6. Do not store this product in a place with a lot of dust, too high or too low temperature and humidity;
7. Do not touch the magnetic stripe card (such as bank card, bus card, etc.) with this product for a long time, as incense may cause the magnetic stripe card to be damaged by the magnetic field;
8. Do not apply greater pressure on this product, or disassemble, beat, or shake this product to prevent damage to the product;
9. Do not use this product near heat sources, such as radiators, hot air regulators, stoves or other heat-generating instruments;
10. Do not block the opening of this product, such as charging port, indicator light, microphone, etc.;
11. Do not use the equipment in rainstorm weather, thunderstorms may cause the equipment to malfunction and increase the risk of electric shock;
12. Please avoid using this product and its accessories when it is rainy or damp, and when you exercise vigorously or sweat a lot, to prevent liquid from penetrating into the product and damaging this product;
13. The product belongs to the built-in polymer battery, which cannot be replaced, please do not discard or put it in the fire to avoid explosion, fire and other dangers;
14. If the personal and property damage caused by the improper use of the consumer violates the above warning, the company will bear all the consequences, and the company will not incur any legal responsibility.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Made in
China**

