


**VERTU**

ENGLAND

Quick Guide





# Mermaid OWS Earphone User's manual

Equipment connection name: VERTU MERMAID  
MERMAID Brand name: Chengdu Weitu Commercial  
Management Co., Ltd


## APP download

Scan the QR code below to download the APP.





## Switchers

Open the charging compartment and turn on the headset by keeping the indicator light on for 2 seconds. Put the headset into the charging compartment and close the lid of the charging compartment, the headset will turn off automatically.



## Connecting the device


When using the headset for the first time, open the headset charging compartment cover, and the headset will automatically turn on and enter pairing mode. Turn on the Bluetooth function of the mobile phone, close to the device, and add a new device in the Bluetooth setting interface of the mobile phone. Find "VERTU MERMAID" in the list of new devices searched, click and complete the operation according to the prompt to complete pairing and connect the device.



## Play music

After the devices are paired and connected, you can enjoy music by turning on the music software of the mobile phone. In the music playing state: Play/Pause: Double-click the touch area of the left earphone or the right earphone to switch between music playing and pause.

- Volume adjustment Click on the right earphone touch area to increase the volume one gear, click on the left Earphone Touch area to reduce the volume one gear.
- Up/down Three clicks on the right ear, three clicks on the left ear.



© The above is the default definition. If customized through APP, the operation will run in the form defined by APP.

## Answer a call

- Answer the phone | Answer the phone by double-clicking on the left earphone or the earphone touch area.
- End call | In the call, double-click the left or right earphone touch area to hang up the call
- Do not answer the phone | In the process of ringing, press the touch control area for 2 seconds to reject the current call
- Voice assistant | Long press the left and right earphone touch control area 2 seconds, hear the prompt sound release can wake up the voice assistant.



Double-click the headset touch area

Answer the phone a little



Double-click the headset touch area during the call.

End the call



Press and hold for 2 seconds to reject the call.


Refuse to call



## Charge

1. Connect the standard TYPE-C USB charging cable and the standard adapter or computer USB port to charge the charging chamber.

2. The charging compartment automatically charges the headset when it is placed in the charging compartment




## Forced pairing:

Put the earphone into the charging compartment, and press the button of the charging compartment for 3 seconds, and the earphone will disconnect the current connection and enter a new pairing mode.

## Restore factory mode:


Put the earphone into the charging bin and press the button of the charging bin for 5~6 seconds, and the earphone will return to the factory default parameters.



## LED status


### Charging compartment:

- Red breathing light --- Charging compartment is charging
- White light is always on --- Charging compartment is fully charged.
- Red light blinks 5 times --- Forced pairing (disconnect the connected device, enter pairing mode)
- Red and white lights blink alternately 5 times---The headset is in the process of restoring factory settings
- The white breathing light is on for 30 seconds---The headset is in the charging compartment, and the headset is charging.  
The white light is always on for 30 seconds---The headset is in the charging compartment and the headset is fully charged.



### Headphones.

- LED stays on for 2 seconds: the headset has been turned on
- LED flashes quickly: right and left ears are paired
- One of the earphones LED blinks slowly: waiting for the device to connect (waiting for pairing)
- the left and right ear LEDs are not lit: connected to the device



## Automatic

When the headset is taken out of the charging compartment and disconnected from the device for more than 5 minutes without reconnecting or pairing with a new device, the headset will turn off automatically. If you need to reboot the headset, please put the headset into the charging compartment, close the lid of the charging compartment, and then reopen the lid, the headset will reboot and wait for connection or pairing.

## Connecting multiple devices

After connecting the headset to one device, turn off the Bluetooth function of the connected device, and then search and connect the headset with another device that needs to connect the headset. After successful connection, turn on the Bluetooth function of the previous device, and click the headset name in the list of connected devices to connect. At this time, the headset is successfully connected to two devices

- Ⓞ Connect two devices at the same time, when device 1 plays music device 2 calls, prioritize device 2 to answer the incoming call.

## Auto-reconnect.

If the phone has not deleted the headset pairing name, the headset will prioritize the last connected device by opening the headset cover.

## Product

Name:Mermaid OWS Earphone

The name of the device connection : VERTU MERMAID

Bluetooth version : V5.3Communication distance : 10 meter

Model: VOWS001

Bluetooth version : 5.2

Equipment requirements : Android6.0andiOS10.0And above

Battery capacity : 70mAh/0.27W/h(Headphones)

400mAh/1.52Wh ( Charging bin )

Headphone rated input : DC-5V-140m

Charging bin rated input DC5V-700mA

Headphones are rated to consume current : 10mA

Charge storage rated consumption : 220mA


Listening time : About 7 hours (turn off ambient adaptation, default sound, 50% volume)

Listen to the song with the charging bin : 25 hours (at full power)

Charging time : About 1 hour

Frequency response range : 20Hz-20KHz charging port: Type-c

Scope of application : Play device with Bluetooth function



## Product Warranty

1. If the product has any functional problems, you can enjoy the warranty service, contact customer service.
2. The warranty does not cover damages caused by human beings, falls, human scratches, water ingress, or the absence of a warranty card.
3. Customers must fill in all necessary information (customer name, address, phone number, date of purchase, etc.).
4. We are responsible for the cost of repairs during the warranty period, but are not responsible for shipping costs or other expenses.



VERTU official customer service: 400-1250-888

Sign: GB4943.1

Service address: <https://www.ivertu.com/download/userguide/ivertu>

Manufacturer: Chengdu Weitu Business Management Co. , Ltd.

Manufacturer address: 101 Block C, deshang international incubator, high-tech zone, Chengdu City, Sichuan Province

## FCC Warning

### 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC RF Radiation Exposure Statement:

- 1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- 2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.

#### IC Warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference;
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The information listed above provides the user with information needed to make him or her aware of a RF exposure, and what to do to assure that this radio operates within the FCC exposure limits of this radio.

The device complies with RF specifications when the device used at 5mm from the body. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.



