


Magnetic Power Bank Manual

Thank you for choosing our Magnetic Power Bank. This versatile device is designed to provide convenient charging for your electronic devices while offering the added benefit of magnetic attachment for easy use. Please read the following instructions carefully to ensure optimal performance and safety.

Package Contents:

Magnetic Power Bank*1
Charging Cable*1 0.3M Type C
User Manual*1



Parameters:

Model:J-W020
Battery: Li-Polymer Battery
Capacity: 10000MAH
Material: PC+ABS
Size: 86*64*27.5mm
Color: Black. White. Blue. Purple
USB1-2 Output: 4.5V5A 5V3A 9V2A 12V1.6A
Type-C Output: 5V3A 9V2.2A 12V1.6A
Type-C Input: 5V3A 9V2A 12V1.5A
Wireless charging: 15W

Note: When any two or more ports (including wireless charge) are output at the same time, the output automatically closes the fast charge mode and enters the 5V output mode.

Charging Instructions:

Before first use, fully charge the power bank using the provided USB charging cable and an appropriate power source.

Connect the USB end of the cable to a power source such as a wall adapter, computer, or USB hub.

Connect the Micro USB or USB-C end of the cable to the input port on the power bank.

The LED indicator lights will illuminate to indicate charging status. When all indicators are solid, the power bank is fully charged and ready for use.

Safety Precautions:

Do not expose the power bank to water or moisture.

Keep the power bank away from heat sources and direct sunlight.

Avoid dropping or subjecting the power bank to impact or physical damage.

Use only the provided charging cable or compatible cables.

Do not attempt to disassemble or modify the power bank.

Troubleshooting:

If the power bank is not charging your device, ensure that both the power bank and device are properly connected and that the power bank has sufficient charge.

If the power bank is not charging or holding a charge, try using a different charging cable or power source.

For further assistance or inquiries, please contact our customer support team at [Insert Contact Information].

Thank you for choosing our Magnetic Power Bank. We hope you enjoy the convenience and reliability it provides for your charging needs.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.