


REMOTE CONTROL TRUCK

1/18 ELEGTRIGROWERED OFF-ROAD






PAIR THE RC CAR AND REMOTE CONTROL



1.Turn ON the RC car switch



2.Turn ON the remote control switch



3.After pairing is completed, you can control the remote control car to drive.

Remote control distance: Approximately 40-50 meters Usage time: Around 25-30 minutes when fully charged

Charging time: Approximately 3 hours


LITHIUM BATTERY CHARGING METHOD



The red light is on when the battery is charged, and off when fully charged.



Can be charged using the computer USB charging port.



Connect as shown in the figure.

OFF-ROAD CAR STYLE DISPLAY

DH666-84A-1



DH666-84B-1



DH666-84C-1







⚠ WARNING

When the remote control can not work, turn off the RC car and controller. Then restart both the car and the remote control. Remember to match frequency before you play.

BATTERY INSTRUCTIONS

- 1. Rechargeable batteries should be removed from toys before charging.
- 2. Do not mix old and new batteries.
- 3. Keep batteries away from kids under 3.
- 4. The light will flash on and off when battery is low.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- •Increase the separation between the equipment and receiver.
- •Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- •Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.