



开放运动耳机

BLUETOOTH

Version 5.4

使用说明书

使用前请仔细阅读本说明书

产品使用简介

- (1) 除说明书有特殊标示的操作方式以外, 请勿尝试拆卸或更换产品内的任何零件。
- (2) 请勿将产品放入水或其他任何液体中, 此产品非防水设计。
- (3) 如果有任何液体不小心进入产品内时, 请立即断开连接并移开此产品。
- (4) 为避免触电, 请在安装或卸载产品时, 确保手上没有沾水。
- (5) 请勿将此产品放置于热源附近或直接暴露在火源附近。
- (6) 请勿将本产品放置在有强大电磁力的环境中, 否则会导致产品故障。断开连接并移开此产品。

包装清单

耳机 × 2	充电仓 × 1
使用说明书 × 1	充电线 × 1

耳机规格

蓝牙版本: V5.4
 传输距离: 10-15米
 电池容量: 30mAh
 使用时长: 约5小时
 充电时长: 约1.5小时
 额定输入: 5V~20mA

充电仓规格

电池容量: 200mAh
 充电时长: 1-1.5小时
 额定输入: 5V~200mA
 使用时长: 15小时

(所有技术信息以实际性能为准)

充电仓充电:
 采用Type-C充电线连接充电仓到5V电源适配器, 本设备不支持快充头。

(温馨提示: 当充电仓指示灯绿灯闪烁时, 请及时给充电仓充电。)

LED指示灯说明

★ 充电仓指示灯

给耳机充电未充满: 蓝灯常亮
 给耳机充满电: 灯灭
 给充电仓充电: 绿灯闪烁
 充电仓充满电: 绿灯常亮
 充电仓低电: 蓝灯闪烁

★ 耳机指示灯

开机: 红蓝灯交替闪烁
 关机: 红灯闪烁三次
 蓝牙配对状态: 红蓝灯交替闪烁
 耳机配对成功: 灯灭

产品操作说明

■■■ 开机

方式一: 将耳机从充电仓中取出, 耳机自动开机。
 方式二: 当耳机处于关机状态, 长按耳机触摸功能区3秒, 耳机开机。

■■■ 关机

方式一: 将耳机放回充电仓, 耳机关机。
 方式二: 长按耳机触摸功能区5秒, 耳机关机。

■■■ 配对

步骤一: 将耳机从充电仓中取出, 耳机自动开机, 开机后耳机自动组队。
 步骤二: 打开智能设备的蓝牙列表, 搜索设备型号(见包装封面型号) 并点击连接(支持单耳使用)。



■ 触控按键的操作

A: 音乐播放模式

■■■ 左/右耳机操作

上一曲: 双击左耳机(L)功能键
 下一曲: 双击右耳机(R)功能键

音量+: 三击右耳机(R)功能键
 音量-: 三击左耳机(L)功能键
 暂停/播放: 单击任意耳机功能键

B: 电话免提模式

■■■ 左/右耳机操作 (来电状态下)

接听: 单击任意耳机功能键
 拒接: 长按任意耳机功能键2秒
 挂断: 单击任意耳机功能键

C: 激活语音助手(智能设备支持语音助手)

■■■ 左/右耳机操作

激活: 长按任意耳机功能键1.5秒(通话状态下除外)



English

Open Ear Bluetooth Headsets

BLUETOOTH

Version 5.4

Instruction Manual

Please read this manual carefully before use the device.

Product Usage Introduction

- (1) Do not attempt to disassemble or replace any part of the product except for those operations specifically indicated in the instruction manual.
- (2) Do not immerse the product in water or any other liquid, the product is not designed to be waterproof.
- (3) If any liquid accidentally enters the product, disconnect and remove the product immediately.
- (4) To avoid electric shock, make sure there is no water on your hands when installing or uninstalling the product.
- (5) Do not place this product near a heat source or expose it directly to an ignition source.
- (6) Do not place this product in an environment with strong electromagnetic force, otherwise it may cause the product to malfunction. In the above cases, it is necessary to disconnect and remove this product.

Packing List

Headset X 2	Charging case X 1
Manual paper X 1	Charging line X 1

Headset Specifications

Bluetooth Version: V5.4
 Transmission distance: 10-15 metres
 Battery capacity: 30 mAh
 Usage time: about 5 hours
 Charging time: about 1.5 hours
 Rated input: 5V~20mA

Charging case Specifications

Battery capacity: 200 mAh
 Charging time: 1-1.5 hours
 Rated input: 5V~200mA
 Usage time: 15 hours

(All technical information depends on actual specifications)

Charging the case:

Use Type-C cable to connect the charging case to the 5V power adapter. This device does not support fast charging head.

(Warm tip: If the charging bay indicator light flashes green, charge the charging bay in time.)

Description of LED Indicators

★ Charging case led indicator

The headset is not fully charged: the blue light is on continuously
 Headset fully charged: the indicator light is off
 Charging the charging case: green light flashes
 Charging case fully charged: green light is on
 Low battery level in the charging case: blue light flashes

★ Headset led indicator

Power on: red and blue LEDs flash alternately
 Power off: red LED flashes three times
 Bluetooth pairing status: red and blue LEDs flash alternately
 Successful pairing with headset: LED off

Product Operating Instructions

■■■ Power on


Option 1: Remove the headset from the charging case, the headset will turn on automatically.
 Option 2: When the headset is off, press and hold the touch area of the headset for 3 seconds, the headset will turn on.

■■■ Power off

Option 1: Put the headset back into the charging case, the headset will switch off.
 Option 2: Long press the touch area of the headset for 5 seconds, the headset will switch off.

■■■ Pairings

Step 1: Remove the headset from the charging case, the headset will automatically switch on and once switched on, it will automatically execute the command.
 Step 2: Open the Bluetooth list on your smart device, find the device model (showed in the package cover) and press the connect button (supports monaural sound).



■ Touch button control

A: Music playback mode

■■■ Left/right headset control

Previous song: double-click the function key on the left headset (L)
 Next song: double-click the right headset function key (R)

Volume +: triple press the function button on the right headset (R)
 Volume -: triple press the function button on the left headset (L)
 Pause/playback: press the function button on the headset once

B: Handsfree phone mode

■■■ Left/right headset control (incoming call)

Answer: press any function key on the headset
 Reject: press and hold any headset key for 2 seconds
 Hang up: press any function key on the headset

C: Activate voice assistant (smart devices support voice assistant)

■■■ Left/Right Headset Operation

Activation: Long press any headset function key for 1.5 seconds (except under call status)

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.