



Model : C2




Scan the QR code to download the "iCam 365" APP

iCam365 / Connect the device



Download the app


Android: Search "icam365" in the Google play to download the app  
iOS: Search "icam365" in the AppStore to download the app




Connect power

Connect the device to the power supply and wait for about 1 minute


iCam365 / Add device




01.log in



02.Add device




03.Scan the QR code of the fuselage




04.Waiting for a utomatic recognition


App will be updated continuously, and the interface is subject to App




05.Select the WiFi to connect to and enter the password



06. Show the QR code to the device lens,When you hear the beep,tick I have heard it Then click next




07.Waiting to configure the network




08.The addition is complete, the device is named

iCam365 / Function Description

App will be updated continuously, and the interface is subject to App



- Alarm message
- Add device
- Live and playback
- Settings
- Share the device
- More features
- Intelligent Recognition
- Cloud recording



- Settings
- More settings
- Sound switch
- Recording screen
- Screenshot
- Video clarity
- Full screen
- Card playback
- Cloud playback
- Intercom

iCam365 / Common problem

Problems	Solution
What should I do if the device is unsuccessfully	Check whether the WiFi password is correct, and the network can be connected correctly, then RESET the camera, and add it again after completion.
How to download	Click the "Record Screen" button during playback, and click the red button after recording, and the video file will be saved to the phone;
What if the display device is offline?	First confirm whether the power supply and network are normal, and there is no problem before powering off the camera and restarting it. If the connection is still
The memory card is full, what should I do?	No manual processing is required. When the remaining memory card capacity is less than or equal to 500M, the camera will automatically overwrite the oldest video file.
The memory card shows no memory card or abnormal	1. The camera does not support hot swapping. When inserting a memory card, it needs to be powered off. Please restart the camera.2. The memory card is still not recognized after restarting the camera, please replace with a new card and test again.3. If the new card is still not recognized, the card slot may be damaged or the cable is faulty. Contact the supplier to replace the device.
What should I do if I cannot receive the warning message?	Confirm whether the system has turned off the message push permission of iCam365. If it is turned off, please turn on the "message notification" permission in the phone settings and check whether the message push is turned off in the device settings.

#### FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.