


Night Light Speaker Instruction Manual





Product Parameters

Name: Night Light Speaker
Interface: TYPE-C
Input voltage: 5V/1A
Wireless name: J01
Speaker power: 5W
Response frequency: 70Hz-18KHz
Wireless version: 5.3
Wireless distance: 10 meters
Battery capacity: 1200mAh
Product size: 14CM * 13CM * 11CM
Net weight of product: 260g
Material: ABS+silicone



Use of Pat Lamp

Long press:  to power on/off
In the startup state, the pat lamp has 4 levels (25% warm light, 50% warm light, 100% warm light, color light). The working time of the pat lamp is 13 hours for warm light level 1, 7 hours for warm light level 2, 3.5 hours for warm light level 3, and 3.5 hours for color light. The pat lamp will automatically shut down after 12 hours of standby time.



Use of White Noise

In the startup state, click  to enter white noise mode, and then click to switch to white noise programmes in sequence (a total of 20 programmes)
White noise volume: Long press the  button to adjust the volume to maximum. Stop pressing when you hear a "rub-a-dub" sound, and the volume is already at maximum.
Long press the  button to adjust the volume to the minimum, stop pressing when you hear a "rub-a-dub" sound, the volume is already at the minimum.
Double click:  to turn off white noise

Use of Wireless

In the startup state, click  to enter Wireless mode (turn off the pat lamp function), turn on Wireless in the phone settings, find the J01 speaker name and click on pairing.
Click  in proper order to switch lighting modes (colored light/warm white/off light).
In Wireless standby mode, if there is no Wireless connection for 10 minutes, it will automatically shut down.
Music playback time: about 5 hours (with 70% volume and lights off state).

TWS Speakers

Both speakers are turned on and enter Wireless mode (disconnected from the phone's Wireless state).
Double click on the  of either speaker, you will hear a "rub-a-dub" prompt sound. After about 3 seconds, both speakers will have a voice prompt sound at the same time, indicating successful pairing;
Double click on the  of either of the speakers again and you will hear a "rub-a-dub" sound, indicating unpairing the device.

Speaker Charging

a. Connect TYPE-C charging cable to speaker charging port;
b. The charger uses 5V 1A/2A adapter.
When charging the speaker, the indicator light will turn red, and when fully charged, the red light will turn off.
Charging time: It takes about 4.5 hours to charge when not working.

Matters Needing Attention

1. Do not use non-nominal voltage for charging
2. The product contains lithium batteries, and it is prohibited to approach heat sources.
3. To ensure the effective service life of the battery, it is recommended to charge it at least once every 3 months.

FCC Caution :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from

that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.