

Bluetooth tripod User Manual

NP-3180S

1. Open the back battery cover of the Bluetooth self-timer, load the battery CR2032, and it can work. Press the power on button, the blue LED will flash, it can work normally when in use, when not in use, disconnected, the product will automatically enter the sleep mode, easy to use, energy saving and environmental protection.

2. Open the Bluetooth of your mobile phone, search for Bluetooth devices, and click connect and pair when you find a Bluetooth selfie device. You can use it after successful connection.

3. When paired with another phone, just press and hold the photo button (about 3 seconds). Let it untie the previous phone first. Then search the Bluetooth device to connect and pair, open the camera, and you can use it to take pictures freely.

4. IOS and Android do not require a toggle button, as long as you connect and pair the corresponding phone, you can use the Bluetooth self-timer to take pictures.

Operation Frequency:	2402~2480 MHz
Modulation Type:	GFSK
Radio Technology:	BLE
Bluetooth Version:	4.2
Bluetooth Configuration:	BLE (1M PHY)
Number Of Channel:	40
Antenna Type:	PCB
Antenna Gain (dBi)	-1 dBi

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.