

User Documentation

Multifunctional Wireless Stereo Headphone

Button Description:

Button ON/OFF: To run/stop the system. Press the play button three times to turn off the light. Hang/Make call.

Button M: Function keys switch between M-Mod. If the device is not connected, long press or double click to switch the Chinese / English voice prompt

Button Volume up+ / Next song

Button Volume down- / Previous song

1. Technical specification

Wireless solution: 5.1(Wireless system compatible with Wireless 2.1/2.0/1.2)

USB Charging: DC 5V

Frequency: 87.5-108MHz

Wireless distance: 10 meters

Frequency response: 50Hz-20KHz

Output power: 35mW

Signal to noise ratio: 88Db

Charging time: 1 hours.

Sensitivity: 90dB/mW

Impedance value: 30 ohm

Drive unit: 40mm

Duration: 6 hours

Renewal time: 40 hours.

Transmission distance: 10 meters

Battery capacity: 250mA

Transmitting frequency: 2402MHz-2480MHz

Support TF card, Wireless, Make call.

2. Pairing to Mobile phone or other device

To use your Wireless Stereo Headphone, first you must pair your Headphone with a phone or a computer. Once your Headphone is paired and will automatically recognized each other whenever they are within range.

Pairing to a phone and Entertainment:

- Turn on your phone and ensure its 'Wireless' function is opened. Turn on the Wireless Stereo Headphone to the pairing mode.
- Search your 'Wireless devices' on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few second the phone will show a list of the device name as a discover device. Select 'Wireless' and follow your phone instruction to select and pairing.
- Finally, select to connect with device from your phone you can play music, watch TV/ movie and play game with your headphone, the you can hear all the sound or music from the headphone. Also you can control it by operating the headphone. For example, volume up, next songs etc.

Pairing to a computer and Entertainment:

- If your laptop don't have Wireless function, you can use a Wireless USB adapter(need to buy Wireless adapter by yourself)
- Turn on the headphone to the pairing mode. Open the Wireless software(such as Blue Soleil) installed on your computer, and select 'Search your Wireless devices' function. Refer to user manual of the Wireless software for more information.
- After a few second the 'Wireless' will list in Wireless software of your computer as a discover device. Select this icon and click left button of mouse to select 'pairing' item, then select 'connect with audio device'.
- With same operation, Open your media player to play music, watch TV/movie and play game, then all the sounds will be play on your headphone.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.