

User Manual for Power Bank

First of all, thanks sincerely for buying this product

- 1) For your safety, please read this manual carefully before using this product
- 2) Please make sure that write down the selling date and sales shop's name on the warranty, and put it away with operation manual, keep them properly

● Scope of application

This charger is applicable to charge the devices which with usb c or wireless charging .

● Standard Accessories

3000mAh Power Bank*1

User manual*1

● Technical Data

Product Name: Power Bank (Poseidon Nano)

Model: PN30GYBR

Capacity: 3000mAh/11.1Wh

USB-C Input: 5VDC 2.4A

USB-C Output: 5VDC 2.4A

Wireless Output: 5W 5VDC 1A

● Usage

1. Before charging your device, make sure that the technical specifications of the device (voltage, current) are compatible with the characteristics of the charger.
2. Connect the device and the mobile power supply to the charging cable, or place the device at the wireless charging port.
3. Turn on the mobile power switch button and your device starts charging.
4. After use, disconnect the charging cable from the mobile power supply and the charging device interface.

● Attention

1. This product must be used as required, otherwise it will cause a fire, explosion and other danger risks.
2. Check the power adapter parameters are with reliable quality and security before, whether the CHARGER is quick charger (QC2.0/QC3.0) or not, as this may cause to no charge or low charge and may even damage the power adapter

3. Check the usb cable is suitable connector for connections, make sure the charging cable should meet the current on 2A, or it will cause no charge or low charge, negative phenomena such as frequent start
4. Do not pull the AC adapter out with wet hands, ensure the safety and integrity of the adapter;
5. Do not let the dust or other things accumulate on the product and the AC adapter;
6. Do not use the product outside the temperature -20 °C to 40 °C;
7. Do not attempt to open, throw, hit or shake the wireless charger
8. Ensure the charging platforms and devices are not overheating, such as overheating, please cut off the power supply, to cool before attempting to charge
9. If your protective case is thick, remove it before placing your device on the wireless charger

● **Warming**

Don't intentionally disassemble and maintain the product if non-professional. Removing the product may result in damage that beyond the warranty.

● **Battery Warming**

- replacement of a battery with an incorrect type may defeat a safeguard;
 - disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, may result in an explosion;
 - leaving a battery in an extremely high temperature surrounding environment, such as sunshine, fire, or hot surface may result in an explosion or the leakage of flammable liquid or gas;
 - a battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.
- Risk of fire or explosion if the battery is replaced by an incorrect type!

● **FCC Warming**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference

received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.