

# User Manual of ML60-001

## **Introduction**

The ML60-001 is a BLE Transceiver for Vacuum Cleaner Stick networks.

Connected to the Vacuum Cleaner Stick, it acts as a pathway between remote home automation.

Power is provided by External 3.3V power supply from Bottom PAD.

## **Networking**

The ML60-001 is applied RTL8762CMF BLE Transceiver of Realtek.

The BLE transceiver delivers the information received from the remote control device to the main board from Bottom PAD.

## **Power source**

The ML60-001 is powered by an external 3.3V from Bottom PAD.

## **Expansion Ports**

34pin of Bottom PAD connects the main control board.

## **Indication**

None.

## **Notice FCC/IC Statement Approval Statement**

### **FCC Compliance Statement**

This device complies with Part 15 of the FCC's Rules. Operation is subject to the following two Conditions:

- 1.This device may not cause harmful interference, and
- 2.This device must accept any interference received, including interference that may cause undesirable operation.To satisfy FCC exterior labeling requirements, the following text must be placed on the exterior of the end product.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this e-quipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.
- The OEM integrator is responsible for ensuring the end-user has no manual instruction to remove or install module.
- The module is limited to installation in mobile or fixed applications.

## **IC approval**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic development Canada's licence exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## **FCC/IC RF exposure statements:**

This device complies with FCC & IC radiation exposure limits set forth for an uncontrolled environment. This device should be installed and must not be colocated or operating in conjunction with any other antenna or transmitter.

This device is intended only for OEM integrators under the following conditions:

- 1) This module may not be co-located with any other transmitters or antennas.
- 2) The antenna must be installed such that 20cm is maintained between the antenna and users.

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end product for any additional compliance requirements with this module installed.

In the event that these conditions cannot be met, then the FCC & IC authorizations are no longer considered valid and the FCC ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for reevaluating the end product including this module and obtaining separate FCC & IC authorizations.

Cet appareil est conforme aux limites de la FCC et IC exposition aux radiations dans un environnement non contrôlé.

Cet appareil doit être installé et ne doit pas être co-localisées ou opérant en conjonction avec une autre antenne ou un autre émetteur.

Cet appareil est conçu uniquement pour les intégrateurs OEM dans les conditions suivantes :

- 1 ) L' antenne doit être installée de telle sorte que 20 cm est maintenue entre l'antenne et les utilisateurs .
- 2 ) Ce module ne peut pas être co-localisé avec d'autres émetteurs ou des antennes . Aussi longtemps que deux conditions précitées sont remplies, le test du transmetteur supplémentaires ne seront pas tenus. Toutefois, l'intégrateur OEM est toujours responsable de tester leurs produits finis pour toutes les exigences de conformité supplémentaires avec ce module installé. Dans le cas où ces conditions ne peuvent pas être remplies, alors la FCC et IC autorisations ne sont plus considérés comme valides et l'ID de la FCC ne peut pas être utilisé sur le produit final. Dans ces circonstances, l'intégrateur OEM sera responsable de réévaluer le produit final, y compris l'obtention de ce module et séparée de la FCC et IC Autorisations

## User Information

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Attention: Toute change ou modifications non expressément approuvés par la partie responsable de la conformité pourraient annuler l'utilisateur `autorité de faire fonctionner cet équipement.

## IMPORTANT NOTE FOR OEM INTEGRATOR

This is single module which has been tested and complied with Part 15.247, and RSS-247 requirements. Host device needs to be labeled with module's FCC/IC IDs, for example, "Contains Transmitter module FCC ID: A3LML60001 IC: 649E-ML60001". This device is intended only for OEM integrators under the following conditions:

- 1) This module may not be co-located with any other transmitters or antennas.
- 2) The antenna must be installed such that 20cm is maintained between the antenna and users.
- 3) Only the antenna type and antenna gain documented in the module FCC/IC reports can be used.

As long as above conditions are met, further test or certification will not be required. However, the OEM integrator is still responsible for host product evaluation or any additional compliance requirements with this module installed. In the event that these conditions cannot be met, then the FCC & IC authorizations are no longer considered valid and the FCC ID cannot be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product including this module and obtaining separate FCC & IC authorizations.

5) Additional testing, Part 15B disclaimer This module only complied with FCC 15.247 requirements as listed on the grant, and therefore, the host product manufacturer is responsible for FCC Part 15B compliance testing with the module installed.

## Supplemental User's Manual

INTEGRATION INSTRUCTIONS per FCC KDB 996369 D03, Section 2.0

### 2.2 List of applicable FCC rules

The module has been certified for use under FCC Part 15.247 only

### 2.3 Summarize the specific operational use conditions

The host device must be tested for spurious emissions due to the module's lack of its own shielding.

### 2.4 Limited module procedures

The host device must be tested for spurious emissions due to the module's lack of its own shielding.

### 2.5 Trace antenna designs

Antenna is integrated into module and the module should be used with no other antennas

### 2.6 RF exposure considerations

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter device. **2.7 Antennas**

Antenna is soldered on the module and the module should be used with no other antennas.

### 2.8 Label and compliance information

Module contains its own label

### 2.9 Information on test modes and additional testing requirements

None required.

### 2.10 Additional testing, Part 15 Subpart B disclaimer

This module has been tested and certified to comply with FCC Part 15C requirements. The host device to which it is installed may require additional testing to show compliance with FCC Part 15B requirements.

## Supplemental User's Manual

INTEGRATION INSTRUCTIONS per FCC KDB 996369 D03, Section 2.0

### Notice:

OEM should include the following warnings on the label:

"Contains FCC ID:\*\*\*\*\*, IC Number:\*\*\*\*\*"

As well as the model name:

\*\*\*\*\*"

Installer should include the following in the user's manual:

"This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

"Changes of modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."