

Power Quotient International Co., Ltd

PQI Air Pen

A400

Getting Started

Step 1: Charge your “PQI Air” Pen

Please fully charge your “PQI Air” Pen before the first use. Connect the USB port to a PC or USB power adapter to charge your device. The orange LED indicator will turn off when charging has completed. The red LED indicator is lit when battery level drops below 20%. Please recharge as soon as possible.

Step 2: Prepare your content for “PQI Air” Pen

Insert the Micro SDHC card into the slot of “PQI Air” Pen (Supports only Micro SDHC 4 to 32 GB). Connect the “PQI Air” Pen to the PC using the USB plug. “PQI Air” Pen will appear as a removable disk drive, and simply copy the files from your PC to “PQI Air” Pen.

Step 3:

Download the free “PQI Air Pen +” App from Apple App Store (iOS Device) or Google Play (Android Device).

Step 4: Power on your “PQI Air” Pen

Press the round P logo power button for two seconds. First the blue LED indicator will light up and then the side blue Wi-Fi LED indicator will begin flashing. Then, move onto the next step.

Step 5:

On your mobile device, choose "Wi-Fi Settings" from the "Settings" menu. Then, choose “PQI Air” Pen to enable the connection.

Step 6:

Once connected, launch the “PQI Air Pen +” application on your mobile device and start to browse the digital content from “PQI Air” Pen.

Note: Repeat steps 3~6 to share your “PQI Air” Pen with up to 5 different devices.

Step 7:

Your "PQI Air" Pen becomes a wireless access point when plugging in an Ethernet cable.

Preferences:

The following settings are available in the "PQI Air Pen +" "Settings" menu.

- "Wi-Fi SSID": Change the name of your "PQI Air" Pen. (It is recommended that you change your own SSID)

- "Password/Change Password": Enable password and setup a password to protect data from being accessed by unauthorized connections.

FCC Statement:

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may

cause undesired operation.

For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

IMPORTANT NOTE:

Federal Communication Commission (FCC) Radiation Exposure Statement

This EUT is compliance with SAR for general population/uncontrolled exposure limits in ANSI/IEEE C95.1-1999 and had been tested in accordance with the measurement methods and procedures specified in OET Bulletin 65 Supplement C. This equipment should be installed and operated with minimum distance 0.5 cm between the radiator & your body.