



Plot H6a1

*RBW 100 kHz Marker 1 [T1]


*VBW 300 kHz 13.52 dBm

Ref 20 dBm

*Att 30 dB

SWT 250 ms

2.405038000 GHz






Plot H6a2

*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 13.60 dBm
Ref 20 dBm *Att 30 dB SWT 2.35 s 2.405038000 GHz

1 PK
VIEW





Plot H6b1

*RBW 100 kHz Marker 1 [T1]

*VBW 300 kHz 13.90 dBm


Ref 20 dBm

*Att 30 dB

SWT 250 ms

2.445022000 GHz

1 PK
VIEW






Plot H6b2

*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 13.83 dBm
Ref 20 dBm *Att 30 dB SWT 2.35 s 2.445022000 GHz

1 PK
VIEW





Plot H6c1

*RBW 100 kHz Marker 1 [T1]


*VBW 300 kHz 13.39 dBm

Ref 20 dBm

*Att 30 dB

SWT 250 ms

2.480008000 GHz





Plot H6c2

*RBW 100 kHz Marker 1 [T1]


*VBW 300 kHz 13.53 dBm

Ref 20 dBm

*Att 30 dB

SWT 2.3 s

2.480008000 GHz





Ref 20 dBm


- * Att 30 dB

```
*RBW 100 kHz   Delta 1 [T1 ]
```

```
* VBW 300 kHz -47.21 dB
```

SWT 2.5 ms

-3.1400000000 MHz





Plot H6d2

*RBW 100 kHz Delta 1 [T1]
*VBW 300 kHz -51.20 dB
Ref 20 dBm *Att 30 dB SWT 2.5 ms 3.860000000 MHz

1 PK
VIEW

