



Plot B6a1

*RBW 100 kHz Marker 1 [T1]


*VBW 300 kHz 15.23 dBm

Ref 20 dBm

*Att 30 dB

SWT 250 ms

2.405038000 GHz






Plot B6a2

*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 15.16 dBm
Ref 20 dBm *Att 30 dB SWT 2.3 s 2.368000000 GHz

1 PK
VIEW





Plot B6b1

*RBW 100 kHz Marker 1 [T1]


*VBW 300 kHz 15.34 dBm

Ref 20 dBm

*Att 30 dB

SWT 250 ms

2.445022000 GHz





Plot B6b2

*RBW 100 kHz Marker 1 [T1]

*VBW 300 kHz 15.03 dBm


Ref 20 dBm

*Att 30 dB

SWT 2.35 s

2.440000000 GHz

1 PK
VIEW





Plot B6c1

*RBW 100 kHz Marker 1 [T1]


*VBW 300 kHz 15.04 dBm

Ref 20 dBm

*Att 30 dB

SWT 250 ms

2.480008000 GHz





Plot B6c2

*RBW 100 kHz Marker 1 [T1]


*VBW 300 kHz 15.35 dBm

Ref 20 dBm

*Att 30 dB

SWT 2.3 s

2.480008000 GHz





Plot B6d1

*RBW 100 kHz Delta 1 [T1]

*VBW 300 kHz -47.17 dB


Ref 20 dBm

*Att 30 dB

SWT 2.5 ms

-3.160000000 MHz

1 PK
VIEW





Plot B6d2

*RBW 100 kHz Delta 1 [T1]

*VBW 300 kHz -48.93 dB

Ref 20 dBm

*Att 30 dB

SWT 2.5 ms

4.260000000 MHz

1 PK
VIEW

