



# Plot H6a.1

Ref 20 dBm

\*Att 30 dB


\*RBW 100 kHz Marker 1 [T1 ]

\*VBW 300 kHz

-2.49 dBm

SWT 250 ms

2.405038000 GHz





# Plot H6a.2

Ref 20 dBm

\*Att 30 dB

\*RBW 100 kHz Marker 1 [T1 ]


\*VBW 300 kHz

-3.02 dBm

SWT 2.3 s

2.368000000 GHz

1 PK  
VIEW






# Plot H6b.1

\*RBW 100 kHz Marker 1 [T1 ]  
\*VBW 300 kHz -0.24 dBm  
SWT 250 ms 2.445022000 GHz

Ref 20 dBm

\*Att 30 dB

1 PK  
VIEW



Start 1 MHz

249.9 MHz/

Stop 2.5 GHz



# Plot H6b.2

Ref 20 dBm

\*Att 30 dB


\*RBW 100 kHz Marker 1 [T1 ]

\*VBW 300 kHz

-0.64 dBm

SWT 2.3 s

2.414000000 GHz





# Plot H6c.1

Ref 20 dBm

\*Att 30 dB


\*RBW 100 kHz Marker 1 [T1 ]

\*VBW 300 kHz

0.49 dBm

SWT 250 ms

2.480008000 GHz





# Plot H6c.2

Ref 20 dBm

\*Att 30 dB

\*RBW 100 kHz Marker 1 [T1 ]


\*VBW 300 kHz

0.65 dBm

SWT 2.3 s

2.460000000 GHz

1 PK  
VIEW



A

LVL



# Plot H6d.1


Ref 20 dBm

\*Att 30 dB

\*RBW 100 kHz Delta 1 [T1 ]

\*VBW 300 kHz -43.05 dB

SWT 2.5 ms -3.700000000 MHz



Start 2.395 GHz

1 MHz/

Stop 2.405 GHz



# Plot H6d.2

Ref 20 dBm

\*Att 30 dB

\*RBW 100 kHz


Marker 1 [T1 ]

\*VBW 300 kHz

-0.29 dBm

SWT 2.5 ms

2.475680000 GHz



Start 2.474 GHz

1 MHz/

Stop 2.484 GHz