



English
More detailed operating instructions are available in "Owner's Manual (PDF format)".
To read it, download it from the website. (→ below)
• Click the desired language.

Francés
Un mode d'emploi plus détaillé est disponible dans "Manuel d'utilisation (format PDF)".
Pour le lire, le télécharger depuis le site web. (→ ci-dessous)
• Cliquez sur la langue souhaitée.

Español
Puede encontrar instrucciones de funcionamiento más detalladas en las "Instrucciones de funcionamiento (formato PDF)".
Para leerlas, descárgalas del sitio web. (→ abajo)
• Haga clic en el idioma deseado.

https://www.technics.com/support/downloads/EAH-AZ60_AZ60.html

Part names

- **Main unit (earphones)**
- 1 Touch sensor (L) (left)
- 2 Touch sensor (R) (right)
- 3 Earphone
- 4 Earphone LED
- 5 Flashing red
- 6 The charge in the battery is running low. You should charge the unit.
- 7 Raised dot indicating the L side

- **Main unit (charging cradle)**
- 6 Certification information label
- 7 Terminal section
- 8 Charging cradle LED
- **Lighting green:**
The battery is charged fully.
- **Lighting yellow:**
The charge in the battery is high.
- **Lighting red:**
The charge in the battery is running low. You should charge the unit.
- **Lighting blue:**
During charging.
- 9 Charging terminal

1 Charging

The rechargeable battery (installed in the unit) is not charged initially. Charge the battery before using the unit.

1 Use the USB charging cord (supplied) (●) to connect the charging cradle to a 5.0 V power source (500 mA or higher) (●).
• The charging cradle LED lights (green, yellow or red) while the charging cradle is charging.

2 Put the earphones into the charging cradle.
• Inserting the earphones, the charging cradle LED (blue) flashes twice. When no flashing, the earphones are not inserted correctly.

3 Confirm that the charging cradle LED has illuminated (charging starts).

■ **Charging time**

Earphones	Approx. XXXX hours
Charging cradle	Approx. XXXX hours
Earphones with Charging cradle	Approx. XXXX hours

2 Pairing

Connecting by pairing (registering) your earphones with a Bluetooth® device.

- Using the "Technics Audio Connect" app (free of charge) makes connecting with Bluetooth® simple.

1 Take both earphones out of the charging cradle.
• The earphone LEDs will light alternately in blue and red.
• When pairing with the another device:
• Touch and hold the sensor (L or R) for 1 seconds until the LED starts flashing Red/Blue, indicating that you have entered the pairing mode.

2 Turn on the Bluetooth® device and enable the Bluetooth® function.
• Inserting the earphones, the charging cradle LED (blue) flashes twice. When no flashing, the earphones are not inserted correctly.

3 From the Bluetooth® menu of the Bluetooth® device, select device name "EAH-AZ60" or "EAH-AZ60".

4 Confirm that the earphones and the Bluetooth® device are connected.
• When the earphone LEDs blink twice at approximately 5 second intervals, pairing has been completed and connection has been established.

3 Fit the earphones

Fit the earphones correctly in order to get adequate noise cancelling effect and acoustics.

1 Check the orientation and L (left) and R (right) of the earphones.
2 Fit firmly the earphones as the illustration.
• Confirm that the earphones will not fall from your ears after you have fitted them.
• The left earphone has a raised dot indicating the L side.
• If the earphones fall out easily, replace with earpieces (supplied) of a different size.

4 Operating with the Touch sensors

Operation	Touch sensor (L)	Touch sensor (R)
Touch once	Volume -	▶▶▶
Touch rapidly 2 times	Volume +	▶▶▶
Touch rapidly 3 times	Start the voice assistant	Change control of external sounds
Touch and hold for about 2 seconds		

Operation	Touch sensor (L)	Touch sensor (R)
Touch once	Receive phone call	
Touch rapidly 2 times	-	Reject a phone call
Touch and hold for about 2 seconds	-	End a phone call

• You can customize the touch sensor operation in the app.

To remove/attach the earpieces

If the earpieces fall out easily, replace with earpieces (supplied) of a different size.

- **Remove the earpieces**
Hold the earpiece with your fingertips and twist slightly to pull it out.
- **Attach the earpieces**
Make sure the earpieces are fitted firmly into your ears and confirm that they are not at an angle.

Restoring to the factory settings

Change the earphones before restoring the earphones to their factory settings.

1 Take the R side earphone out of the charging cradle.
2 Touch and hold the touch sensor (R) for about 7 seconds.
• The earphone LED will light alternately in blue and red.

3 Touch and hold the touch sensor (R) for about 10 seconds.
• The earphone LED (blue) blinks rapidly, and when the power turns off, the earphone returns to the factory settings.

4 Do the same Steps 1 to 3 above for the L side earphone.

• To re-pair the earphones with a Bluetooth® device, delete the registered information (device name: EAH-AZ60 or EAH-AZ60) on the device, then pair the earphones with the Bluetooth® device again.

Troubleshooting

Before requesting service, make the following checks. If you are in doubt about some of the check points, or if the remedies indicated do not solve the problem, consult your dealer for instructions.

Does not connect with the Bluetooth® device.

- Delete the registration information for this unit from the Bluetooth® menu, etc., of the Bluetooth® device, then pair again.

Cannot charge the unit.

- Make sure to charge in a room temperature between 10 °C and 35 °C.
- Is the unit already fully charged? The charging cradle LED will turn off immediately if the unit is fully charged.
- Have the earphones been put into the charging cradle correctly?
- If the earphone LEDs do not light even after putting the earphones into the charging cradle, then there is no charge remaining in the charging cradle battery. First charge the charging cradle.
- Is the USB charging cord connected firmly to the USB terminal of the computer?

Part names

- **Main unit (earphones)**
- 1 Touch sensor (L) (left)
- 2 Touch sensor (R) (right)
- 3 Earphone
- 4 Earphone LED
- 5 Flashing red
- 6 The charge in the battery is running low. You should charge the unit.
- 7 Raised dot indicating the L side

- **Main unit (charging cradle)**
- 6 Certification information label
- 7 Terminal section
- 8 Charging cradle LED
- **Lighting green:**
The battery is charged fully.
- **Lighting yellow:**
The charge in the battery is high.
- **Lighting red:**
The charge in the battery is running low. You should charge the unit.
- **Lighting blue:**
During charging.
- 9 Charging terminal

1 Charging

The rechargeable battery (installed in the unit) is not charged initially. Charge the battery before using the unit.

1 Use the USB charging cord (supplied) (●) to connect the charging cradle to a 5.0 V power source (500 mA or higher) (●).
• The charging cradle LED lights (green, yellow or red) while the charging cradle is charging.

2 Put the earphones into the charging cradle.
• Inserting the earphones, the charging cradle LED (blue) flashes twice. When no flashing, the earphones are not inserted correctly.

3 Confirm that the charging cradle LED has illuminated (charging starts).

■ **Charging time**

Earphones	Approx. XXXX hours
Charging cradle	Approx. XXXX hours
Earphones with Charging cradle	Approx. XXXX hours

2 Pairing

Connecting by pairing (registering) your earphones with a Bluetooth® device.

- Using the "Technics Audio Connect" app (free of charge) makes connecting with Bluetooth® simple.

1 Take both earphones out of the charging cradle.
• The earphone LEDs will light alternately in blue and red.
• When pairing with the another device:
• Touch and hold the sensor (L or R) for 1 seconds until the LED starts flashing Red/Blue, indicating that you have entered the pairing mode.

2 Turn on the Bluetooth® device and enable the Bluetooth® function.
• Inserting the earphones, the charging cradle LED (blue) flashes twice. When no flashing, the earphones are not inserted correctly.

3 From the Bluetooth® menu of the Bluetooth® device, select device name "EAH-AZ60" or "EAH-AZ60".

4 Confirm that the earphones and the Bluetooth® device are connected.
• When the earphone LEDs blink twice at approximately 5 second intervals, pairing has been completed and connection has been established.

3 Fit the earphones

Fit the earphones correctly in order to get adequate noise cancelling effect and acoustics.

1 Check the orientation and L (left) and R (right) of the earphones.
2 Fit firmly the earphones as the illustration.
• Confirm that the earphones will not fall from your ears after you have fitted them.
• The left earphone has a raised dot indicating the L side.
• If the earphones fall out easily, replace with earpieces (supplied) of a different size.

4 Operating with the Touch sensors

Operation	Touch sensor (L)	Touch sensor (R)
Touch once	Volume -	▶▶▶
Touch rapidly 2 times	Volume +	▶▶▶
Touch rapidly 3 times	Start the voice assistant	Change control of external sounds
Touch and hold for about 2 seconds		

Operation	Touch sensor (L)	Touch sensor (R)
Touch once	Receive phone call	
Touch rapidly 2 times	-	Reject a phone call
Touch and hold for about 2 seconds	-	End a phone call

• You can customize the touch sensor operation in the app.

To remove/attach the earpieces

If the earpieces fall out easily, replace with earpieces (supplied) of a different size.

- **Remove the earpieces**
Hold the earpiece with your fingertips and twist slightly to pull it out.
- **Attach the earpieces**
Make sure the earpieces are fitted firmly into your ears and confirm that they are not at an angle.

Restoring to the factory settings

Change the earphones before restoring the earphones to their factory settings.

1 Take the R side earphone out of the charging cradle.
2 Touch and hold the touch sensor (R) for about 7 seconds.
• The earphone LED will light alternately in blue and red.

3 Touch and hold the touch sensor (R) for about 10 seconds.
• The earphone LED (blue) blinks rapidly, and when the power turns off, the earphone returns to the factory settings.

4 Do the same Steps 1 to 3 above for the L side earphone.

• To re-pair the earphones with a Bluetooth® device, delete the registered information (device name: EAH-AZ60 or EAH-AZ60) on the device, then pair the earphones with the Bluetooth® device again.

Troubleshooting

Before requesting service, make the following checks. If you are in doubt about some of the check points, or if the remedies indicated do not solve the problem, consult your dealer for instructions.

Does not connect with the Bluetooth® device.

- Delete the registration information for this unit from the Bluetooth® menu, etc., of the Bluetooth® device, then pair again.

Cannot charge the unit.

- Make sure to charge in a room temperature between 10 °C and 35 °C.
- Is the unit already fully charged? The charging cradle LED will turn off immediately if the unit is fully charged.
- Have the earphones been put into the charging cradle correctly?
- If the earphone LEDs do not light even after putting the earphones into the charging cradle, then there is no charge remaining in the charging cradle battery. First charge the charging cradle.
- Is the USB charging cord connected firmly to the USB terminal of the computer?

Part names

- **Main unit (earphones)**
- 1 Touch sensor (L) (left)
- 2 Touch sensor (R) (right)
- 3 Earphone
- 4 Earphone LED
- 5 Flashing red
- 6 The charge in the battery is running low. You should charge the unit.
- 7 Raised dot indicating the L side

- **Main unit (charging cradle)**
- 6 Certification information label
- 7 Terminal section
- 8 Charging cradle LED
- **Lighting green:**
The battery is charged fully.
- **Lighting yellow:**
The charge in the battery is high.
- **Lighting red:**
The charge in the battery is running low. You should charge the unit.
- **Lighting blue:**
During charging.
- 9 Charging terminal

1 Charging

The rechargeable battery (installed in the unit) is not charged initially. Charge the battery before using the unit.

1 Use the USB charging cord (supplied) (●) to connect the charging cradle to a 5.0 V power source (500 mA or higher) (●).
• The charging cradle LED lights (green, yellow or red) while the charging cradle is charging.

2 Put the earphones into the charging cradle.
• Inserting the earphones, the charging cradle LED (blue) flashes twice. When no flashing, the earphones are not inserted correctly.

3 Confirm that the charging cradle LED has illuminated (charging starts).

■ **Charging time**

Earphones	Approx. XXXX hours
Charging cradle	Approx. XXXX hours
Earphones with Charging cradle	Approx. XXXX hours

2 Pairing

Connecting by pairing (registering) your earphones with a Bluetooth® device.

- Using the "Technics Audio Connect" app (free of charge) makes connecting with Bluetooth® simple.

1 Take both earphones out of the charging cradle.
• The earphone LEDs will light alternately in blue and red.
• When pairing with the another device:
• Touch and hold the sensor (L or R) for 1 seconds until the LED starts flashing Red/Blue, indicating that you have entered the pairing mode.

2 Turn on the Bluetooth® device and enable the Bluetooth® function.
• Inserting the earphones, the charging cradle LED (blue) flashes twice. When no flashing, the earphones are not inserted correctly.

3 From the Bluetooth® menu of the Bluetooth® device, select device name "EAH-AZ60" or "EAH-AZ60".

4 Confirm that the earphones and the Bluetooth® device are connected.
• When the earphone LEDs blink twice at approximately 5 second intervals, pairing has been completed and connection has been established.

3 Fit the earphones

Fit the earphones correctly in order to get adequate noise cancelling effect and acoustics.

1 Check the orientation and L (left) and R (right) of the earphones.
2 Fit firmly the earphones as the illustration.
• Confirm that the earphones will not fall from your ears after you have fitted them.
• The left earphone has a raised dot indicating the L side.
• If the earphones fall out easily, replace with earpieces (supplied) of a different size.

4 Operating with the Touch sensors

Operation	Touch sensor (L)	Touch sensor (R)
Touch once	Volume -	▶▶▶
Touch rapidly 2 times	Volume +	▶▶▶
Touch rapidly 3 times	Start the voice assistant	Change control of external sounds
Touch and hold for about 2 seconds		

Operation	Touch sensor (L)	Touch sensor (R)
Touch once	Receive phone call	
Touch rapidly 2 times	-	Reject a phone call
Touch and hold for about 2 seconds	-	End a phone call

• You can customize the touch sensor operation in the app.

To remove/attach the earpieces

If the earpieces fall out easily, replace with earpieces (supplied) of a different size.

- **Remove the earpieces**
Hold the earpiece with your fingertips and twist slightly to pull it out.
- **Attach the earpieces**
Make sure the earpieces are fitted firmly into your ears and confirm that they are not at an angle.

Restoring to the factory settings

Change the earphones before restoring the earphones to their factory settings.

1 Take the R side earphone out of the charging cradle.
2 Touch and hold the touch sensor (R) for about 7 seconds.
• The earphone LED will light alternately in blue and red.

3 Touch and hold the touch sensor (R) for about 10 seconds.
• The earphone LED (blue) blinks rapidly, and when the power turns off, the earphone returns to the factory settings.

4 Do the same Steps 1 to 3 above for the L side earphone.

• To re-pair the earphones with a Bluetooth® device, delete the registered information (device name: EAH-AZ60 or EAH-AZ60) on the device, then pair the earphones with the Bluetooth® device again.

Troubleshooting

Before requesting service, make the following checks. If you are in doubt about some of the check points, or if the remedies indicated do not solve the problem, consult your dealer for instructions.

Does not connect with the Bluetooth® device.

- Delete the registration information for this unit from the Bluetooth® menu, etc., of the Bluetooth® device, then pair again.

Cannot charge the unit.

- Make sure to charge in a room temperature between 10 °C and 35 °C.
- Is the unit already fully charged? The charging cradle LED will turn off immediately if the unit is fully charged.
- Have the earphones been put into the charging cradle correctly?
- If the earphone LEDs do not light even after putting the earphones into the charging cradle, then there is no charge remaining in the charging cradle battery. First charge the charging cradle.
- Is the USB charging cord connected firmly to the USB terminal of the computer?

English

Useful information (Only for Latin American countries)

Customer Service

Customer Service Directory

Obtain product information and operative assistance. Locate the closest distributor or Service Center. See page numbers and accessories by our Web Site in Latin America or calling our Contact Center.

- Haga clic en el idioma deseado.

País	Sitio Web	Contacto
Brasil	www.panasonic.com/br/technical	800-7262782
Colombia	www.panasonic.com/co/technical	01-8000-847212
Ecuador	www.panasonic.com/ve/technical	1-800-7262782
Costa Rica	www.panasonic.com/cr/technical	800-7262782
El Salvador	www.panasonic.com/sv/technical	800-7262782
Guatemala	www.panasonic.com/gu/technical	1-800-811-7262
Honduras	www.panasonic.com/hn/technical	8-800-7262
Paraguay	www.panasonic.com/py/technical	6-800-71-7262
Perú	www.panasonic.com/pe/technical	800-390-862
Uruguay	www.panasonic.com/uy/technical	800-7262782
Venezuela	www.panasonic.com/ve/technical	800-7262-800
México	www.panasonic.com/mx/technical	800-847-7262
Argentina	www.panasonic.com/ar/technical	800-221-7262
Chile	www.panasonic.com/cl/technical	800-221-7262
Dominican Rep.	www.panasonic.com/do/technical	800-200-8000

For Caribbean countries that speak English please enter this web site to enter the full information of our products and operative assistance: www.panasonic.com/caribbean

Español

Información útil (Solo para los países de América Latina)

Atención al Cliente

Directorio de Atención al Cliente

Obtenga información de productos y asistencia operativa. Localice el Centro de Servicios más cercano y consulte repuestos y accesorios a través de nuestro Sitio Web o llamando a nuestro Contact Center.

- Haga clic en el idioma deseado.

País	Sitio Web	Contacto
Brasil	www.panasonic.com/br/technical	800-7262782
Colombia	www.panasonic.com/co/technical	01-8000-847212
Ecuador	www.panasonic.com/ve/technical	1-800-7262782
Costa Rica	www.panasonic.com/cr/technical	800-7262782
El Salvador	www.panasonic.com/sv/technical	800-7262782
Guatemala	www.panasonic.com/gu/technical	1-800-811-7262
Honduras	www.panasonic.com/hn/technical	8-800-7262
Paraguay	www.panasonic.com/py/technical	6-800-71-7262
Perú	www.panasonic.com/pe/technical	800-390-862
Uruguay	www.panasonic.com/uy/technical	800-7262782
Venezuela	www.panasonic.com/ve/technical	800-7262-800
México	www.panasonic.com/mx/technical	800-847-7262
Argentina	www.panasonic.com/ar/technical	800-221-7262
Chile	www.panasonic.com/cl/technical	800-221-7262
Dominicana	www.panasonic.com/do/technical	800-200-8000

Para países que hablan inglés por favor ingrese a este sitio web para obtener toda la información de nuestros productos y asistencia operativa: www.panasonic.com/caribbean

Solo para México

La información en este manual está escrita en los idiomas de los condados. Si no encuentra que este equipo o dispositivo no tiene información por idioma y si este equipo o dispositivo debe aceptar cualquier información, indíquenos lo que puede ocurrir en operación no deseada.