Selectable Gadget pack

You can set it yourself and select it later.


You can select from the following five types of pack.

Type A	Type B	Type C	Type D	Type E
Second Battery	Smart Card	Fingerprint	Contactless Smart Card	Contactless Smart Card Reader / Fingerprint Reader
Pack	Reader	Reader	Reader	

Inserting/Removing the Selectable Gadget pack


- 1. Turn off the computer and disconnect the AC adaptor.
- 2. Turn your computer over and remove the battery pack (Replacing the Battery Pack).

 Make sure no foreign objects are under the computer.
- 3. Insert/Remove the Selectable Gadget pack.
 - To remove
 - 1. Remove the screw (A).
 - 2. Slide the latch (B), and pull out the Selectable Gadget pack (C).



- To insert
 - 1. Slide the Selectable Gadget pack in parallel with the arrow direction until it click to the secured position.

2. Tighten the screw (D) firmly.



4. Insert the Battery Pack.

ENGLISH

Addendum

Thank you for using Panasonic products.

This leaflet is informed of the following products: FZ-VNF551U / FZ-VNF552U

To attach the gadget pack to the computer, refer to Doperating Instructions - Reference Manual "Selectable Gadget pack".

To use RFID reader or fingerprint reader, refer to Coperating Instructions - Reference Manual "Contactless Smart Card Reader/RFID Reader" "Fingerprint Reader".

> HS1018-0 DHQX1545ZA/T1

Printed in Taiwan

Supplied accessories

Check and identify the supplied accessories. If you do not find the described accessories, contact your support office.

- RFID Reader or RFID & Finger Print Reader 1
- Addendum (this leaflet) 1

This product can be used only for FZ-55 series.

■ Regulatory Information

For U.S.A.

Federal Communications Commission Radio Frequency Interference Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the Panasonic Service Center or an experienced radio/TV technician for help.

Warning

To assure continued compliance, use only shielded interface cables when connecting to a computer or peripheral. Also, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that may cause undesired operation.

This device is Class B confirmed to comply with Part 15 of FCC Rules when used with Panasonic Notebook Computer.

Responsible Party:

Panasonic Corporation of North America Two Riverfront Plaza Newark, NJ 07102

Support Contact:

https://na.panasonic.com/us/support

For Canada Canadian ICES-3 CAN ICES-3(B)/NMB-3(B)

For Europe

Declaration of Conformity (DoC)"Hereby, Panasonic declares that this product is in compliance with the essential requirements and other relevant provisions of EU Council Directives.

Authorised Representative: Panasonic Testing Centre Panasonic Marketing Europe GmbH Winsbergring 15, 22525 Hamburg, Germany Disposal of Old Equipment



Only for European Union and countries with recycling systems

This symbol on the products, packaging, and/or accompanying documents means that used electrical and electronic products must not be mixed with general household waste. For proper treatment, recovery and recycling of old products, please take them to applicable collection points in accordance with your national legislation.

By disposing of them correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment. For more information about collection

and recycling, please contact your local municipality. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

For India

Declaration of Conformity with the requirements of the E-Waste (Management) Rules
The Product is in conformity with the requirements of the reduction of hazardous substances of the E-Waste Rules.

The content of hazardous substance with the exemption of the applications listed in SCHEDULE II of the E-waste Rules:

1. Lead (Pb) - not over 0.1% by weight;

2. Cadmium (Cd) - not over 0.01% by weight;

3. Mercury (Hg) - not over 0.1% by weight;

4. Hexavalent chromium (Cr6+) - not over 0.1% by weight;

5. Polybrominated biphenyls (PBBs) - not over 0.1% by weight;

6. Polybrominated diphenyl ethers (PBDEs) - not over 0.1% by weight.



For the purpose of recycling to facilitate effective utilization of resources, please return this product to a nearby authorized collection center, registered dismantler or recycler, or Panasonic service center when disposing of this product. Please see the Panasonic website for further information on collection s, etc., or call the toll-free number below.

Website:

https://www.panasonic.com/in/corporate/sustainability/panasonic-india-irecycle-program.html

Service helpline: 1800 103 1333 or 1800 108 1333

Do's	Do's & Don't: - E-Waste (Management) Amendment Rules 2018				
S.No.	Do's	Don't			
1	All electrical and electronic products are required to be handed over only to the Authorized recycler.	The product should not be opened by the User himself/ herself, but only by authorized service personnel.			
2	The product should be handed over only to authorized recycler for disposal.	The product is not meant for resale any unauthorized agencies/scrap dealer/ kabariwalahs.			
3	Keep the product in isolated area, after it becomes non-functional/un-repairable so as to prevent its accidental breakage.	The product is not meant for mixing into household waste stream.			
4	Provide information on the catalogue with product end-of-life.	Do not keep any replaced spare part(s) from the product in exposed area.			
5	Always Dispose products that have reached end-of life at Panasonic India authorized service center.	Do not donate old electronic items to anybody.			
6	Wherever possible or as instructed, separate the packaging material according to responsible waste disposal options and sorting for recycling.	Do not give e-waste to informal and unorganized sectors like Lo- cal Scrap Dealer/ Rag Pickers.			
7	Create environment awareness PAN India Level.	Do not dispose your product in garbage bins along with municipal waste that ultimately reaches landfill.			

68-M-3

6-M-1

7-M-2