



SAFETY INSTRUCTIONS

WARNING



Do not open the equipment.

Hazardous voltage which can cause electrical shock, burn or serious injury exists inside the equipment. Only qualified personnel should work inside the equipment.



Do not approach the antenna closer than 33 cm when it is transmitting.

The antenna emits radio waves which can be harmful to the human body.

	RF power density on antenna aperture	distance
FM-8800S	100 W/m ²	0.11 m
	10 W/m ²	0.33 m
FM-8800L	100 W/m ²	0.10 m
	10 W/m ²	0.33 m

Do not disassemble or modify the equipment.

Fire, electrical shock or serious injury can result.

Turn off the power immediately if water leaks into the equipment or the equipment is emitting smoke or fire.

Continued use of the equipment can cause fire or electrical shock.

Do not place liquid-filled containers on the top of the equipment.

Fire or electrical shock can result if a liquid spills into the equipment.

WARNING

Do not operate the equipment with wet hands.

Electrical shock can result.

Keep heater away from equipment.

Heat can alter equipment shape and melt the power cord, which can cause fire or electrical shock.

Any repair work must be done by a licensed radio technician.

Improper repair work can cause electrical shock or fire.


CAUTION

Do not touch any part of the antenna when the equipment is transmitting.

Electrical shock can result.

Use the proper fuse.

Use of a wrong fuse can result in fire or cause permanent damage to the equipment.



Terminal, Communication Unit
Name: Warning Label (1)
Type: 86-003-1011
Code No.: 100-236-231