

DMH-W2770NEX DMH-W2700NEX

Quick start guide
Guide de démarrage rapide
Guía de inicio rápido

English
This guide is intended to guide you through the basic functions of this unit.
For details, please refer to the Operation manual stored on the website.
<https://www.pioneer-electronics.com/PUSA/>



<https://www.pioneer-electronics.ca/POCEN/>

Français
Ce guide est destiné à vous guider dans les fonctions de base de cet appareil.
Pour les détails, veuillez vous reporter au Mode d'emploi disponible sur le site Web.
<https://www.pioneer-electronics.com/PUSA/>



<https://www.pioneer-electronics.ca/POCEN/>

Español
Este guía tiene como fin explicar las funciones básicas de esta unidad.
Para obtener más información, consulte el manual de operaciones que se encuentra en el sitio web.
<https://www.pioneer-electronics.com/PUSA/>



<https://www.pioneer-electronics.ca/POCEN/>



English Precaution

Information to user

This device contains (one or more) transmitter(s)/receiver(s) that complies with Part 15 of FCC Rules and Innovation, Science, and Economic Development Canada licence exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

The Bluetooth antenna cannot be removed or replaced by user. This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Information to User: Alteration or modifications carried out without appropriate authorization may invalidate the user's right to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FEDERAL COMMUNICATIONS COMMISSION SUPPLIER'S DECLARATION OF CONFORMITY
Product Name: RDS AV RECEIVER
Model Number: DMH-W2770NEX, DMH-W2700NEX
Responsible Party Name: PIONEER ELECTRONICS (USA) INC. SERVICE SUPPORT DIVISION
Address: 2000 W. 190TH STREET, SUITE 100, TORRANCE, CA 90504, U.S.A.
Phone: 1-800-421-1404
URL: <http://www.pioneer-electronics.com>

WARNING
Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product, and to protect it from overheating. To prevent fire hazard, the openings should never be blocked or covered with items such as papers, floor mat, cloth.

CAN ICES-3 B/NMB-3 B

<QSG_DMHW2700NEXUC_A>

English

- Touch
- Touch and slide
- Touch and hold

What's What

1. Power off
2. Mute or unmute
3. Activate the voice recognition mode
4. Display off
5. Power off
6. Display the top menu screen

Selecting the clock

1. Switch to clock adjustment display
2. Adjust the clock

Selecting the source

1. Select a source

Tuner operation

1. Store the strongest broadcast frequencies
2. Select a band
3. Tune into the next station
4. Recall the preset channel stored to a key from memory
5. Store the current broadcast frequency to a key
6. Displays a preset channel for 10 seconds and switches to the next channel automatically.
7. Tune into only radio stations with sufficiently strong signals

Moving images operation

1. Pause and start playback
2. Change the playback point
3. Selects the previous file or the next file.

Audio operation

1. Pause and start playback
2. Selects the previous file or the next file.
3. Performs fast forward or fast reverse. Touch again to change the playback speed.

List search operation

1. Display the playlist screen
2. Select the media file types
3. Select a list title or folder that you want to play
4. Scroll the list

Wi-Fi® connection

1. Turn on the Wi-Fi function on the device.
2. [Wi-Fi] → [Wi-Fi Settings]
3. Set [Wi-Fi] to on.
4. Check the password in the [Password] menu.
5. [Device Information]
6. Check the [Network Name] and select the network name on the mobile device.
7. Input the password displayed in [Password] on the mobile device.

Bluetooth® connection

1. [Bluetooth] → [Bluetooth Settings] → [Search].
2. [Bluetooth device name].

NOTE
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Pioneer Corporation is under license. Other trademarks and trade names are those of their respective owners.

Bluetooth telephone operation

1. Enter the phone number directly
2. Switch to the phone book mode
3. Switch to the call history list
4. Make an outgoing call