# TALKABOUT <sup>®</sup> TWO-WAY RADIO T1XX SERIES





MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. © 2016 and 2019 Motorola Solutions, Inc. All rights reserved.

Printed in

#### Safety and General Information

#### Caution

Before using this radio, read this booklet which contains important operating instructions.

For information on product details, brochures, user manuals and approved accessories. Please refer to www.mo

### Compliance with RF Exposure Standards

National and international regulations require manufacturers to comply with the RF energy exposure limits for portable two-way radios before they can be marketed. Your Motorola Solutions twoway radio is designed, manufactured, and tested to comply with all applicable national and international regulations for human exposure to radio frequency electromagnetic energy.

### Information and Operational Instructions for General Population and Uncontrolled Environment Use

following websites:

### **Operating Instructions**

- Transmit no more than 50% of the time. To transmit (talk), press the Push-To-Talk (**PTT**) button. To receive calls, release
- Hold the radio in a vertical position in front of the face with the microphone (and other parts of the radio including the antenna) at least 1 in. (2.5 cm) away from the nose or lips Antenna should be kept away from the eye.
- When worn on the body, always place the radio in a Motorola Solutions-approved clip, holder, holster, case, or body harness for this product.
- DO NOT hold the antenna when the radio is transmitting DO NOT use any portable radio that has a damaged antenna.
- If a damaged antenna comes into contact with your skin, a To ensure continued compliance with applicable RF exposure
- limits, use only Motorola Solutions-approved, supplied or replacement antennas, batteries, and accessories.
- For a list of Motorola Solutions-approved accessories please refer to your user manual or visit <a href="https://www.motorolasolutions.com">www.motorolasolutions.com</a>.

### **Acoustic Safety**

Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the volume of the radio, the sooner your hearing will be affected. Hearing damage from loud noise is sometimes undetectable at first, and can have a cumulative effect.

To protect your hearing, follow these precautions:

- Use the lowest volume necessary to do your job. Turn up the volume only if you are in noisy surroundings Turn down the volume before putting on a headset or
- Limit the amount of time you use a headset or headphones at high volume
- When using the radio without a headset or headphones, do not place the speaker of the radio directly against your ear

#### **Medical Devices**

If you use a personal medical device, such as a pacemaker or hearing aid, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information

#### **Holsters Incorporating Magnets**

Some Motorola Solutions holsters incorporate strong, neodymium magnets. If you use a personal medical device, such as a pacemaker or hearing aid, consult the manufacturer of your device to determine if it can be used in close proximity to magnets. Your physician may be able to assist you in obtaining this information. Also be aware that magnets can damage other products, including cell phones, computers, hard drives, and other electronic devices, as well as credit cards and magnetic media. Keep the holster away from any mechanical device that could be affected by a magnetic field. Consult the manufacturer of your product to determine if your device or product can be used in close proximity to magnets.

#### Operational Warnings

The following explains the operational warnings: For Vehicle With Air Bags

WARNING

installation of electronic equipment to avoid interference with air bag wiring. DO NOT place a portable radio in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable radio is placed in the air bag deployment area and the air bag inflates, the radio may be propelled with great force and cause serious

injury to occupants of the vehicle.


Refer to vehicle manufacturer's manual prior to

#### **Potentially Explosive Atmospheres**

#### Warning:

Use of a radio that is not intrinsically safe in a potentially explosive atmosphere could result in a serious injury, or death. You should only use a certified Intrinsically Safe radio in potentially explosive atmospheres.

Explosive atmospheres refer to hazard



- Turn off your radio prior to entering any area with a potentially explosive atmosphere unless it is a radio type specifically certified for use in
- hazardous location areas.

  DO NOT remove, install, or charge batteries in such areas, or remove or install antennas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Warning: To avoid possible interference with blasting

operations, turn off your radio when you are near

#### **Blasting Caps and Blasting Areas**



WARNING

electrical blasting caps, in a blasting area, or in areas posted: "Turn off two-way radio." Obey all signs and nstructions

- source, such as a hair dryer or microwave oven.

  DO NOT allow conductive material such as jewelry, keys, or
- beaded chains to touch exposed battery terminals
- Do not dispose of batteries with household waste.

### Repair

#### Warning:

Repairs to a Motorola Solutions intrinsically safe radio roduct certified by, for example, FM, UL, CSA, CENELEC, should only be done at a location that has been audited under the certifying body's repair and



Contact Motorola Solutions for assistance regarding epairs and service of Motorola Solutions intrinsical afe equipment

## WARNING

A repair constitutes something done internally to the unit that would bring it back to its original condition. tems not considered as repairs are those in which ar action is performed on a unit which does not require the outer casing of the unit to be opened in a mannel that exposes the internal electrical circuits of the unit.

#### Do Not Substitute Options or Accessories

The Motorola Solutions communications equipment certified as intrinsically safe by the approving agency (FM, UL, CSA, CENELEC) is tested as a complete system which consists of the listed agency approved portable, approved battery, and approved accessories or ontions or both. This approved portable and battery combination. must be strictly observed. There must be no substitution of items, even if the substitute has been previously approved with a different Motorola Solutions communications equipment unit. Approved configurations are listed by the approving agency (FM, UL, CSA,

The Intrinsically Safe Approval Label affixed to radio refers to the intrinsically safe classification of that radio product, and the approved batteries that can be used with that system. The manual PN referenced on the Intrinsically Safe Approval Label identifies the approved accessories and/or options that can be used with that portable radio unit. Using a non-Motorola Solutions-intrinsically safe battery and/or accessory with the Motorola Solutions-approved radio unit will void the intrinsically safe approval of that radio unit.

#### European Union (EU) Waste of Electrical and Electronic Equipment (WEEE) Directive



he European Union's WEFE directive requires that oducts sold into EU countries must have the rossed out trash bin label on the product (or the ackage in some cases). As defined by the WEEE irective, this cross-out trash bin label means that istomers and end-users in EU countries should not ccessories in household waste. Customers or end-users in EU countries should contact their ocal equipment supplier representative or service centre for information about the waste collection stem in their country.

#### **Declaration of Conformity**

Responsible Party

Declaration of Conformity
Per FCC CFR 47 Part 2 Section 2.1077(a)

Name: Motorola Solutions, Inc. Address: 1303 East Algonquin Road, Schaumburg, IL 60196-1078, U.S.A. none Number: 1-800-927-2744 ereby declares that the product lodel Name: T100, T107, T100TP, T100MC, 107MC, T100TMC onforms to the following regulations: FCC Part 15, subpart B, section 15.107(a), 15.107(d), and section 15.109(a)

#### FCC Licensing Information

For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Regrient or relocate the receiving antenna Increase the separation between the equipment and receiver.

  Connect the equipment into an outlet on a circuit different from
- that to which the receiver is connected.

#### **Licensing Information**

#### USA (FCC)/CANADA

According to FCC Part 95, FRS devices do not require a license. Use of Motorola radio in Canada is subject to the rules regulations in ISED RSS 210 and do not require a license.

Changes or modifications not expressly approved by Motorola Solutions may void the user authority granted by the FCC or ISED to operate this radio and should not be made. To comply with FCC or ISED requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services. Replacement of any transmitter component (crystal, semiconductor, etc) not authorized by the FCC or ISED equipment authorization for this radio could violate


Note: Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be

Use of GMRS frequencies is subject to the Rules and Regulations of the Federal Communications Institute (IFT) requires that all operators using GMRS frequencies obtain a permit before operating their equipment. To obtain a permit from the IFT, you must proceed in accordance with Articles 14 and 15 of the Federal Telecommunications Law. Consult your local IFT office for more information: www.ift.org.mx

Uruguay
Use of GMRS frequencies is subject to the Rules and Regulations of the Regulatory Unit Communications Services (URSEC). URSEC requires that all operators using GMRS frequencies obtain a permit before operating their equipment. The authorization shall depend on the channel availability at the time the authorization is requested. To obtain a permit from URSEC, consult your local URSEC office for mation: www.ursec.gub.uy

Panama and Paraguay
The Republic of Panama and Paraguay do not require authorization to use FRS/GMRS radio equipment frequencies.

#### Talking and Listening



- Tx is shown.
  When you are finished talking, release the PTT button.

3. When receiving, the  $\mathbf{R}\mathbf{x}$  is shown. For maximum clarity, hold the radio 1 in. away from your mouth and speak directly into the microphone. Do not cover the microphone

#### Talk Range

Volume

Battery (2

Battery Levels)

Status (transmit/

Your radio is designed to maximize performance and improve transmission range. Do not use the radios closer than 5 ft apart.

#### **Push-to-Talk Timeout Timer**

To prevent accidental transmissions and save battery life, the radio emits a continuous warning tone and stops transmitting if you press the **PTT** button for 60 s continuously.

#### **Channel Scan Mode**

Channel Scan Mode enables your radio to scan for active channels. When activity is detected, your radio lands (stays) on that channel (for two seconds). To transmit on that channel, press the PTT button When activity on the landed channel ends, your radio continues scanning other channels. To turn the channel scan ON:

- Press MENU/() two times until Z appears
- Press / lato start scanning. Press MENU/ or PTT to turn

#### **Key Lock**

- Press and hold 🎝 🖺 until 🚨 appears to lock the keypad. When in lock mode, you can turn the radio on and off, adjust the volume, send a call tone, receive, and transmit. All other functions are locked.
- Press and hold I / $\blacksquare$ , until  $\blacksquare$  disappears to unlock the

#### **Monitor Mode**

Your radio enables you to listen for weak signals on the current To turn the Monitor Mode ON:

- Press MENU/ three times until the Channel Monitor setting
- flashes and the Rx appears. Press the J/ A button for continuous listening. The Rx icon continues to appears.
  To turn the Monitor Mode OFF:
- Press the MENU/ button to return to "Normal" mode. The

Roger beep sounds to indicate the end of a PTT transmission. It can be heard through the speaker when Key Beep is on. It cannot be heard through the speaker if Key Beep is turned off

Press and hold the + button while turning the radio ON to turn the Roger Beep ON. Repeat the step to turn Roger Beep OFF.

For better battery life, your radio is designed to switch to Power Save mode when there has been no transmissions after 3 s. The radio can receive transmissions in this mode.

### **Channels and Frequencies** USA, Canada, Mexico, Panama, Paraguay, Uruguay Max Power

Channel	Frequency	Output	Channel	Frequency	Output
1	462.5625 MHz	2 W	12	467.6625 MHz	0.5 W
2	462.5875 MHz	2 W	13	467.6875 MHz	0.5 W
3	462.6125 MHz	2 W	14	467.7125 MHz	0.5 W
4	462.6375 MHz	2 W	15	462.5500 MHz	2 W
5	462.6625 MHz	2 W	16	462.5750 MHz	2 W
6	462.6875 MHz	2 W	17	462.6000 MHz	2 W
7	462.7125 MHz	2 W	18	462.6250 MHz	2 W
8	467.5625 MHz	0.5 W	19	462.6500 MHz	2 W
9	467.5875 MHz	0.5 W	20	462.6750 MHz	2 W
10	467.6125 MHz	0.5 W	21	462.7000 MHz	2 W
11	467.6375 MHz	0.5 W	22	462.7250 MHz	2 W

#### **Patent and Copyright Information**

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are ty of their respective owners © 2016 and 2019 Motorola Solutions, Inc. All rights reserved.

#### Warrantv

Consumer Two-Way Radio Products and Accessories purchased in the USA, Canada, Mexico, Uruguay, Panama, and Paraguay

### What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola Solutions, Inc. ("Motorola") warrants the Motorola Solutions branded consumer two-way radios that operate through Family Radio Service or General Mobile Radio Service ("Products"), the Motorola Solutions branded or certified accessories sold for use with these Products ("Accessories") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is the exclusive remedy of a consumer, and applies as wallarly is the exclusive terrieur of a consumer, and applies as follows to new Products and Accessories and purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

#### Who is Covered?

This warranty extends only to the first consumer purchaser, and is

#### What will MOTOROLA SOLUTIONS, INC. do?

Motorola Solutions, Inc., at its option, will at no charge repair, replace or refund the purchase price of any Products or Accessories that do not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products or

#### What Other Limitations Are There?

Any Implied Warranties, Including Without Limitation
The implied warranties of merchantability and fitness for a particular
purpose, shall be limited to the duration of this limited warranty, otherwise the repair, replacement, or refund as provided under this express limited warranty is the exclusive remedy of the consumers, and is provided in lieu of all other warranties, express or implied. In no event shall Motorola Solutions be liable, whether in contract or tort (including negligence) for damages in excess of the purchase price of the product or accessory, or for any indirect, incidental, special or consequential damages of any kind, or loss of revenue or profits, loss of business, loss of information or other financial loss arising out of or in connection with the ability or inability to use the products or accessories to the full extent these damages may be disclaimed by

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one iurisdiction to another

Length Of Coverage

#### **USA** and Canada Products Covered

Products and Accessories as defined above, unless otherwise provided for below.	<b>Two (2) years</b> from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Products and Accessories that are repaired or replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

#### Latin America

Products Covered	Length Of Coverage
as defined above, unless otherwise provided for	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
	The balance of the original

#### **Products and Accessories** warranty or for ninety (90) days hat are repaired or replaced from the date returned to the consumer, whichever is longer

## **Exclusions From Warranty Coverage**

## Normal Wear and Tear: Periodic maintenance, repair, and replacement of products or

accessories due to normal wear and tear

#### Abuse and Misuse:

Defects or damage that result from: (a) improper operation, storage misuse or abuse, accident, or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the Products and Accessories resulting from misuse; (b) contact with liquid, water rain, extreme humidity or heavy perspiration, sand, dirt, or the like extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola Solutions.

#### Use of Non-Motorola Solutions branded Products and Accessories:

Defects or damage that result from the use of Non-Motorola Solutions branded or certified products, accessories, software, or other peripheral equipment

#### Unauthorized Service or Modification:

Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola Solutions, or its authorized service

### Altered Products:

Products or Accessories with (a) serial numbers or date tags that have been removed, altered, or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) non-conforming or non-Motorola Solutions branded housings; or parts.

## Communication Services: Defects, damages, or the failure of Products or Accessories due to

any communication service or signal you may subscribe to or use with the Products or Accessories How to Obtain Warranty Service or Other Information?

## To obtain customer service or information

#### 1-800-448-6686. www.motorolasolutions.com/talkabout E-mail us at consumerradio@motorolasolutions.com

**USA** and Canada

Latin America Toll free: Mexico 001-855-241-8253 Panama 001-800-507-3589

## Toll or long distance: Spanish +001-312-725-5372

English +001-312-725-5368 Paraguay +595 61 548 1000

Uruguay 598 – 24001716

www.motorolasolutions.com/talkabout/es (Spanish)

Replace the battery compartment door. RF Energy Exposure Awareness and Control Batteries Consult the dealer or an experienced radio/TV technician for **Battery Level and Low Battery Alert** Rx icon stops appearing. Charge your battery using the approved Motorola Solutions This icon will show when battery is low and will blink Roger Beep Notice to Users (FCC and Industry Canada) when battery is extremely low. Replace the batteries Use the battery in accordance with its water and/or dust For more information on what RF energy exposure is, see the This device complies with Part 15 of the FCC rules and Industry immediately Ingress Protection (IP) rating. DO NOT discard your battery into a fire Canada's license-exempt RSS's per the following conditions Removing the Alkaline Batteries https://www.fcc.gov/
 http://www.who.int/peh-emf/project/en/
For additional information, see https://www.motorolasolutions.com/ Do not replace the battery in any area labeled "Hazardous This device may not cause harmful interference. Turn the radio off. This device must accept any interference received, including Atmosphere" With the back of the radio facing you, lift the battery cover latch DO NOT disassemble, crush, puncture, shred, or otherwise interference that may cause undesired operation. up and remove the cover. **Automatic Power Save** npt to change the form of your battery. Changes or modifications made to this device, not expressly approved by Motorola Solutions, could void the authority of the Gently remove each alkaline battery. DO NOT dry a wet or damp battery with an appliance or heat Close the battery cover firmly. user to operate this equipment. Note:

## **Getting Started**

**Control Buttons** 

②.⊕

**Display Screen Guide** 

Tx

Rx

TxRx -

#### Installing the Batteries

─ Scan

Keypad Lock

Push-to-Talk

Speaker\_

Call Tone/ Lock

Make sure your radio is OFF. To remove the battery compartment door, by pressing the tab at the bottom of the compartment door. Remove the door. Insert three AAA batteries into the battery compartment

Exercise care when removing AAA batteries. Do not use sharp or conductive tools to remove either of these batteries. Remove the batteries before storing your radio for extended periods of time. Batteries corrode over time and may cause

#### permanent damage to your radio. Attaching and Removing the Belt Clip

Attach the belt clip to the back of the radio until the clip clicks in

Attach the belt clip to pocket or belt strap until the clip clicks in

#### place. To Remove

Pull the release tab on top of the belt clip to release the latch. Push the belt clip with the other hand towards the top of radio

**Basic Radio Operations** 

#### Read this reference guide completely before attempting to operate the unit

Turning Your Radio On/Off Press and hold the MENU/(I) button to turn your radio ON/OFF.

#### Adjusting the Volume

Selecting a Channel

Adjust the volume by pressing the (+) and (-) buttons. When the volume reached level 0, the mute icon ■x appears permanently on screen

## Adjusting the Sound (Key Beeps) Your radio emits a beep each time one of the buttons is pressed (except the PTT button).

Press and hold the — button while turning the radio ON to switch the sound OFF To turn this sound ON, turn the radio OFF and ON again without pressing the 

button.

In order to speak to someone, both your radios must be set to the

#### To select a channel

Press **MENU**/() one time to enter Menu. Press (+) or (-) to the required channel. An extended press of  $\widehat{\phantom{a}}$  or  $\widehat{\phantom{a}}$  allows you to scroll through the channel

Press PTT button to confirm the selection or MENU/ () to

For Accessories:
Please call the telephone number designated above for the Product with which they are used.

You will receive instructions on how to ship the Products or Accessories at your expense, to Motorola Solutions or a Motorola Solutions Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

## For more information, please visit us at:



https://www.facebook.com/ MotorolaTalkaboutWalkieTalkies





www.motorolasolutions.com/talkabout



www.motorolasolutions.com/talkabout/es (Spanish)