



1. Power On/Off
2. USB Port: Mini USB Port for DC 5V charging
3. LINE\_IN: 3.5 mm stereo jack. Can be connect with Audio output device directly.
4. Power/Bluetooth indicator:
  - 4.1. Red light indicator for charging:
    - No charge: Red light is on all the time
    - Charging: Red light is On for 1 second and Off for 3 seconds
    - Charging Complete: Red light is on all the time
    - Low power state: Red light is On for 0.2 second and Off for 0.2 second.
  - 4.2. Blue light indicator for bluetooth:
    - Waiting for being searched: if unconnected, Blue light will be On for 1 second and Off for 1 second. Connecting successfully: Blue light will be On all the time.
5. VOL +
6. VOL -
7. PREVIOUS: Bluetooth Mode for Songs, FM Mode for Channel
8. NEXT: Bluetooth Mode for Songs, FM Mode for Channel
9. Function Key:
  - Short Press: Play/Pause
  - Long Press: Swichover among Bluetooth / FM / LINE\_IN
10. MIC: Built-in microphone

Instruction for Bluetooth Function: After Power On, it will connect automatically with the Bluetooth device which has been matched last time. If no the device be found, it will enter a status of waiting for being searched.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## Bluetooth Speaker



KB304

**KOHO**

KOHO KB304 Bluetooth Speaker

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.