


Settings

- Preselector = OFF
- Scan Type = Swept
- Number of Scans = 1
- Y Axis Unit = dBm
- Ref Level Offset = 0.00 dB
- Coupling = AC
- Input Z Correction = 50 ohm

Screen Image



Scan Table

	Start Frequency	Stop Frequency	RBW	Dwell Time	Step Size	Auto Rules	Atten	Auto range	Int Preamp	Auto Preamp	RF Input
1	1.000000000 GHz	3.600000000 GHz	1 MHz	1.00 us	500.000 kHz	2 Pts/RBW	10 dB	OFF	Low	OFF	Input1

## Final Measurement

- Autorange = OFF
- Auto Preamp = OFF
- Amplitude Unit = dBm

Final Det	Det Type	Dwell Time	Limit Line
1	Peak	200 ms	1
2	QuasiPeak	1.00 s	1
3	EmiAverage	1.00 s	1

## Signal List

Sig	Trc	Freq	PEAK Amptd	QPD Amptd	EAVG Amptd	PEAK vs LL1	QPD vs LL1	EAVG vs LL1	RBW	RBW Type	Time Stamp	Comment
1	1	1.0750 GHz	-63.854 dBm	---	---	---	---	---	1.00 MHz	CISPR	2015/01/31 12:26:08	
2	1	1.3030 GHz	-82.038 dBm	---	---	---	---	---	1.00 MHz	CISPR	2015/01/31 12:25:53	
3	1	1.5500 GHz	-42.425 dBm	---	---	---	---	---	1.00 MHz	CISPR	2015/01/31 12:26:23	
4	1	2.1940 GHz	-36.026 dBm	---	---	---	---	---	1.00 MHz	CISPR	2015/01/31 12:27:08	
5	1	3.5590 GHz	-33.936 dBm	---	---	---	---	---	1.00 MHz	CISPR	2015/01/31 12:27:30	