

ENGLISH

THANK YOU.....	2
ABOUT YOUR JABRA BT8040	2
WHAT YOUR HEADSET CAN DO	3
GETTING STARTED	4
WEAR IT HOW YOU LIKE IT	6
HOW TO	6
WHAT THE LIGHTS MEAN	8
LISTENING TO MUSIC USING JABRA BT8040	9
USING JABRA BT8040 WITH 2 MOBILE PHONES.....	9
USING A JABRA BLUETOOTH HUB.....	9
TROUBLESHOOTING & FAQ.....	10
NEED MORE HELP?.....	12
TAKING CARE OF YOUR HEADSET	12
WARNING!	12
WARRANTY	13
CERTIFICATION AND SAFETY APPROVALS.....	15
GLOSSARY	17

THANK YOU

Thank you for purchasing the Jabra BT8040 Bluetooth® headset. We hope you enjoy using it! This instruction manual will get you up and running to make the most of your headset.

ABOUT YOUR JABRA BT8040


1 Volume up, volume down

2 Charging socket

3 Answer/end button

Press and hold to turn headset on and off

• Tap to answer or end a call



WHAT YOUR HEADSET CAN DO

Your Jabra BT8040 lets you perform all of this:

- Answer calls
- End calls
- Reject calls*
- Voice dialing*
- Last number redialing*
- Call waiting*
- Put call on hold*
- Mute
- Multi-point - connected to two Bluetooth devices at the same time
- Play music*

Specifications

- Talk time up to 6 hours/standby time up to 200 hours
- Rechargeable battery with a charging option from an AC power supply, a PC via USB cable, or a car charger (not included)
- Multi-colored light for status and battery indicator
- Quiet mode – turns light off after 1 minute
- Size: L 39 mm x W 18mm x D 12 mm
- (Weight) 10 grams

Digital sound enhancement via DSP technology

- Noise reduction for transmitting and receiving audio
- Noise dependent volume control*
- Automatic volume adjustment for receiving audio
- Acoustic shock protection
- Qualified for Bluetooth Specification version 2.0 + EDR (enhanced data rate), supporting Headset and Hands-free Profiles for phone conversations and Advanced Audio Distribution Profile (A2DP) for streaming music
- e-SCO for enhanced audio quality
- 128 bit encryption
- Operating range up to 10 meters (approx. 33 feet)

GETTING STARTED

The Jabra BT8040 is easy to operate. The answer/end button on the headset performs various functions depending on how long you press the button down.

Instruction	Duration of press
Tap	Press briefly
Double tap	2 quickly repeated taps
Press	Approx: 1 seconds
Press and hold	Approx: More than 3 seconds

1. Charge your headset

Ensure that your Jabra BT8040 headset is fully charged before you start using it. Use the AC adaptor to charge the headset from a power socket, or charge directly from your PC with the USB cable that was provided. Your headset indicates the charging level while charging:

What you see	Charge level
Solid red	Less than 70%
Solid yellow	Between 70% and fully charged
Solid green	Fully charged

Please note: The lifetime of the battery will be significantly reduced if your device is left uncharged for an extended period. We therefore recommend that you recharge your device at least once a month.

Turning your headset on and off

- Press and hold the answer/end button to turn on your headset. The LED will show the battery level status to indicate that the Jabra BT8040 is on.
- Press and hold the answer/end button until you see a burst of red flashes in order to turn your headset off.

Pair it with your phone

Before you use your Jabra BT8040, you will need to pair it with your mobile phone.

1. Your headset will automatically go into pairing mode when you turn it on the first time.
2. Set your Bluetooth phone to 'discover' the Jabra BT8040.

Follow your phone's instructions. This usually involves going to a 'setup', 'connect', or 'Bluetooth' menu on your phone and selecting the option to 'discover' or 'add' a Bluetooth device.*



3. Your phone will find the Jabra BT8040.

Your phone then asks you if you want to pair with it. Accept this by pressing 'Yes' or 'OK' on the phone and confirm with the passkey or PIN = 0000 (4 zeros). Your phone will confirm when the pairing is complete.

In the case of an unsuccessful pairing, repeat steps 1 to 3.

Manual pairing

You can manually put your Jabra BT8040 into pairing mode, if you want to pair with a second phone or Bluetooth device:

1. Ensure that the headset is off.
2. Press and hold the answer/end button for approx. 5 sec. until the light turns solid Blue.
3. Set your Bluetooth phone to discover your headset as described above.

WEAR IT HOW YOU LIKE IT

The Jabra BT8040 is ready to be worn. The ear gels can be used for both left and right wearing. The BT8040 comes with a medium sized ear-gel, but it can be replaced by a small or large one. You can also twist the ear gel slightly to optimize the fit and comfort. For optimal performance, wear the Jabra BT8040 and your mobile phone on the same side of your body or within your line of sight. In general, you will get better performance when there are no obstructions between your headset and your mobile phone.

HOW TO

Answer a call

- Tap the answer/end button on your headset to answer a call.

End a call

- Tap the answer/end button to end an active call.

Make a call

- When you make a call from your mobile phone, the call will (subject to phone settings) automatically transfer to your headset. If your phone does not have this feature, tap on the Jabra BT8040's answer/end button to transfer the call with the headset.

Reject a call*

- Press the answer/end button when the phone rings to reject an incoming call. Depending on your phone settings, the person who called you will either be forwarded to your voice mail or you will hear a busy signal.

Activate voice dialing*

- Press the answer/end button. For best results, record the voice-dialing tag through your headset. Please consult your phone's user manual for more information about using this feature.

Redial the last number*

- Double tap the answer/end button when the headset is on and not being used.

Adjust the sound and volume*

- Tap the volume up or down to adjust the volume.

Mute on/Mute off

- To mute, press the volume up and down at the same time. A low beep alert plays during a muted call.
- To turn the mute off, tap either of the volume buttons.

Call waiting and placing a call on hold*

This allows you to put a call on hold during a conversation and answer an incoming call.

- Press the answer/end button once to put the active call on hold and then answer the incoming call.
- Press the answer/end button to switch between the two calls.
- Tap the answer/end button to end the active conversation.

Battery Indicator

When the Jabra BT8040 is turned on or a button is pressed more than 1 minute after the last button was pressed, the LED indicates the battery level of the headset.

What you see	Battery level/Talk time
2 Green flashes	1-5 hours talk time
2 Yellow flashes	10 min.-1 hour
2 Red flash	10 min.

WHAT THE LIGHTS MEAN

Series of flashes	See battery indicator
Flashing blue and green light	Incoming call
Flashing blue light	Flashing every three seconds: In Standby mode and connected to mobile phone (only for 1 minute then off)
Flashing green light	Flashing every three seconds: In standby mode – not connected (only for 1 minute then off)
Flashing blue light	Flashing every second: active call (only for 30 seconds then off)
Flashing red light	Running low on battery
Flashing purple light	Flashing every seconds: Connected in A2DP streaming music (only for 30 seconds then off)
Solid blue light	In pairing mode
Solid purple light	Special music pairing mode See chapter Troubleshooting & FAQ - Frequently Asked Questions
Solid green light	Fully charged
Solid yellow light	Charging level between 70% and fully charged
Solid red light	Charging level less than 70%

LISTENING TO MUSIC USING JABRA BT8040

Jabra BT8040 is capable of streaming music over Bluetooth - either from a mobile phone or any other Bluetooth device supporting A2DP. Once you have paired your BT8040 with your mobile phone or to the Bluetooth music player, use your phone or music player to play, pause, stop, skip forward, or backward. When you receive a call, the music will be automatically suspended and you will be able to answer or reject a call through the headset. Once you end a call, the music should restart. On some phones and music devices you may have to press 'play' to restart the music.

USING JABRA BT8040 WITH 2 MOBILE PHONES

Jabra BT8040 is capable of having two mobile phones (or Bluetooth devices) connected to the headset at the same time. This will give you the freedom of having only one headset to operate both of your mobile phones. Please note that Last Number Redial will dial the number from the last outgoing call, independent of the mobile phones, and the Voice Dialing function will only work on the last paired mobile phone.

USING A JABRA BLUETOOTH HUB

The Jabra BT8040 can be used along with the Jabra Bluetooth Hub (sold separately). This will enable you to use the headset with your mobile and office phones.

To pair the Jabra BT8040 with the Jabra Bluetooth Hub

The pairing process is a little different:

1. Put your Jabra BT8040 in pairing mode.
2. Put the Jabra Bluetooth Hub in pairing mode.
3. Place them close together. You do not need a dedicated pin code to pair the two Jabra products. Consult the Jabra Bluetooth Hub user manual for more information on how to connect the Bluetooth hub to your office phone.

The use of the Jabra BT8040 with the Jabra Bluetooth Hub is very similar to using the headset with a mobile phone only. The only difference is in the transfer of a call to the headset from the office phone.

Transfer the call to the headset

- Tap the answer/end button to transfer the call from the office phone to the headset via the Jabra Bluetooth Hub

The answering of a call from the office phone requires a hook lifter in order to have the Jabra BT8040 answer the call automatically.

TROUBLESHOOTING & FAQ

I hear crackling noises

- Bluetooth is a radio technology, which means it is sensitive to objects between the headset and the connected device. It is designed for the headset and the connected device to be used within 33 feet (10 meters) of each other, with no major objects in the way (walls, etc.).

I cannot hear anything in my headset

- Increase the volume in the headset
- Ensure that the headset is paired to a device that is playing
- Make sure your phone is connected to the headset by tapping the Answer/End button.

I am having pairing problems

- You may have deleted your headset pairing connection in your mobile phone.

Follow the pairing instructions.

I want to reset the headset

It is possible to reset and test the headset by 'Pressing and holding' all three buttons at the same time. The red, blue, and green lights will light up in a white light. In this mode, the pairing list is reset, and you can test if the headset works, as you will be able to hear audio in the speaker from the microphone.

The headset will automatically turn off after approx. 10 seconds. The next time you power on, the headset will go into pairing mode just like the first time you powered on your new BT8040.

Will the Jabra BT8040 work with other Bluetooth equipment?

- The Jabra BT8040 is designed to work with Bluetooth mobile phones. It can also work with other Bluetooth devices that are compliant with Bluetooth version 1.1 or higher and that support a headset, hands-free, and/or advance audio distribution profile.

I cannot use reject call, call on hold, redial, or voice dialing

These features are dependent on the ability of your phone to support a hands-free profile. Even if the hands-free profile is implemented, the reject call, call hold, or voice dialing are all optional features that are not supported by all devices. Please consult your device manual for further details.

Please note that some features can only be operated from the primary device e.g. voice dial using Jabra BT8040 with 2 mobile phones.

The device does not connect to my headset in time to answer an incoming call

If the headset is off and is turned on when a call is incoming, the device and headset might not connect in time for the call to be answered. In order to avoid such inconveniences please keep the headset on, in range, and connected.

The music player starts playing when connecting to the headset

Some phones may start the music player once it connects to the headset. Pair your headset again to the device in order to avoid this behavior.

1. Ensure that the headset is off
2. Press and hold the answer/end button for approx. 5 sec. until the light turns to solid blue
3. Continue to press and hold the answer/end button until the solid blue light turns off
4. Continue to press and hold until a solid purple light turns on

Go through the regular steps in pairing the headset to a Bluetooth device.

The music stream from my connected device is choppy or the music pitch is changing

If you have connected two devices and move out of range of one device while playing music from the connected device, the headset will try to reconnect to the lost device. This can cause the audio stream to be disrupted. For example, the music audio is choppy or the audio pitch varies. In order to prevent this, do not go out of range of your paired/connected devices.

NEED MORE HELP?

1. Web: www.jabra.com
(for the latest support info and online user manuals)
2. E-mail: Tech Support: techsupp@jabra.com
Information: info@jabra.com
3. Phone: 1 (800) 327-2230 (toll-free in USA)
(603) 579-5311 (Canada)

TAKING CARE OF YOUR HEADSET

- Always store the Jabra BT8030 with the power off and safely protected.
- Avoid storage at extreme temperatures (above 45°C/113°F – including direct sunlight – or below -10°C/14°F). This can shorten the battery life and may affect its operation. High temperatures may also degrade performance.
- Do not expose the Jabra BT8030 to rain or other liquids.

WARNING!

Headsets are capable of delivering sounds at loud volumes and high pitched tones. Exposure to such sounds can result in permanent hearing loss. The volume level may vary based on conditions, such as the phone that you are using, its reception and volume settings, and the surrounding environment. Please read the safety guidelines below before using this headset.

Safety guidelines

1. Prior to using this product follow these steps

- before putting on the headset, turn the volume control to its lowest level,
- put the headset on, and then
- slowly adjust the volume control to a comfortable level.

2. During the use of this product

- Keep the volume at the lowest level possible and avoid using the headset in noisy environments where you may be inclined to turn the volume up;
- If increasing the volume is necessary, adjust the volume control slowly;

And

- If you experience discomfort or ringing in your ears, immediately discontinue using the headset and consult a physician.

With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

Using the headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions. Check your local laws. Use caution when using your headset while engaging in any activity that requires your full attention. While engaging in any such activity, remove the headset from your ear area or turn your headset off in order to keep you from being distracted so as to avoid an accident or injury.

3. Keep out of reach of children

The plastic bags that the product and its parts are wrapped in are not toys for children. The bags themselves or the many small parts that they contain may cause choking if ingested. Never try to take the product apart yourself. None of the internal components can be replaced or repaired by users.

Only authorized dealers or service centers are permitted to open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.

Avoid exposing the product to rain or other liquids.

4. ACA TS028 – Ignition of flammable substances

Do not use the Headset in environments where danger of ignition of flammable gases is present.

WARRANTY

Service and Warranty Information

Limited One (1) -Year Warranty GN US Inc., warrants this product to be free from defects in materials and workmanship (subject to the terms set forth below) for a period of one (1) year from the date of purchase (“Warrenty Period”). During the Warranty Period, GN will repair or replace (at GN’s discretion) this product or any defective parts (“Warrenty Service”). If repair or replacement is not commercially practicable or cannot be timely made, GN may choose to refund to you the purchase price paid for the affected product. Repair or replacement under the terms of this warranty

does not give right to any extension or a new beginning of the period of warranty.

Claims under the Warranty

To obtain Warranty Service, please contact the GN dealer from which you purchased this product or visit www.jabra.com for further information about customer support. You will need to return this Product to the dealer or ship it to the dealer or to GN (if so indicated on www.jabra.com) in either its original packaging or packaging affording an equal degree of protection. You will bear the cost of shipping the product to GN. If the Product is covered by the warranty, GN will bear the cost of shipping product back to you after the completion of service under this warranty. Return shipping will be charged to you for products not covered by the warranty or requiring no warranty repair.

The Following information must be presented to obtain Warranty Service: (a) the product, and (b) proof of purchase, which clearly indicates the name and address of the seller, the date of purchase and the product type, which is evidence that this product is within the Warranty Period. Please further include (c) your return address. (d) daytime telephone number, and (e) reason for return. As part of GN/Jabra's efforts to reduce environmental waste you understand that the product may consist of reconditioned equipment that contains used components, some of which have been reworked. The used components all live up to GN/Jabra's high quality standards and comply with the GN product performance and reliability specifications. You understand that replaced parts or components will become the property of GN.

Limitation of Warranty

This warranty is only valid for the original purchaser and will automatically terminate prior to expiration if this product is sold or otherwise transferred to another party. The warranty provided by GN in this statement applies only to products purchased for use, and not for resale. It does not apply to open box purchases, which are sold "as is" and without any warranty. Specifically exempt from warranty are limited-life consumable components subject to normal wear and tear, such as microphone windscreens, ear cushions, modular plugs, ear tips, decorative finishes, batteries, and other accessories. This warranty is invalid if the factory-applied serial number, date code label, or product label has been altered or removed from this product. This Warranty does not cover cosmetic damage or damage due to misuse, abuse, negligence, Acts of Nature, accident, disassembling or modification of, or to any part

of, the product. This Warranty does not cover damage due to improper operation, maintenance or installation, or attempted repair by anyone other than GN or a GN dealer which is authorized to do GN warranty work. Any unauthorized repairs will void this
REPAIRS OR REPLACEMENTS AS PROVIDED UNDER THIS WARRANTY ARE THE EXCLUSIVE REMEDY OF THE CONSUMER. GN SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES WHATSOEVER, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PRACTICAL PURPOSE.

NOTE! This warranty gives you specific legal rights. You may have other rights which vary from location to location. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or implied warranties, so the above exclusions may not apply to you. This warranty does not affect your legal (statutory) rights under your applicable national or local laws.

CERTIFICATION AND SAFETY APPROVALS

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by Jabra (GN US Inc.) will void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not

occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device and its antenna must not be co-loaded or operating in conjunction with any other antenna or transmitter.

Industry Canada

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC:" before the certification/registration number only signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

CE

This product is CE marked according to the provisions of the R & TTE Directive (99/5/EC).

Hereby, GN A/S, declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

For further information please consult <http://www.jabra.com>

Bluetooth

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Jabra is under license. Other trademarks and trade names are those of their respective owners.

GLOSSARY

- 1. Bluetooth** is a radio technology that connects devices, such as mobile phones and headsets, without wires or cords over a short distance (approx. 30 feet). Obtain more information at www.bluetooth.com.
- 2. Bluetooth profiles** are the different ways that Bluetooth devices communicate with other devices. Bluetooth phones support either the headset profile, the hands-free profile, or both. In order to support a certain profile, a phone manufacturer must implement certain mandatory features within the phone's software.
- 3. Pairing creates** a unique and encrypted link between two Bluetooth devices and lets them communicate with each other. Bluetooth devices will not work if the devices have not been paired.
- 4. A Passkey or PIN** is a code that you enter on your mobile phone to pair it with your Jabra BT8030. This makes your phone and the Jabra BT8030 recognize each other and automatically work together.
- 5. The Standby mode** is when the Jabra BT8030 is passively waiting for a call. When you 'end' a call on your mobile phone, the headset goes into standby mode.



Dispose of the product according to local standards and regulations.

www.jabra.com/weee