


# INSTRUCTIONS FOR OPERATION

## SETTING THE OPERATING CONTROLS

1. This unit operates on a 3 volts battery (not included).  
To prevent possible damage if the battery should leak , be sure to remove the battery when the unit is not use .
2. Store the controller away from excess heat or humidity .
3. This remote control unit is required with 24bit code combinations. To prevent possible interference from or to other remote units such as garage door openers, car alarm or security system .
4. Operation buttons on the panel of transmitter .



**FAN SPEED button – fan speed(speed 1~6)  
( 6 ~1)**

**REV button – Fan reverse Warm weather/Cool  
weather**

**LIGHT button - Light ON/OFF or Dimmer**

**FAN OFF button - FAN OFF**



**CONTROL SWITCH – For light brightness and  
ON/OFF control .**

5. **Start the fan**  
Press the **FAN speed button** .
6. **Turn off the fan :**  
Press the **OFF button** .
7. **Light control :**  
Turn the light on or off by only touching the **LIGHT CONTROL button** .  
Keep pressing the button in excess of **0.7 second** it becomes a dimmer ,  
the light varies cyclically in **0.8 second** .

#### **GENERAL INFORMATION :**

**This REMOTE controller is designed to separately control your ceiling fan speed and light brightness . The Light ON/OFF button will control the light brightness ON/OFF . The LED indicator on the transmitter will light when the Function button is pressed .**

#### **INSTRUCTIONS FOR INSTALLATION AND OPERATION OF FAN SPEED CONTROLLER**

##### **1. Setting the code on your new transmitter .**

**Within 60 seconds of turning the AC power on, press and hold the FAN ON/OFF button for 5 seconds. The receiver will then lock in the chosen frequency. If your fan has a light it will blink twice, for fans without lights check operation using the transmitter**

##### **NOTICE :**

**The changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment .**

**IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.**

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause**