


Connecting Video

There are two types of video signal which can be used with the TTX81X.

The "RF In" jack will accept a VHF/UHF signal such as you would obtain from either a cable outlet or a rooftop antenna for local broadcast. A threaded (type F) jack is used on the "North American" model (TTX815); an IEC aerial jack is used on the "European" model (TTX816). If you have an RF signal, connect it as shown below. If it is the threaded type, tighten it fully using your fingers.

The "Video In" jack will accept a composite video signal such as you would obtain from the "video out" jack of a satellite receiver, component tuner or VCR. This jack is a reliable BNC type; if your video signal source uses another type of jack (for example, phono), you will need an adaptor to connect it to the TTX81X. If you have a video signal, connect it as shown below.



You are now ready to install and use your application software. To proceed, refer to the manual supplied with the software.

norpak corporation
Telephone: 613-592-4164.
Fax: 613-592-6560
web: <http://www.norpak.ca>

norpak corporation

TTX81X TV Data Receiver Installation Guide

Introduction

This guide describes how to install the TTX81X TV Data Receiver in your computer, how to connect the video signal to it, and how to check that it operates properly in your computer.

Once you have completed these steps, you will be ready to install application software to work with the TTX81X.

Please follow these steps carefully, to ensure a successful installation.

Information to User

The following warning is provided in compliance with the regulations of the United States Federal Communications Commission (FCC):

This device complies with part 15 of the FCC Rules, and operates under the following two conditions: (1) This device may not accept harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Norpak Corporation could void the user's authority to operate the equipment.