

IMPORTANT SAFETY AND PRODUCT INFORMATION (ENGLISH)

By using this product, you acknowledge that you have read and agree to our Terms of Use (gopro.com/ terms) and Privacy Policy (gopro.com/legal/privacy-policy). For more detailed information about camera features and settings, download the user manual online at opro.com/helo.



This symbol identifies a potential hazard which, if not avoided, could result in death, serious injury or property damage. Read this guide for important safety and health information for the product that you purchased.



WARNING: Failure to properly set up, use, and care for this product can increase the risk of serious injury, death, property damage, or damage to the product or related accessories. Exercise caution when using your GoPro MAX as part of your active lifestyle. Always be aware of your surroundings to avoid injury to yourself and others.

- 1. Read these instructions.
- 2. Keep these instructions
- 3. Heed all warnings.
- Follow all instructions.
- 5. Clean only with a dry cloth.
- 6. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where it exits from the apparatus.
- 9. Only use attachments and accessories specified and provided by the manufacturer for MAX.
- 10. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 11. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normaliv, or has been drooped.

CAMERA SAFETY



WARNING: Failure to take the following precautions can result in serious injury or death from electric shock, fire, or damage to your GoPro MAX:

Inspect your camera and accessories before use to ensure they are not damaged
and are assembled according to GoPro's instructions. For safety purposes, use only
genuine GoPro supplied or purchased parts with your MAX. The use of any other
component, accessory, or charger that is not recommended by GoPro may cause
fire, electric shock, or injury. Your warranty does not cover damage caused by use of
unauthorized attachments. For approved accessories, visit appro.com.

- Do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate or paint the camera, battery or powered accessories.
- · Do not insert foreign objects into any opening on the camera, such as the USB port.
- Do not use the camera if it has been damaged—for example, if cracked, punctured or harmed by water.
- Do not dry the camera or battery with an external heat source such as a microwave oven or hair dryer.
- · Do not place naked flame sources, such as lighted candles, on or near the product.
- Your GoPro camera mounting fingers may become warm from prolonged use. Turn
 off your camera and simply let it sit and cool before attempting to hold the camera by
 the mounting fingers.

When charging the camera, do not handle the plug or charger with wet hands. Failure to observe this warning could result in electric shock.

Using a wall charger other than a GoPro wall charger can damage the GoPro camera battery and could result in fire or leakage.

Camera will not float. Do not get the battery wet. Failure to observe this precaution could result in fire or electric shock. Do not submerge MAX in liquid if the battery door is open. Damage to the camera or battery caused by contact with liquid is not covered under the warranty.

Use only in low-velocity or stationary settings. The Curved Fusion Mount is not recommended for helmet mounting. To mount MAX on a helmet, use the Curved Adhesive Mount and Mounting Buckle. These items are available in the Grab Bag, sold separately at gopro.com. Only mount the product where it will not interfere with vehicle or equipment operation. Do not mount your MAX in a high vibration setting in cold weather conditions (for example, on top of skis or snowboard). Do not wear MAX if this will interfere with the use of required equipment. Do not wear this product where it will come into contact with other objects. Failure to observe this warning could result in accidents or other injury.

Do not place the product on, or attach it to, unstable surfaces. Failure to observe this precaution could result in the product coming loose or falling over, causing accidents or other injury.

If using the external power connection, follow all safety guidelines for the third-party power device.

Your GoPro camera lens is glass. Should the lens break, care should be taken to avoid injury due to broken glass. Keep out of reach of children. Contact GoPro Customer Support.

The temperature of your camera may become warm during operation, which is a normal condition during use. In such circumstances, disconnect the battery or power source and let it sit and cool before attempting to use it again. Continued operation could result in fire, burns or other injury.

This product is not a toy. It is solely your responsibility to comply with all local laws, regulations, and restrictions. Should a child swallow any part of this product, seek immediate medical attention.

Do not use your MAX for unauthorized surveillance, surreptitious use, or in any manner that violates

personal privacy laws. Such use is often strictly forbidden and can subject the operator to serious liability and criminal prosecution.

CAUTION: Radio-frequency emissions from electronic equipment can negatively affect the operation of other electronic equipment, causing them to malfunction. The wireless transmitters and electrical circuits in your product may cause interference in other electronic equipment. When using GoPro products near another device, read that device's user guide for any safety instructions. Power your camera off whenever it is forbidden to use it or when it may cause interference.

NOTICE: Avoid exposing your camera or battery to very cold or very hot temperatures. Low or high temperature conditions may temporarily shorten the battery life or cause the camera to temporarily stop working properly. The microphones in your camera are designed to provide optimal audio capture in a variety of environments. When Wi-Fi is on, microphones may detect and capture low-level noises. To prevent this noise, turn off Wi-Fi when recording, Abide by all local laws when using your GoPro and related mounts and accessories, including all privacy laws, which may restrict recording in certain areas



WARNING: The dual lenses of MAX are unprotected and are susceptible to scratches if not cared for properly. Always store MAX with the provided lens protection and avoid resting the lens on any surface. Scratches to the lens are not covered by the warranty.

BATTERY SAFETY



WARNING: The following precautions apply to the rechargeable battery provided with your MAX. Improper battery use may result in serious injury, death, property damage, or damage to the product or related accessories as a result of battery fluid leakage, fire, overheating, or explosion. Released battery fluid is corrosive and may be toxic. It can cause skin and eye burns, and is harmful if swallowed. If fluid from the battery contacts skin or clothes, flush skin with water immediately. Before inserting any new battery, thoroughly clean the battery compartment with a dry cloth. To reduce the risk of injury and ensure proper performance of your battery, follow these quidelines:

- · Keep batteries out of the reach of children.
- Keep batteries clean and dry.
- Do not dismantle, open or shred battery pack or cells. Do not short-circuit the battery.
 Do not store batteries in a box or drawer where they may short-circuit each other or be short-circuited by other metal objects. Failure to follow this warning can cause an explosion or fire.
- Do not subject batteries to mechanical shock.
- · Never use or charge a damaged, leaky or swollen battery.
- Batteries need to be charged before use. Always use the charger that came with your MAX and refer to the manufacturer's instructions or equipment manual for proper charging instructions.
- · Do not leave a battery on prolonged charge when not in use. Discontinue use

- immediately should you notice any discoloration or deformation in the battery. Failure to observe these warnings could result in the battery leaking, overheating, rupturing, or catching fire.
- Batteries give their best performance when they are operated at normal room temperature 68°F (20°C) ± 9°F (5°C).
- · When possible, remove the battery from the equipment when not in use.
- · Only use authentic GoPro batteries that are designed for MAX.
- Do not dispose of the battery in regular trash containers. Recycle the battery according to your local regulations.

LIMITED WARRANTY

GoPro warrants that for a period of one (1) year from original date of purchase, the product will be free from defects in materials and workmanship under normal use. In the event of a defect, contact GoPro Customer Support (gopro.com/help) for assistance. GoPro's sole obligation under this warranty will be, at its option, to repair or replace the product. This warranty does not apply to products damaged by misuse, accident, or normal wear and tear, Damage resulting from use with non-GoPro batteries. power cables, or other battery charging/recharging accessories or devices is also not covered by this or any warranty. ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICUL AR PURPOSE ARE LIMITED TO THE DURATION OF THIS WARRANTY GOPRO DISCLAIMS ALL OTHER EXPRESSED OR IMPLIED WARRANTIES OR CONDITIONS. TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL GOPRO BE LIABLE FOR ANY LOSS OF DATA, REVENUE OR PROFIT, OR FOR ANY SPECIAL, INDIRECT, CONSEQUENTIAL, INCIDENTAL OR PUNITIVE DAMAGES, HOWEVER CAUSED, ARISING OUT OF OR RELATED TO THE USE OF OR INABILITY TO USE THE PRODUCT. EVEN IF GOPRO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT WILL GOPRO'S LIABILITY EXCEED THE AMOUNT PAID BY YOU FOR THE PRODUCT. Some jurisdictions do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary by jurisdiction,

European Union Consumers: GoPro grants for a period of two (2) years from the original date of purchase of the relevant GoPro product and free of charge a limited manufacturer's guarantee to the end customer. This shall not limit any consumer rights which you have under consumer law; instead it grants you additional rights. The guarantee is governed by the following terms and conditions. GoPro guarantees that for a period of two (2) years from the original date of purchase, your GoPro product will be free from defects in materials and workmanship under normal use and provided it has been used in accordance with the instructions in the relevant GoPro user manual (gopro.com/help). In the event of a defect, contact GoPro Customer Support (gopro.com/help) for assistance and be prepared to present the original purchase receipt. GoPro's sole obligation under this quarantee will be, at its option, to repair or replace the defective product. This guarantee does not apply to products damaged by misuse, accident, or normal wear and tear. This guarantee also does not apply to products damaged as a result of repair works not performed by GoPro or an authorized GoPro dealer.

Australian Consumers: The benefits given by the GoPro limited warranty are in addition to other

rights and remedies available to you. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and to compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the product repaired or replaced if it fails to be of acceptable quality and the failure does not amount to a major failure.

Open Source Software: Disclosures and disclaimers in connection with GoPro's incorporation of certain open-source software into its products can be found at gopro.com/support/open-source.



Please dispose of used batteries properly, following local regulations. Do not incinerate.



This symbol means that, according to local laws and regulations, your product should be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. Some collection points accept products for free. The separate collection and recycling of your product at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.



Hereby, GoPro, Inc. declares that the radio equipment type GoPro MAX is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: qopro.com/help.

GoPro Inc., 3000 Clearview Way, San Mateo CA 94402 USA GoPro GmbH, Floessergasse 2, 81369 Munich, Germany

The GePro MAX (SPCCI) transmits at 2.400 GHz – 2.4835 GHz. The maximum power transmitted in this frequency band is EIRP 88.72 mW. It also transmits at the 5.180 GHz - 5.825 GHz frequency bands (except 5.35GHz - 5.47GHz). The maximum power transmitted in these frequency bands is EIRP 112.20 mW. GePro MAX (SPCCI) Hardware Version: EVT; Software Version: H19.03.00.07.00. Country specific rules and regulations can prevent or limit the use of some or all of the listed frequency bands and power level

IC Regulations: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1. This device may not cause interference. 2. This device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003. Canada: 5.150-5.250 GHz, indoor use only.

The Country Code Selection feature is disabled for products marketed in the US/Canada.

IMPORTANT NOTE:

IC Radiation Exposure Statement

This EUT is in compliance with SAR for general population/uncontrolled exposure limits in IC RSS-102 and has been tested in accordance with the measurement methods and procedures specified in IEEE 1528.

ELECTRICAL RATINGS

5V === 2.5A

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, includin interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

The provided shielded USB cable must be used with this unit to ensure compliance with the class B FCC limits.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Information (SAR)

This device has been designed and manufactured to comply with the limits for exposure to RF energy set by the Federal Communications Commission (FCC) of the United States, Industry Canada (IC) and the European Union and other countries.

The exposure standards for wireless devices employ a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC/IC is 1.6W/kg averaged over 1 gram of tissue. The SAR limit recommended by The Council of the European Union is 2.0W/kg averaged over any 10 grams of tissue. The highest reported SAR value to FCC/IC are: 1.173 W/kg for head and 1.195 W/kg for body. The highest reported SAR value to European Union are: 0.795 W/kg for head and body.

The FCC and IC have granted an Equipment Authorization for this device with all reported SAR

levels evaluated as in compliance with the FCC and IC RF exposure guidelines. SAR information on this device is on fille with the FCC and IC, and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: CNFSPCC1 and under the Industry Canada Radio Equipment List database http://www.ic.gc.ca/app/sitt/reltel/srch/nwRdSrch.do? lang=eng after searching 10193A-SPCC1. The milimum usage distance is 10mm for FCC and 5mm for CE.

To find Regulatory Information, swipe down on your camera's touch screen, then tap Preferences > Regional > Regulatory.

REGULATORY INFORMATION

Europe $C \in$ New Zealand R-N7

Russia

Singapore

Complies with IDA Standards DA107035

Ukraine

China CMIIT ID: XXXXXXXXXXX

Malavsia

Nigeria



ข้อกำหนดของ กทช."





Connection and use of this communications equipment is permitted by the Nigerian Communications Commission

Thailand

EU

This telecommunication equipment conforms to the requirements of the National Telecommunications Commission "เครื่อง โทรคมนาคมแลกะอุปรณ์นี้ มีความสอดคล้องตาม



South Korea

Taiwan

제작자 및 설치자는 해당 무선설비가 전파후 신 가능성이 있으므로 인명안전과 관련된 서 비스는 할 수 없습니다. 5150 ~ 5250 MHz 대역 은 실내에 한하여 사용할 수 있습니다

一般設備(低功率電波輻射性電機管理辦法 第12、14條)

經型式認證合格之低功率射顯電機,非經許 可,公司、商號或使用者均不得擅白變更額 率,加大功率或變更原設計之特性及功能。

低功率射額電機之使用不得影響飛航安全及干 擾合法誦信: 經發現有干擾現象時, 應立即停 用, 並改善至無干擾時方得繼續使用。

前項合法通信,指依電信法規定作業之無線電 通信低功率射頻電機需忍受合法通信或工業、 科學及醫療用電波輻射性電機設備之干擾。

Oman

India

Indonesia

OMAN - TRA D100428 TRA/TA-R/5915/18 ETA certificate No: NR-ETA/9742-RLO(NR) NR-ETA/9743-RLO(NR) 57801/SDPPI/2018 3672

Philippines

UAE

Morocco

No.: ESD-1817554C

NTC Type Accepted

TRA REGISTERED NO. ER64590/18 DEALER NO DA0111732/13

NºD'AGRÉMENT MR 17054 ANRT 2018 (09/07/2018)

Paraguay

Vietnam



RIGSTAR S.A. Producto: Cámara Av. Camilo Recalde Modelo: SPCC1 C/ Coronel Toledo Marca: GoPro Ciudad del Este Fabricante: GoPro, Inc. · Alto Parana ·



Israel מספר אישור אלחוטי של משרד התקשורת הוא 51-65802

אסור להחליף את האנטנה המקורית של המכשיר ולא לעשות בו כל שינוי נוכני אחר This product has been Type Approved by Jamaica SMA - SPCC1

Jamaica

Brazil



Modelo: SPCC1 04767-18-08441 Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

Este produto está homologado pela Anatel, de acordo com os procedimentos regulamentados pela Resolução nº242/2000 e atende aos requisitos técnicos aplicados, incluindo os limites de exposição da Taxa de Absorção Específica referente a campos elétricos, magnéticos e eletromagnéticos de radiofrequência, de acordo com as Resoluções nº 303/2002 e 533/2009.

Mexico



La operación de este equipo está sujeta a las siguientes dos condiciones: (1) es rejudic que este equipo o dispositivo no cause interferencia rejudicial y (2) este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

South Africa



