RFID Reader Model 810

Owner's Manual





Copyright © 2008, 3M. All rights reserved.

RFID Reader Model 810 Owner's Manual, 78-8129-3165-3 Rev A

Contents

Safety	1
EMC compliance	3
Overview. Model 810 components. Equipment specifications	5
3M Service	7

Contents

Safety

Intended use

The 3M RFID Reader Model 810 is designed and tested to read and/or program 3M RFID Tags. When used in conjunction with appropriate computer software, the Model 810 can track, monitor, and assist in locating various items equipped with RFID Tags.

Explanation of signal word consequences

	RNING Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury and/or property damage.	
CAUTION Indicates a potentially hazardous situation, which, if not avoided, may result in minor of moderate injury and/or property damage.		

Explanation of product safety labels

or	Attention: Read accompanying documentation
	Risk of electric shock

▲ Warning!

To reduce the risks associated with hazardous voltage contained within the power supply:


- Do not use the power supply if the case or cord are damaged;
- Do not use power supply in outdoor or wet environments;
- Do not attempt to service or repair the RFID circuitry or power supply no user serviceable parts inside.

▲ Caution!

To reduce the risks of damaging the RFID Reader, DO NOT over tighten the antenna cable connection: Tighten this connection finger tight (snug—as tight as possible using only your fingers).

Note: At the end of service life, dispose of the RFID Reader according to federal, state and local requirements.

Label locations



EMC compliance

FCC Intentional Radiator Certification

RFID Reader Model 810	FCC ID: DGFTTS810
	IC: 458A-TTS810

This equipment contains an intentional radiator approved by the FCC and Industry Canada. This device complies with both FCC Part 15 and Canadian ICES-003 rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesirable operation.

Note: This equipment has been tested and found to comply with the limits for a Class A device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

NO MODIFICATION: Modifications to this device shall not be made without the written consent of the 3M Company. Unauthorized modifications may void the authority granted under Federal Communications Commission rules and Industry Canada rules permitting the operation of this device.

This device has been designed to operate only with the following antennas. Antennas not included in this list or having a gain greater than the listed antennas are strictly prohibited for use with this device and may void the authority granted under FCC and Industry Canada Rules permitting the operation of this device.

- 78-8129-2159-7, 12-inch Pad antenna
- 78-8129-2122-5, 8-inch Pad antenna
- 78-8126-8102-7, V-antenna
- 78-8129-2618-2, L-antenna

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communications. Contact your 3M representative as to which antenna is best for your application.

EMC compliance Europe

This equipment complies with the requirements of the R&TTE and EMC directives. See appropriate system owner's manual.

EMC compliance

Overview

Model 810 components

The Model 810 includes the following components:

- 3M RFID Reader
- USB cable connects the RFID Reader to an appropriate computer system
- AC-DC adapter/power cord or Interconnect Box with internal power supplies

Equipment specifications

RFID Reader

Dimensions	Length: 5.125 in. (13.0 cm)	
	Width: 3.0 in. (7.62 cm)	
	Height: 1.0 in. (2.54 cm)	
Weight	3.64 oz. (103.2 g)	
Environmental	Operating temperature range: 50°F to 104°F (10°C to 40°C)	
	Storage temperature range: -40°F to 131°F (-40°C to 55°C)	
	Humidity: 0% to 85% RH, non-condensing	
Electrical	100-240 VAC, 47 to 63 Hz, 0.5 A	

Interconnect Box

Dimensions	Length: 12.0 in. (30.5 cm)
	Width: 12.0 in. (30.5 cm)
	Height: 3.0 in. (7.62 cm)
Weight	3.6 lb. (1.6 kg)
Environmental	Operating temperature range: 50°F to 104°F (10°C to 40°C)
	Storage temperature range: -40°F to 131°F (-40°C to 55°C)
	Humidity: 0% to 85% RH, non-condensing
Electrical	100–240 VAC, 47 to 63 Hz, 1.0 A

Overview

3M Service

To locate service telephone numbers, see your 3M software manual.

3M Library Systems 3M Center, Building 225–4N-14 St. Paul, Minnesota 55144–1000