

MOMENTUM Wireless

M2 AEBT



Instruction Manual

Contents

- Important safety instructions 2**
- The MOMENTUM Wireless (M2 AEBT) 4**
- Package includes..... 6**
- Product overview..... 7**
 - Overview of the headphones 7
 - Overview of pictograms 7
 - Overview of LED indicators..... 9
 - Overview of buttons 10
- Getting started 11**
 - Charging basics 11
 - Pairing the headphones 13
 - Adjusting the headband 16
- Using the headphones 17**
 - Switching the headphones on 17
 - Switching the headphones off..... 17
 - Adjusting the volume 18
 - Checking the remaining battery life 19
 - Music functions 20
 - Call functions 21
 - Voice control functions 23
 - Using the audio cable 24
- Caring and maintenance..... 25**
 - Replacing the earpads 25
 - Caring for leather parts 25
 - Storing and handling 26
 - Updating the software using the Sennheiser Updater 26
 - Replacing/removing the rechargeable battery 27
- Troubleshooting..... 28**
 - Clearing the paired settings 29
- Specifications 30**
- Manufacturer declarations..... 31**



Important safety instructions

- ▶ Read the instruction manual, safety guide, quick guide (as supplied) carefully and completely before using the product.
- ▶ Always include this safety guide when passing the product on to third parties.
- ▶ Do not use an obviously defective product.

Preventing damage to health and accidents

- ▶ Protect your hearing from high volume levels. Permanent hearing damage may occur when headphones are used at high volume levels for long periods of time. Sennheiser headphones sound exceptionally good at low and medium volume levels.
- ▶ Keep the headphones at least 10 cm/3.94" from cardiac pacemaker or implanted defibrillator. The headphones contain magnets that generate a magnetic field which could cause interference with cardiac pacemaker and implanted defibrillator.
- ▶ Keep the product and its accessories away from small children and pets. The product contains small parts which may cause choking hazards to small children and pets.
- ▶ Do not use the product in situations which require special attention (for example, in traffic or when performing skilled jobs).

Preventing damage to the product and malfunctions

- ▶ Always keep the product dry and do not expose it to extreme temperatures to avoid corrosion or deformation. The normal operating temperature is from 0 to 40°C/32 to 104°F.
- ▶ Use only attachments/accessories/spare parts supplied or recommended by Sennheiser.
- ▶ Clean the non-leather parts of the product only with a soft, dry cloth.
- ▶ Use only the product in environments where **Bluetooth®** wireless transmission is permitted.
- ▶ Do not wear the headphones during charging because the built-in rechargeable battery can get warm.
- ▶ Use the product with care and store it in a clean, dust-free environment.
- ▶ Do not operate the product near heat sources.

Caring for leather parts

- ▶ Gently wipe leather parts periodically with a clean, soft cloth dampened with water.
- ▶ Do not use leather polish, detergents or harsh soaps to clean leather parts.
- ▶ Avoid storing the headphones in a damp or humid environment.

Intended use/Liability



This wireless headphones are designed for use with mobile devices (e. g. mobile music players, mobile phones, tablets, computers) that support wireless communication via **Bluetooth**. Compatible **Bluetooth** devices include those that support the following profiles: Hands Free Profile (HFP), Headset Profile (HSP), Advanced Audio Distribution Profile (A2DP), Audio/Video Remote Control Profile (AVRCP), and Device ID profile (DIP).

It is considered improper use when this product is used for any application not named in the associated instruction manuals and product guides.

Sennheiser does not accept liability for damage arising from abuse or misuse of this product and its attachments/accessories.

Safety instructions for the Lithium-Polymer battery pack

WARNING

In extreme cases, abuse or misuse of Lithium-Polymer battery pack can lead to:



- explosion,
- fire development,
- heat generation or
- smoke or gas development.

	Dispose of products with built-in rechargeable batteries at special collection points or return them to your specialist dealer.
	Use only rechargeable batteries and chargers recommended by Sennheiser.
	Charge products with built-in rechargeable batteries at ambient temperatures between 10 and 40°C (+/-5°C) / 50 and 104°F (+/-41°F).
	Switch battery-powered products off after use.
	When not using the product for an extended period of time, charge them regularly (about every 3 months).
	Do not expose to heat above 70°C/158°F, e.g. do not expose to sunlight or throw into fire.
	Do not charge products with built-in rechargeable batteries if the product is obviously defective.

The MOMENTUM Wireless (M2 AEBT)

Proudly leading the way into the next generation of Sennheiser's highly regarded MOMENTUM line, the M2 AEBT brings you freedom of movement and total purity of sound. **Bluetooth®** wireless technology makes a cable unnecessary, and thanks to Sennheiser's innovative **NoiseGard™** hybrid active noise cancellation technology, you'll be able to enjoy your favorite music on the go in amazing clarity. Two pairs of internal and external microphones work together to virtually eliminate ambient noise at both high and low frequencies.

A technological masterpiece in a stunning package, the M2 AEBT sports an elegant stainless steel construction and luxurious leather padding of the highest quality, fully in keeping with the exacting aesthetic principles of the MOMENTUM line while the foldable headband and spacious ear cups add a new level of comfort and convenience to your listening experience. Sennheiser's M2AEBT – a modern classic.

Features

- Closed circumaural design featuring **Bluetooth®** wireless technology
- Luxurious leather headband and earpads for a feeling of substance and quality
- Amazing stereo sound across the audible range thanks to Sennheiser's 18Ω high-end transducers
- Robust, foldable headband for easy storage on the go
- **NoiseGard™** hybrid active noise cancellation for optimum isolation from background noise and outstanding audio performance
- Immediate pairing to smart devices using NFC
- **VoiceMax™** technology utilizing two built-in microphones for voice communication to emphasize speech quality and remove external noise
- 22 hours of battery life span with both **Bluetooth®** and **NoiseGard™** activated
- Comes with an attachable audio cable for use in environments where **Bluetooth®** connectivity is not permitted.



Bluetooth

The MOMENTUM Wireless (M2 AEBT) headphones comply with the **Bluetooth** technology 4.0 standard and are compatible with all **Bluetooth** 1.1, 1.2, 2.0, 2.1, and 4.0 devices with the following profiles:

- **Headset Profile (HSP) 1.2** - The profile that provides the basic functionalities used by the headphones to interact with a **Bluetooth** smartphone.
- **Hands-Free Profile (HFP) 1.6** - A profile used by the headphones to interact with a **Bluetooth** smartphone. This profile provides extra functionalities as compared to the HSP. If a function, such as voice control, is not supported by the HSP profile, the HFP takes place.
- **Audio/Video Remote Control Profile (AVRCP) 1.5** - The profile used to control music on the **Bluetooth** device from the headphones (Play, pause, skip music track, etc.).
- **Advanced Audio Distribution Profile (A2DP) 1.3, supporting aptX®** - The profile used by a **Bluetooth** device to stream high-quality stereo music to the headphones.
- **Device ID Profile (DIP) 1.3** - The profile used by the headphones to be identified, such as by its manufacturer, product ID, product version, etc.



NFC

Near Field Communication (NFC) is a short-range wireless technology that enables connection and communication between NFC-capable electronic devices by placing them near one another or with a single touch.



VoiceMax

VoiceMax™ dual microphone technology filters away the background noise. 2 microphones work in synergy; one to emphasize your voice, and the other to remove the ambient noise.



NoiseGard

The **NoiseGard™** hybrid Active Noise Cancellation system is a combination of 2 noise-cancellation systems composed of a total of 4 microphones. Two microphones with openings to the outside of the headphones work as a Feed-Forward active noise cancellation system that reduces noise at the high frequency band, while the other two microphones inside the headphones work as a Feed-Back active noise cancellation system that reduces noise at the low frequencies. The combination of these 2 microphone systems results in a broad reduction in noise covering a wider band of frequencies.



aptX®

With aptX® audio coding, you can be assured of crisp, pure and full stereo sound. It allows you to not only hear, but experience and feel the audio as it was intended. Utilizing aptX®, **Bluetooth** technology can now offer wireless audio quality that is indistinguishable from the highest quality wired connection.

Package includes



Headphones



Hard carry case



Soft carry case



Audio cable with 2.5-mm and 3.5-mm jack



USB cable with micro USB connector




In-flight adapter



Quick start guide



Safety guide

 A list of accessories can be found at www.sennheiser.com. For information, contact your local Sennheiser partner: www.sennheiser.com> "Sales Partner".

Product overview




Overview of the headphones



- ① Headband
- ② Earpads
- ③ Earcups
- ④ Microphone
- ⑤ NFC Antenna
- ⑥ LED indicator
- ⑦ Power button
- ⑧ 3-way multifunction button
- ⑨ Audio input
- ⑩ Micro USB input

Overview of pictograms

Pictograms for using buttons

Pictogram	Meaning
	Press and immediately release the button
	Press the button twice
	Press the button and hold for 5 seconds


Pictograms for LED indicators

Pictogram	Meaning
	LED shines
	Time interval or interruption. Causes LED to flash
	Continuous shine/flash
	Time interval of flashing

Examples of pictographs used in this manual:

Pictogram	Meaning
	The LED continuously flashes on and off
	The LED continuously flashes once every 3 seconds
	The LED continuously shines
	The LED flashes thrice per second.

The icon with „i”

 Notes marked with the pictogram “i” provide useful information on the use of the headphones.

Overview of LED indicators



LED indicators when operating


Indicator	Meaning
	Headphones are switching on Pairing with a device is successful
	Headphones are switching off
	Headphones are in pairing mode
	Headphones are disconnected from the device
	Headphones, with an almost empty battery, are disconnected from the device
	Pair settings on the headphones are cleared


LED indicators when making a call

Indicator	Meaning
	Incoming call
	Incoming call with an almost empty battery


Overview of buttons







Power button



Press	Function	Page
	Switches the headphones on and off	17

3-way multifunction button



Press	Function	Page
	Accepts/ends a call	21
	Accepts an incoming call and ends the active call	21
	Plays/pauses a song	20
	Rejects a call	21
	Activates the voice control	23
	Transfers a call	22
	Plays the next song	20
	Accepts an incoming call and puts the active call on hold/Toggles between 2 calls	21
	Checks the battery life	19
	Plays the previous song	20
	Rewinds a song	20
	Fast-forwards a song	20

Getting started

Charging basics



A complete charging cycle takes about 3 hours. Before using the headphones for the first time, charge the headphones for a complete charging cycle without interruption.

When the battery is almost empty or when you are charging the headphones, the LED emits a signal and a voice message prompts you of the charge condition of the battery. When the battery life drops to a low level, a voice message prompts you to recharge the headphones to avoid call and music disruptions.

It is recommended to charge the headphones using only the supplied USB cable and a USB power adaptor with a rated output of 500 mA or higher.

LED	Meaning	Voice prompt
	Battery is almost empty (less than 2%)	„Recharge headset“ „Power off“
	Battery is less than 15% charged	„Below 3 hours play time“
	Battery is less than 25% charged	„Between 3 and 5 hours play time“
	Battery is less than 50% charged	„Between 5 and 11 hours play time“
	Battery is less than 80% charged	„Between 11 and 18 hours play time“
	Battery is more than 80% charged	„Between 18 and 22 hours play time“
	Battery is fully charged	„Between 18 and 22 hours play time“

Charging the headphones

1. Connect the micro USB plug of the charging cable to the micro USB input of your headphones.
 2. Connect the USB plug to a power adaptor (not included) or to the USB car charger adaptor (not included), and connect to the power source. If you are using a computer, connect the USB plug to the USB port.
- The LED flashes/shines depending on the battery condition of the headphones, as provided in the table above.



i When you connect the headphones to a computer using the USB cable, it will automatically switch off. Switch the headphones on, see page 17, to continue to listen to music or make calls from your smartphone via **Bluetooth** wireless connection.

You can also use the cable to listen to a media player on your computer. If you are connecting to a computer for the first time, you may need to set your M2 AEBT headphones as the default speaker from the Sound control panel of your computer.

Pairing the headphones

CAUTION

Danger of malfunction!



The transmitted radio waves of mobile phones can impair the operation of sensitive and unprotected devices.

- ▶ Make calls on the headphones only in locations where **Bluetooth** wireless transmission is permitted.

To pair your headphones with a **Bluetooth** device you can either use the Near Field Communication (NFC) or the **Bluetooth** search function. To connect the headphones, **Bluetooth** needs to be activated in both cases of pairing.

The M2 AEBT headphones comply with the **Bluetooth** 4.0 standard. In order for the data to be transmitted wirelessly using **Bluetooth** technology, you need to pair your headphones to compatible **Bluetooth** devices that support the following profiles:

- ▶ Hands Free Profile (HFP)
- ▶ Headset Profile (HSP)
- ▶ Audio/Video Remote Control Profile (AVRCP)
- ▶ Advanced Audio Distribution Profile (A2DP)
- ▶ Device ID Profile (DIP)

When you switch the headphones on, it automatically tries to connect to the last two connected **Bluetooth** devices. The headphones can save the connection profiles of up to eight **Bluetooth** devices with which it had been paired.

If you pair the headphones to a ninth **Bluetooth** device, the saved connection profile of the least used **Bluetooth** device will be overwritten. If you want to re-establish a connection with the overwritten **Bluetooth** device, you have to pair it back to the headphones again.



You can easily pair and connect your wireless headphones to your smartphone if the device supports the Near Field Communication (NFC) technology.



The following sections describe, using a smartphone as an example, how to pair your M2 AEBT headphones to an NFC or **Bluetooth** device. If the instructions provided do not work on your smartphone, please proceed as described in the instruction manual of your device.

Pairing the headphones to an NFC device


1. Switch the NFC function on from your smartphone.
2. Place your smartphone close, about less than 3 cm, to the NFC antenna on the left earcup of the headphones.
You hear the voice prompts „power on“ and „pairing“ and the LED flashes blue and red.
3. Depending on your smartphone, click „Yes“ if a verification to pair to the headphones appears on the screen.
If the pairing is successful, you hear the voice prompt „connected“ and the LED switches off.



Pairing the headphones to a Bluetooth device

Ensure that your headphones are within the 20 cm range of your smartphone during this procedure.


1. Switch the headphones on (see page 17). Continuously press the power button until you hear the voice prompt „*pairing*“ and the LED flashes blue and red.
The headphones are in pairing mode.
2. Enable the **Bluetooth** visibility from your smartphone.
3. From your smartphone, search for **Bluetooth** devices.
All active **Bluetooth** devices in the proximity of your smartphone are displayed.
4. From the list of **Bluetooth** devices that appears, select „*MOMENTUM M2 AEBT*“ to establish a **Bluetooth** connection to the headphones. If necessary, enter the default PIN code “0000”.
If the pairing is successful, you hear the voice prompt „*connected*“ and the LED switches off.



i If no connection is established within 5 minutes, the pairing mode breaks down completely and the headphones go to the disconnected state. Switch the headphones off and repeat the pairing procedure.

Disconnecting the headphones from an NFC or Bluetooth device

- ▶ Disable the **Bluetooth** visibility from your smartphone.
The headphones are disconnected from the smartphone, and you hear the voice prompt „disconnected“. The headphones then searches for other previously paired devices. If no device is found, you hear the voice prompt „no device found“ after few minutes.



Adjusting the headband

For good sound quality and best possible wearing comfort, you can adjust the earpad location on the headband to properly match the size of your head. The earcups feature a locking mechanism that you can easily slide up and down through the headband slider.

- ▶ Wear the headphones so that the headband runs over the top of your head.
- ▶ Adjust the location of the earpads by moving the earcups up and down of the headband slider until:
 - your ears are comfortably covered by the earpads,
 - you feel even, gentle pressure around your ears,
 - a snug fit of the headband on the head is ensured.

