


Out Band Antenna Conducted Emission at Antenna Terminal Plot




*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 0.51 dBm
Ref 10 dBm Att 40 dB SWT 250 ms 2.405038000 GHz

1 PK
MAXH



*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 0.30 dBm
Ref 10 dBm Att 40 dB SWT 2.3 s 2.403341000 GHz

1 PK
VIEW



Out Band Antenna Conducted Emission at Antenna Terminal Plot




*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 0.13 dBm
SWT 250 ms 2.445022000 GHz

Ref 10 dBm

Att 40 dB

1 PK
MAXH




*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz -0.79 dBm
SWT 2.3 s 2.414000000 GHz

Ref 10 dBm

Att 40 dB

1 PK
MAXH



Out Band Antenna Conducted Emission at Antenna Terminal Plot




*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 0.38 dBm
SWT 250 ms 2.480006000 GHz

Ref 10 dBm

Att 40 dB

1 PK
MAXH




*RBW 100 kHz Marker 1 [T1]
*VBW 300 kHz 0.67 dBm
SWT 2.3 s 2.477559000 GHz

Ref 10 dBm

Att 40 dB


1 PK
MAXH



Bandedge Plots




Ref 10 dBm Att 40 dB SWT 2.5 ms
 *RBW 100 kHz Marker 1 [T1]
 *VBW 300 kHz -43.73 dBm
 2.400000000 GHz



Calculation at
 2.400GHz:
 $101.8 - 30.1 - 39.43$
 $= \underline{32.37\text{dB}\mu\text{V/m}}$
 <limit 54.0dB $\mu\text{V/m}$
 PASS



Ref 10 dBm Att 40 dB SWT 2.5 ms
 *RBW 100 kHz Marker 1 [T1]
 *VBW 300 kHz -50.98 dBm
 2.483500000 GHz



Calculation at
 2.4835GHz:
 $101.4 - 30.1 - 49.73$
 $= \underline{21.57\text{dB}\mu\text{V/m}}$
 <limit 54.0dB $\mu\text{V/m}$
 PASS