
6. Photos

6.1 Setup Photo (Conducted Emission)

Front View




Side View



Cosmos Corporation

6.2 Setup Photo (Radiated Emission, Maximum Carrier Output power, Frequency Tolerance)

Front View (9kHz - 30MHz / Angle 1)



Rear View (9kHz - 30MHz / Angle 1)




Cosmos Corporation

6.2 Setup Photo (Continued)(Radiated Emission, Maximum Carrier Output power, Frequency Tolerance)

Front View (9kHz - 30MHz / Angle 2)



Rear View (9kHz - 30MHz / Angle 2)



6.2 Setup Photo (Continued) (Radiated Emission, Maximum Carrier Output power, Frequency Tolerance)

Front View (9kHz - 30MHz / Angle 3)




Rear View (9kHz - 30MHz / Angle 3)



Cosmos Corporation

6.2 Setup Photo (Continued) (Radiated Emission)

Front View (Above 30MHz / Angle 1)



Rear View (Above 30MHz / Angle 1)



Cosmos Corporation

6.2 Setup Photo (Continued) (Radiated Emission)

Front View (Above 30MHz / Angle 2)



Rear View (Above 30MHz / Angle 2)



Cosmos Corporation

6.2 Setup Photo (Continued) (Radiated Emission)

Front View (Above 30MHz / Angle 3)



Rear View (Above 30MHz / Angle 3)



Cosmos Corporation

6.2 Setup Photo (Continued)

Closeup (Angle 1)




Closeup (Angle 1)



Cosmos Corporation

6.2 Setup Photo (Continued)

Closeup (Angle 2)




Closeup (Angle 2)



Cosmos Corporation

6.2 Setup Photo (Continued)

Closeup (Angle 3)



Closeup (Angle 3)

