


Plot # 1 20 dB Occupied Bandwidth




Plot # 2 20 dB Occupied Bandwidth



Plot # 3 20 dB Occupied Bandwidth



Plot # 4 Channel Hopping Frequency Separation




SPAN 3.00 MHz


50 ms

CENTER 915.000 MHz


Plot # 5 Average Time of Occupancy Low End of Frequency Band




Plot # 6 Average Time of Occupancy Low End of Frequency Band




Plot # 7 Average Time of Occupancy Middle of Frequency Band




Plot # 8 Average Time of Occupancy Middle of Frequency Band




Plot # 9 Average Time of Occupancy High End of Frequency Band




Plot # 10 Average Time of Occupancy High End of Frequency Band




### Plot # 11 Band-Edge Spurious Emissions at Antenna Terminals Low End of Frequency Band Single Frequency Mode



### Plot # 12 Band-Edge Spurious Emissions at Antenna Terminals Low End of Frequency Band Pseudorandom Channel Hopping Mode



### Plot # 13 Band-Edge Spurious Emissions at Antenna Terminals High End of Frequency Band Single Frequency Mode



Plot # 14 Band-Edge Spurious Emissions at Antenna Terminals High End of Frequency Band Pseudorandom Channel Hopping Mode

