

## TABLE OF CONTENTS

<u>Par. No.</u>		<u>Page No.</u>
<b>Section 1 General Description</b>		
1-1	Introduction.....	1-1
1-2	General Description.....	1-1
1-3	Functional and Physical Specifications.....	1-1
<b>Section 2 Installation</b>		
2-1	Introduction.....	2-1
2-2	Electrical Service Recommendations.....	2-1
2-3	Unpacking and Inspection .....	2-1
2-4	Installation Instructions .....	2-2
2-5	+26 VDC Power and Ground Connector P1.....	2-2
2-6	Alarms and Sensing Connector P2.....	2-3
2-7	Differential IIC Clock, Receive, and Transmit Connector P3.....	2-4
2-8	IIC, Power, Alarms,and Controls Connector P4.....	2-4
2-9	IIC, RS485, Power, and Other Signals Connector P5.....	2-6
<b>Section 3 Operating Instructions</b>		
3-1	Introduction.....	3-1
3-2	Initial Start-Up and Operating Procedures .....	3-1
<b>Section 4 Principles of Operation</b>		
4-1	Introduction.....	4-1
4-2	RF Input Signal .....	4-1
4-3	RF Output Load.....	4-1
4-4	Amplifier Functional Description.....	4-1
4-4.1	Input Amplifier .....	4-1
4-4.2	Predistortion Amplifier.....	4-1
4-4.3	Driver Amplifier .....	4-2
4-4.4	Main Amplifier .....	4-2
4-4.5	Multifunction Board.....	4-2
4-5	Amplifier Module Cooling.....	4-2
4-5	Power Distribution .....	4-2

## TABLE OF CONTENTS (Continued)

<u>Par. No.</u>	Section 5 Maintenance	<u>Page No.</u>
5-1	Introduction.....	5-1
5-2	Periodic Maintenance.....	5-1
5-3	Test Equipment Required For Test.....	5-1
5-4	Performance Test.....	5-2
5-4.1	Amplifier Performance Test.....	5-2
5-5	Field Replacement of the Module.....	5-5

### Section 6 Troubleshooting

6-1	Introduction.....	6-1
6-2	Troubleshooting.....	6-1
6-3	Return for Service Procedures.....	6-1
6-3.1	Obtaining an RMA.....	6-1
6-3.2	Repackaging for Shipment.....	6-1

## LIST OF ILLUSTRATIONS

<u>Figure No.</u>		<u>Page No.</u>
1-1	NTGY81AA Multichannel Power Amplifier.....	1-3
2-1	+26 Vdc Power and Ground Connector P1.....	2-2
2-2	Alarms and Sensing Connector P2.....	2-3
2-3	Differential IIC Clock, Receive, and Transmit Connector P3.....	2-4
2-4	IIC, Power, Alarms, and Controls Connector P4.....	2-4
2-5	IIC, RS485, Power and Other Connector P5.....	2-6
4-1	NTGY81AA Multichannel Power Amplifier Functional Block Diagram.....	4-2
5-1	NTGY81AA Amplifier Test Setup Diagram.....	5-3

## LIST OF TABLES

<u>Table No.</u>		<u>Page No.</u>
1-1	NTGY81AA Multichannel Power Amplifier Functional Specifications.....	1-2
2-1	+26 Vdc Power and Ground Connector P1 Definition.....	2-2
2-2	Alarms and Sensing Connector P2 Definition.....	2-3
2-3	Differential IIC Clock, Receive, and Transmit Connector P3 Definition.....	2-4
2-4	IIC, Power, Alarms, and Controls Connector P4 Definition.....	2-5
2-5	IIC, RS485, Power and Other Connector P5 Definition.....	2-6
5-1	Periodic Maintenance.....	5-1
5-2	Test Equipment Required.....	5-2
5-3	Multichannel Power Amplifier NTGY81AA Test Data Sheet.....	5-4

6-1 Troubleshooting.....6-1