

Model 07S

Transmitter Programming Guide

These transmitters make use of icons (symbols) to identify the reaction your security system/keyless entry/and or remote start system, where applicable, will have when any icon (button) is pressed. These icons are programmed at time of installation to meet the needs of the individual and to complement the vehicle that the system is installed in. To replace a transmitter or add transmitters, please follow the programming instructions listed on the pages of this manual.

| BUTTON | RECEIVER CHANNEL | SYSTEM FUNCTION |
|---|------------------|--|
|  | 1 | Lock And Arm Alarm, also initiate and terminates *Panic |
|  | 2 | Unlock And Disarm, also initiates and terminates *Panic. Programmable to unlock drivers door and or all doors. |
|  | 1 | Lock and arm/unlock and disarm. May be programmed to unlock driver's door or all doors. Also will initiate and terminate *Panic. |
|  | 3 | Pulsed or switched output to control Remote Trunk Release or optional device connected to channel 3. |
|  | 3 | When pressed and release two times, will provide pulsed output or activate the Remote Start option when installed. |
| OPT.1 | *4 | When so equipped, this button can be used to operate an optional device connected to channel 4. |
| OPT.2 | *5 | When so equipped, this button can be used to operate an optional device connected to channel 5. |

* Where So Equipped

128-8119

1 of 8

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution :To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.